

LORAN C RECEIVER

XJ - 1

OPERATION MANUAL

SITEX[®]

DOC. NO. XJ-1 07-91

IMPORTANT NOTICE ON XJ-1

IMPORTANT NOTICE ON XJ-1

1. ANTENNA COUPLER INSTALLATION

IF A LAYDOWN BASE MOUNT IS USED, CAULKING OR SEALING COMPOUND MUST BE APPLIED AROUND THE BASE OF THE COUPLER AND THE CABLE ENTRANCE TO PREVENT WATERLEAKAGE WHEN COUPLER IS IN HORIZONTAL POSITION.

2. GRI ENTRY PROCEDURE

WHEN ALL 9'S APPEAR ON THE DISPLAY WITHOUT THE BAR (-) INDICATOR, SIMPLY PRESS THE 4 DIGIT GRI NUMBER OF YOUR AREA AND THEN THE ENT KEY.

ENTRY PROCEDURE

PRESS	ON	FOR POWER ON	OBSERVE 9'S
	(OFF)		
PRESS	(#)	(#)	(#) GRI NUMBER FOR YOUR AREA
PRESS	(ENT)	TO ENTER GRI	

OBSERVE NORMAL OPERATION

NOTE: 9'S MAY APPEAR FROM STARTING ENGINE WITH EQUIPMENT ON.

3. REVERSE POLARITY

REVERSE POLARITY WILL CAUSE INTERNAL DAMAGE NOT COVERED UNDER WARRANTY. THE FOLLOWING PROCEDURE WILL GIVE ADDITIONAL REVERSE POLARITY PROTECTION.

INSTALL A 5 AMP SLO BLO FUSE IN THE NEGATIVE SIDE OF THE POWER CABLE.

ATTACH THE POWER CABLE TO THE LORAN AND OPERATE THE UNIT PRIOR TO ATTACHING THE CASE (R.F.) GROUND.

4. CAUTION

WHEN HANDLING THE LORAN RECEIVER, TAKE CARE NOT TO GRASP BY THE DISPLAY PORTION (TOP HALF) OF THE FACE PLATE. DISCOLORATION OF THE LCD DISPLAY CAN OCCUR. THIS IS USUALLY TEMPORARY, BUT THE LONG TERM EFFECTS OF MISHANDLING COULD BE PERMANENT AND NOT COVERED UNDER YOUR WARRANTY.

5. INSTALLATION NOTICE

THIS UNIT CONTAINS LIQUID CRYSTAL DISPLAYS. PROLONGED EXPOSURE TO DIRECT SUNLIGHT CAN CAUSE THE DISPLAY TO WASH OUT. PERMANENT DAMAGE COULD RESULT. PRECAUTIONS SHOULD BE OBSERVED TO PROVIDE ADEQUATE PROTECTION FROM DIRECT SUN EXPOSURE.

OPERATION	MODE	KEY PRESS SEQUENCE	TYPICAL DISPLAY
POWER ON AND CRT ENTRY	GRI	ALL 9'S OR MODE BAR TO GRI 	142488 441138 1980
TURNING XJ-1 OFF	LDP OR L/L	HOLD 5 SECONDS 	142488 441138 1980
SELECT LDPs	GRI	TOP DISPLAY LOWER DISPLAY THREE SETS OF COLORS WILL STOP BLINKING WHEN SELECTED BAR UNDER CATHODE UNIT SETTLES	142488 441138 1980
LDP DISPLAY	LDP	PRESS POSITION BAR UNDER LDP	142488 441138 1980
LAT/LON DISPLAY	L/L	PRESS POSITION BAR UNDER L/L	142488 441138 1980
SPEED & HEADING DISPLAY SPD	HDC	IF DISPLAY IS ALL 7's REPEAT LDP SELECT POSITION BAR POSITION BAR OVER SPD OVER HDC WILL READ CORRECTLY AFTER 4 MIN OVERWAY	142488 441138 1980
V/CMG DISPLAY	V/CMG	PRESS POSITION BAR OVER V/CMG UPPER-DAY NR, MIN, LOWER-CMG & VNG PRESS AGAIN TO RECALL POSITIVE 10.00	142488 441138 1980
BASIC NAVIGATION PROGRAMMING	WP	SELECT LOP SELECT WP SELECT L/L SELECT WP 	142488 441138 1980
DIRECT ENTRY LOP WAYPOINT	WP	SELECT L/L SELECT WP 	142488 441138 1980
DIRECT ENTRY LAT/LON WAYPOINT	WP	SELECT L/L SELECT WP 	142488 441138 1980
DISPLAY BEARING & DISTANCE	STC	ENTER WP BEARING & DIST POSITION BAR POSITION BAR OVER STC OVER DIST	142488 441138 1980
DISPLAY TIME-TO-GO (TTE)	TTC	ENTER WP POSITION BAR OVER TTC	142488 441138 1980
DISPLAY SIGNAL QUALITY MONITOR	TST	POSITION BAR UNDER TST HIGH NUMBERS INDICATE BETTER SIGNAL DIGITS 5, 4, 5 BLINK	142488 441138 1980
RESET OF POINT OF ORIGIN FOR THE COURSE	LDP, L/L	POSITION BAR OVER WP PRESS TO RT-DISPLAY DESIRED CPN INFO	142488 441138 1980



GRI-Group Repetition Interval
LOR-Lines of Position
L/L-Latitude/Longitude
FST-Test Mode
CMP-Compensation Mode
SET-Set Mode
WP-Waypoint
TTG-Time To Go
SIG-Steering (or Bearing)
HDG-Heading
DIST-Distance To Waypoint
SPD-Speed
V/CMS-Velocity Made Good
and Course Made Good

4990-CENTRAL PACIFIC	8290-NORTH CENTRAL U.S.
5930-CANADIAN EAST COAST	8970-GREAT LAKES
5970-COMMAND LION	8990-NORTH SAUDI ARABIA
5990-CANADIAN EAST COAST	9610-SOUTH CENTRAL U.S.
7170-SOUTH SAUDI ARABIA	9940-U.S. WEST COAST
7930-LABRADOR SEA	9960-NORTHEAST U.S.
7960-GULF OF ALASKA	9970-NORTHWEST U.S.
7970-NORWEGIAN SEA	9980-NORTH ATLANTIC
7980-SOUTHEAST U.S.	9990-NORTH PACIFIC
7990-MEDITERRANEAN SEA	

OPERATION	MODE	KEY PRESS SEQUENCE	TYPICAL DISPLAY
LOP WAYPOINT STORAGE IN MEMORY	WP FROM LOP MODE	POSITION BAR OVER WP 1/R 4/M 2/R ENTER NUMBER 1/R 0 1/R 0 1/R 0 ENTER PRESS	142488 447132
L/L WAYPOINT STORAGE IN MEMORY	WP FROM LOP MODE	POSITION BAR OVER WP 1/R 2/R 7 ENTER NUMBER 1/R 0 1/R 0 1/R 0 ENTER PRESS	275400 447132
WAYPOINT RECALL	WP	FROM L/L OR LOP POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	WAYPOINT MAY BE LOPS OR L/L
ENTER RECALLED WAYPOINT	WP	FROM L/L OR LOP POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	142488 447132
TRANSFERRED MEMORY WAYPOINTS	WP	FROM L/L OR LOP POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	275400 447132
INSTANT MEMORY STORAGE	LOP OR L/L	WHILE THE BAR IS UNDER L/L OR LOP PRESS 1/R 0 2/R 0 ENTER PRESS	142488 447132
INSTANT MEMORY RECALL	LOP OR L/L	WHILE THE BAR IS UNDER L/L OR LOP PRESS 1/R 0 2/R 0 ENTER PRESS	142488 447132
AUTOMATIC WAYPOINT SEQUENCE	WP	FROM L/L OR LOP POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	142488 447132
TO SKIP A WAYPOINT IN AUTO SEQUENCE	LOP OR L/L	5 ENTER STEPS AUTOMATIC WAYPOINT SEQUENCING TO THE NEXT ENTERED WAYPOINT	142488 447132
MANUAL LOP TO L/L CONVERSION	CHP OS PAGE	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	142488 447132

OPERATION	MODE	KEY PRESS SEQUENCE	TYPICAL DISPLAY
IMAGINARY COURSE DISPLAY	CHP OS	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000
LAT/LON MANUAL CORRECTION	CHP	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000
LDP CORRECTION	GRI	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000
COMPLIMENTARY L/L	L/L	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000
HEADING BEARING CORRECTION	CHP	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000
AUTOMATIC ASST CORRECTION	CHP	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000
CHANGING SET MODE LIMITS	SET	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000
ANCHOR WATCH	WP	FROM LOP OR L/L POSITION BAR OVER WP 1/R 0 2/R 0 ENTER PRESS	000000 000000

CONTENTS

PRECAUTIONS	iii
Specifications For Loran C Navigator XJ-1	iv
1. NAMES AND FUNCTIONS OF OPERATING CONTROLS	1
1.1 Names And Functions Of Keys	1
1.1.1 ON/OFF (DIM) Key	1
1.1.2 Operation And CPN Mode Change Key	2
1.1.3 Numeric Keypad	2
1.2 Mark Display Position And Function	6
1.2.1 MEMO And WP	6
1.2.2 Operation Modes: Mark 1 Set To Particular Mode	7
1.2.3 Navigation Computing Function	12
1.3 Alarm Types	15
1.3.1 Audible Alarms	15
1.3.2 Visual Alarms	16
2. OPERATION PROCEDURE	18
2.1 Initial Setting	18
2.2 Usual Operation	21
2.2.1 Precautions And Operations When Power Is Turned On	21
2.2.2 Changing Display Brightness	22
2.2.3 Precautions And Operations When Turning Off Power	23
2.2.4 Changing Secondary Station	23
2.2.5 Changing The Loran C Chain	24
2.3 Correcting Current Location	26
2.3.1 Correction In Terms Of Latitude And Longitude	26
2.3.2 Correction In Terms Of Time Difference	28
2.3.3 Manual Assist For Cycle Selection	30
2.4 Correction Of Radio Wave Propagation (ASF)	35
2.5 Complementary Latitude/Longitude Solution	37
2.6 Instant Memory And Recall	39
2.7 Storing And Recalling Location Or Waypoints	42
2.7.1 Storing Location	42
2.7.2 Recalling Stored Location	45
2.8 Setting Waypoint	48
2.8.1 Setting Waypoint Of Desired Location	48
2.8.2 Enter Waypoints Stored In Instant Memory	51
2.8.3 Setting Of Two Or More Waypoints	52
2.8.4 Waypoint Arrival Alarm	58
2.9 Navigation Display	61
2.9.1 Displaying Cross Track Error	61
2.9.2 Cross Track Error Alarm	63
2.9.3 Indicating Distance To Go	64
2.9.4 Display Of Vessel Speed And Repeated Setting Of Average Vessel Speed	64
2.9.5 Display And Correction Of Heading	67
2.9.6 Display Of Route	69
2.9.7 Display Of Steer To Go	70

2.9.8	Display Of Time To Go	70
2.9.9	Display Of Timer	71
2.9.10	Display Of Imaginary Course Distance And Bearing	72
2.10	Converting From Time Difference To Latitude/Longitude	74
2.11	Displaying Signal Status And Frequency Deviation	78
2.12	Displaying Error Signal	79
2.13	Selecting Connected Devices	80
3.	MAINTENANCE	82
3.1	Replacing Fuse	83
3.2	When Trouble Is Suspected	83
4.	EQUIPMENT INSTALLATION	86
4.1	Locations Of Antenna And Its Coupler	86
4.1.1	Reference Diagrams For Receiving Antenna Mounting Position ...	87
4.2	Typical Installation Of Receiving Antenna	89
4.3	Power Supply And RF Ground	90
4.3.1	Source Voltage	90
4.3.2	Connecting Power	90
4.3.3	RF Ground	91
4.4	External Dimensions	92
4.5	Connecting Antenna Coupler	93

"PRECAUTIONS"

1. Before operating Loran C Navigator XJ-1 read through the manual carefully.
2. If it does not operate properly even with correct handling, repeat the initial setting operating.
3. The Loran C XJ-1 navigator contains an internal lithium battery for memory storage of programmed information. Replacement may be required once every 3 to 5 years. There is no recharging necessary.
4. The Loran C signal may be distorted and a location error may be produced depending on its transmission passage. As a corrective measure, Loran charts where location errors are corrected, and Loran C error correction tables where errors are enumerated, are available commercially.
5. If the unit cannot be energized, the fuse may have blown. The fuse is located on the back panel, however, before replacing the fuse, the cause of the trouble must be located. Contact the nearest agent.
6. If you encounter difficulty with your Loran C settling out or maintaining cycle lock, the problem can often time be traced to R.F. interference. Refer to your operators manual and use the TEST function provided in your Loran C receiver to locate the sources of R.F. interference. The following is a list of known possible interference sources:
 - Television sets
 - Color video sounders
 - Alternators
 - Improperly grounded radar
 - Electronic Tachometers
 - Microprocessor based instruments
 - D. C. powered fluorescent lights
7. If a lay down mount is used to mount the antenna coupler, do not allow the coupler to be lowered to a horizontal position. The coupler should be kept elevated so that water does not lay against the cable entrance.
8. Reverse polarity, improper ground wiring, will cause internal damage not covered under warranty. The following procedure will give additional reverse polarity protection.
 - a. Install a 5 Amp Slo Blo fuse in the negative side of the power cable.
 - b. Attach the power cable to the Loran and operate the unit prior to attaching the case (R.F.) ground.
9. When handling the loran receiver, take care not to grasp by the display portion (top half) of the face plate. Discoloration of the LCD display can occur. This is usually temporary, but the long term effects of mishandling could be permanent and not covered under your warranty.
10. This unit contains liquid crystal displays. Prolonged exposure to direct sun light can cause the display to wash out. Permanent damage could result. Precautions should be observed to provide adequate protection from direct sun exposure.

Specifications For Loran C Navigator XJ-1

SPECIFICATIONS


Frequency	: 100kHz
Tracking stations	: Master and 4 slave stations
GRI selection	: Manual
Secondary selection	: Manual
Acquisition	: Automatic
Tracking	: Automatic
ASF correction	: Automatic (only in the area with compensation table) or manual
Magnetic compass	
compensation	: Automatic or manual
Settling time	: Approx. 3 min. at 0 dB (nominal)
Max. tracking speed	: 80 knots
Max. signal level	: 110 dBuV/m
Notch filter	: Built-in preset: 4
Display element	: One LCD backlighted (3 lines)
Display unit	: LOP: 0.1 usec, Lat/Long: 0.01 min. Bearing: 0.1 degree, Time: 1 min. Speed: 0.1 knot, Distance: 0.01 n.m.
Output data format	: KODEN-717, NMEA-0180 (simple and complex), NMEA-0182, and NMEA-0183 (LOP or L/L)
Ambient temperature	: 0 to 50° C
Power supply	: 11-15 VDC
Power consumption	: 8 VA at 12 VDC

DISPLAY CONTENTS AND MAJOR FUNCTIONS

Position display	: 2 LOPs or Lat/Long
Navigational display	: Speed, heading, steering to go, distance to go, time to go, cross track error, velocity made good, course made good, elapsed time, distance between 2 imaginary points and its bearing
Signal condition	: Displayed
Frequency deviation	: Displayed
Instant memory	: 10 points
Waypoint memory	: 89 points
Route setting	: 1 route (10 waypoints are settable)
Visual alarm	: CS, S/N, station blink
Audible alarm	: Waypoint proximity, anchor watch, cross track error
Compensation	: Position of acquisition (+10 usec), Lat/Long position, magnetic compass variation, additional secondary factor (ASF)

Specifications subject to change without notice.

1. NAMES AND FUNCTIONS OF OPERATING CONTROLS



1.1 Names and Functions of Keys

1.1.1 **DN/OFF** (DIM) Key

(1) Pressing it turns on power and starts the acquisition of Loran signal.

(2) Pressing it again, briefly, dims the Display and Keyboard. An additional brief press will return the Display and Keyboard to their original brightness.

(3) Pressing the **DN/OFF** Key and holding it for a moment will power-down (turn-off) the unit.

1.1.2 Operation and CPN mode change key

(4)  key

The mark 1 moves to the right (upper stage) to select the operation mode.


(5)  key

When the mark 1 is at LOP or L/L position, the mark 2 moves to the left, thereby selecting the navigation display.

(6)  key

When the mark 1 is at LOP or L/L position, the mark 3 moves to the right, thereby selecting the navigation display.

1.1.3 Numeric keypad

(8)  Key. This key is used in several different modes of operation to select and display various data.

GRI, and LOP modes The time difference of the secondary station to be indicated on the Secondary 1 Display is selected.

L/L mode The Latitude and Longitude within normal operation range is displayed. (Note 1)

CMP mode
(Conversion) When a desired time difference is converted into latitude and longitude, the location within a normal operation range is displayed. (Note 1)

TST mode The signal quality of the selected secondary stations is sequentially displayed in the S1 Display Area.

CMP and SET mode Page is advanced.

NOTE 1: Refer to Special Computation of Latitude and Longitude.

(9) **S2** Key. This key is used in several different modes of operation to select and display various data.

GRI and LOP modes	The time difference of the secondary station indicated on the secondary 2 display is selected.
L/L mode	The latitude and longitude within a <u>special</u> operation range are displayed. (Note 1)
CMP mode (Conversion)	When a desired time difference is converted into latitude and longitude, the location within a <u>special</u> operation range is displayed. (Note 1)
TST mode	The signal quality of the selected secondary stations is sequentially displayed in the S1 Display Area.

(10) **+M** Key

GRI mode (Master)	The tracking point of the master station signal is adjusted by plus ten microseconds. Thus, the time difference displayed for both secondary stations is reduced by ten microseconds.
(Secondary 1)	The tracking point of the signal from secondary station 1 is adjusted by plus ten microseconds. Thus, the time difference displayed for secondary station 1 is increased by ten microseconds.
(Secondary 2)	The tracking point of the signal from secondary station 2 is adjusted by plus ten microseconds. Thus, the time difference displayed for secondary station 2 is increased by ten microseconds.
LOP mode	The current location (time difference) is stored in the instant memory. Each press of the key increases the instant memory number by one. The instant memory numbers are 90 to 99. After memory number 99 has been used, instant memory numbers restart from 90. Location information stored at number 90 will be replaced with new TD's.
L/L mode	The current location (latitude/longitude) is stored in instant memory. Each press of the key increased the instant memory number by one. The instant memory numbers are 90 to 99. After memory number 99 has been used, instant memory numbers restart from 90. Location information stored at number 90 will be replaced with new lat/lon's.

NOTE 1: Refer to Special Computation of Latitude/Longitude.

CMP mode (Conversion)	When the stored location (time difference) is converted into latitude/longitude, the designated two-digit memory number (01 to 89) must be entered using the numeric keypad.
WP mode	The memory location (two-digit memory number from 01 to 89) for a waypoint, is stored in this mode.
(11) -/R Key	
GRI mode (Master)	The tracking point of a Loran C signal from the master station is adjusted by minus ten microseconds. The time difference displayed for both secondary stations is thus increased by ten microseconds.
(Secondary 1)	The tracking point of the signal from the S1 secondary station is adjusted by minus ten microseconds. The displayed time difference for the S1 secondary station is thus decreased by ten microseconds.
(Secondary 2)	The tracking point of the signal from the S2 secondary station is adjusted by minus ten microseconds. The displayed time difference for the S2 secondary station is thus decreased by ten microseconds.
LOP mode	The locations stored in the instant memory (memory numbers 90 to 99) are recalled. Each key press decreases the instant memory number by one.
L/L mode	The locations stored in the instant memory (memory numbers 90 to 99) are recalled. Each key press decreases the instant memory number by one.
CMP mode (Conversion)	The stored time difference (TD) is recalled and is converted into latitude and longitude. To designate the stored TD, use a two-digit memory number from 01 to 99.
SET mode	When correcting the bearing of a waypoint by function 02, a negative correction value can be entered. The entered correction value is deducted from the current waypoint bearing. The SET mode function is indicated on the location/navigation display area. By pressing +/M or -/R key, the two-digit function codes will be circled through within the range of 01 to 09.
WP mode	By designating a two-digit memory number from 01 to 99, a stored location is recalled as a waypoint.

(12) **CLR** key

GRI mode The audible alarm for off-course, waypoint arrival, or anchor watch is silenced. Loran C signal acquisition and tracking processes are restarted. An error, if any, during GRI entry is corrected.

LOP mode
and L/L mode The audible alarm for off course, waypoint arrival, or anchor watch is silenced. Pressing this key after storing the current location into the instant memory resumes normal display of the Loran C signal. The location (waypoint) information entered into the instant memory is recalled, and the Loran C receiver is returned to normal display.

CMP mode
(Conversion) After converting from time difference (TD) to latitude/longitude, the location/navigation display is cleared. Errors, if any, produced during the entry of TD for conversion is cleared.

SET mode The latitude/longitude correction manually added to the latitude/longitude reading is cancelled. The correction of heading and bearing information is cancelled. Key-in error produced during correction entry is cleared. Key-in error produced during entry of latitude/longitude correction is cleared. The alarm limit of off-course, arrival, and anchor watch is set to zero (0), thereby inhibiting the audible alarm.

WP mode A recalled destination is cleared and the location/navigation display is returned to the current designation data. Key-in error is cleared.

(13) **ENT** key

GRI mode Pressing the **ENT** key completes GRI entry. By pressing the **ENT** key without pressing the numeric keys for a chain code, all 9's will be displayed.

CMP mode
(Conversion) A time difference (TD) to be converted into latitude/longitude coordinates is entered. The conversion to latitude/longitude is initiated. Two waypoints are entered for computing the distance and bearing of an imaginary course. When the **ENT** key is pressed, a value is entered, and a correction is applied.

SET mode Limit values and data are entered into each of six setting mode functions. When current position is known, lat/lon correction is entered.

WP mode Completes the entry of a waypoint into the navigation course computer.

LOP mode or
L/L mode Pressing the **1/N** key, followed by pressing the **ENT** key resets the point of origin for navigation computation. Pressing the **U** key, followed by pressing the **ENT** key skips the waypoints to the next one.

- (14) **1/N** key
The numeric value 1 is entered for waypoint data, SET mode, GRI correction, and memory number entry. Pressing the **1/N** key, followed by pressing the **ENT** key resets the point of origin for the computed course. Additionally, northern hemisphere is designated when entering latitude information.
- (15) **2/S** key
The numeric value 2 is entered for waypoint data, SET mode, GRI correction, and memory number entry. Additionally, southern hemisphere is designated when entering latitude information.
- (16) **3/E** key
The numeric value 3 is entered for waypoint data, SET mode, GRI correction, and memory number entry. Additionally, eastern hemisphere (easterly from Greenwich, England, from 0 degrees to 180 degrees) is designated when entering longitude information.
- (17) **4/W** key
The numeric value 4 is entered for waypoint data, SET mode, GRI correction, and memory number entry. Additionally, western hemisphere (westerly from Greenwich, England, from 0 degrees to 180 degrees) is designated when entering longitude information.
- (18) **5**, **6**, **7**, **8**, **9**, and **0** keys
Numeric information corresponding to the respective keys is entered when entering navigation method computing, SET mode, GRI, corrections, and memory numbers.
- (19) **0** key
In LOP or L/L mode, pressing the **0** key, followed by pressing the **ENT** key skips to the next waypoint.

1.2 Mark Display Position and Functions

1.2.1 MEMO and WP

a. MEMO

- (1) The storage mark displayed under MEMO indicates whether the location/navigation display information is stored or recalled from memory.

- (2) The number under MEMO is the memory number for a destination which is stored or recalled.

b. WP

- (1) There are two marks (-) active in the WP mode.
- (2) The destination mark indicated above WP for a memory number display denotes the memory display number has been entered as a waypoint.
- (3) Mark 1, if any, above WP mode indicates that the WP mode is selected.
- (4) The WP mode is used for memory entry, recall, and transfer of memory information.
- (5) The waypoint is entered to compute navigation information.
- (6) Pressing the key, followed by pressing the key initiates the anchor watch alarm.
- (7) The line of position (LOP) or latitude/longitude position of the waypoint is displayed.

c. MEMORY/WAYPOINT NUMBER

- (1) When a memory mark is displayed under MEMO, the memory number of the waypoint being recalled, or being stored is indicated.
- (2) When a waypoint mark is displayed below MEMO, it indicates the number of the current waypoint (waypoint in use).
- (3) When several waypoints are set, the waypoint which is currently in use is indicated.
- (4) In SET mode, the SET function number is displayed.
- (5) In LOP or L/L mode, the instant memory number to be stored appears when the key is pressed.
- (6) In LOP or L/L mode, pressing the key displays an instant memory number which has already been stored.

1.2.2 Operation modes: Mark 1 set to particular mode

a. GRI

- (1) A GRI (chain code) can be entered.
- (2) The secondary station is initially selected for TD display between the secondary stations 1 and 2.

- (3) Pressing the **CLR** key will restart Loran C signal acquisition.
 - (4) Cycle selection is active in this mode for all stations.
- b. GRI (Master)
- (1) The tracking point of the master station can be changed.
 - (2) The tracking point of the master station signal can be changed in ten microsecond step by pressing the **0** and **+/M** keys or the **0** and **-/R** keys.
 - (3) the secondary station is changeable using **S1** or **S2** keys.
- c. GRI (Secondary 1)
- (1) The secondary station 1 is selected, or its tracking point is changed.
 - (2) The secondary station can be changed by pressing **S1** key.
 - (3) The tracking point of the signal from secondary station 1 is changed in ten microsecond step by pressing the **1/N** and **+/M** keys or the **1/N** and **-/R** keys.
- d. GRI (Secondary 2)
- (1) The secondary station 2 is selected, or its tracking point is changed.
 - (2) The secondary station can be changed by pressing **S2** key.
 - (3) The tracking point of the signal from secondary station 2 is changed in ten microsecond step by pressing the **2/S** and **+/M** keys or the **2/S** and **-/R** keys.
- e. LOP
- (1) The current position is displayed in TD (time difference).
 - (2) Pressing the **+/M** key will store the current location LOP in the instant memory.
 - (3) Pressing the **-/R** key will recall the instant memory contents.
 - (4) Pressing the **CLR** key resumes normal display.
 - (5) The CPN function becomes active for entering LOP waypoints.
 - (6) The point of origin for navigation computing in the CPN mode can be read by pressing the **1/N** key followed by pressing the **ENT** key.

- (7) The waypoint in use during navigation is changed to the next waypoint by pressing the **[0]** key followed by the **[ENT]** key.

f. L/L

- (1) The current location is displayed in terms of latitude and longitude (degrees, minutes, and 1/100th minute).
- (2) Pressing the **[+M]** key stores the current location in instant memory.
- (3) Pressing the **[-R]** key recalls the instant memory contents.
- (4) Pressing the **[CLR]** key resumes normal latitude/longitude mode display.
- (5) The navigation computing (CPN) function becomes active for entering Lat/Lon waypoints.
- (6) The point of origin for navigation computing can be renewed by pressing the **[1/N]** key followed by pressing the **[ENT]** key.
- (7) The waypoint in use can be cycled sequentially to the next waypoint entered during a navigation by pressing the **[0]** key followed by pressing the **[ENT]** key.

g. WP

- (1) The waypoint can be entered, and stored location data can be transferred in this mode.
- (2) The waypoint can be entered in terms of time difference (TD) or latitude/longitude.
- (3) A stored location can be entered as a waypoint.
- (4) Information stored in the instant memory can be transferred to permanent memory.

h. SET

- (1) Six functions are available.
- (2) The function number is indicated in the memory number display area.
- (3) Any of the six functions is selectable sequentially by pressing the **[+M]** or **[-R]** key.
- (4) SET: 01.....setting of waypoint arrival alarm range.
The waypoint arrival alarm, and waypoint changeover distance when several waypoints have been entered, is set. Setting is available up to 9.9 nautical miles. Setting 0.0 nautical miles inhibits the waypoint arrival alarm and waypoint changeover action.

- (5) SET: 02.....setting of anchor watch alarm range
The alarm range (radius) around the alarm point is set. The anchor watch alarm sounds as soon as the vessel goes beyond the alarm range. This function is activated by pressing the **[0]** key and **[ENT]** key in this mode. Up to 9.9 nautical miles can be set. Setting 0.0 nautical miles inhibits the anchor watch alarm.
- (6) SET: 03.....setting of off-course alarm range (XTE Alarm).
When the vessel goes off-course by a specified distance, the alarm will sound. Setting is available up to 9.9 nautical miles. By setting 0.0 nautical miles, the off-course alarm (cross-track error alarm) is inhibited.
- (7) SET: 04.....speed averaging constant
The range of averaging constant values is from 1 to 5. The default value is 2. The slower the vessel speed, the higher the value required. It takes several minutes to obtain a correct speed reading after the vessel speed has steadied. Vessel course information is computed from the same information that is used to compute vessel speed.
- (8) SET: 05.....data output format
An output format for serial data is settable by entering one of the following five numbers: 1 sets KODEN-717 format; 2 sets NMEA-0182 format; 3 sets NMEA-0183 Number 1 type format; 8 sets NMEA-0180 format; 9 sets NMEA-0183 Number 2 type format.
- (9) SET: 06.....validating complementary lat/lon solution
Because of the hyperbolic (curving) nature of Loran lines plotted on a chart, it is possible in some cases for one LOP to cross another LOP at two different locations. Normally, the Loran unit automatically selects the primary correct crossing point of the two LOP's. The resulting conversion to Lat/Lon will provide a correct, primary Lat/Lon position display. The user/operator may, however, choose to display the second, or complementary, solution. Pressing the **[1/N]** key followed by pressing the **[ENT]** key selects the automatic (default) computation. By pressing the **[0]** key followed by pressing the **[ENT]** key, the complementary solution is displayed.

1. TST

- (1) The signal status of the secondary stations S1 and S2 is displayed. The frequency deviation of the oscillator is indicated for the navigation display (left). The S1 display is selected by the S1 key -- the S2 display by the S2 key.
- (2) For information on the interpretation of the display, refer to "2.11 Displaying Signal Status and Frequency Deviation."

j. CMP

- (1) Any of the five functions is selectable sequentially by pressing the **[S1]** key.

- 01: The amount of compensation currently being applied to LOP's is displayed in this mode. Compensation factors may be added to, or subtracted from LOP's or Latitude/Longitude conversions. Refer to "2.3 Correcting Current Location."
- 02: Bearing (heading STG) compensation is accomplished in this mode. Refer to "2.9.5 a, Correcting Heading."
- 03: Compass auto/manual compensation is selected in this mode. Pressing the **[0]** key, followed by pressing the **[ENT]** key selects manual compensation. Pressing the **[1]** key followed by pressing the **[ENT]** key selects automatic compensation. When left-most digit is 1, correction data is in memory. When left-most digit is 0, no correction data has been entered into memory.
- 04: ASF (Additional Secondary Factors) auto/manual correction is selected in this mode. By pressing the **[0]** key, followed by pressing the **[ENT]** key, manual correction is selected. Pressing the **[1/N]** key, followed by pressing the **[ENT]** key selects automatic correction. When the left-most digit is 1, correction data has been entered into memory. When the left-most digit is 0, no correction data has been entered. Refer to section "2.4, Correction of Radio Wave Propagation."
- 05: CNV the time difference (TD) is converted to LAT/LONG.

k. CS ALARM

- (1) Indicated by a blinking colon (:) in the CS column of displays of S1 display and S2 display, and navigation display in GRI, or TST modes.
- (2) It is an indication that the cycle selection of the secondary station signal is erroneous, and that the displayed time difference (TD) is unreliable.
- (3) The CS alarm can be cleared by moving the mode display bar over TST, and back again to the tracking mode. Unless the signal quality is then correct, the CS alarm will be displayed again.
- (4) If the CS alarm persists, the fault may be signal interference from the generator/alternator, poor antenna installation, improper grounding of the system, or signal interference from the TV set, fluorescent lamps, or wireless transmitter.

1. S/N ALARM

- (1) An S/N alarm condition is indicated by a blinking colon (:) in the S/N column of S1 and S2 displays, and the navigation display in GRI, or TST modes.
- (2) An S/N alarm condition indicates that the Loran signal-to-noise ratio is not within a receivable range, and that the displayed time difference (TD) is unreliable.
- (3) An S/N alarm may persist when there is signal interference from an alternator/generator, poor system grounding, improper installation of the antenna, interference from a TV set, fluorescent lamps, or wireless transmitter.

1.2.3 Navigation computing Function

a. XTE

- (1) Cross track error indicates a deviation, either left or right, to get back to the computed course.
- (2) Course deviation, either right or left, is indicated, and distance off-course is displayed in tenths or hundredths of nautical miles. Tenths of nautical miles are automatically selected when the alarm range is one nautical mile or more. Hundredths of nautical miles are automatically selected when the alarm range is 0.9 nautical miles, or less.

b. SPD

- (1) The vessel speed is indicated by the four left-most digits of the navigation display.
- (2) The speed reading is not quick to respond. At least three or four minutes are required after vessel speed has stabilized to get an accurate reading.
- (3) After changes in vessel speed, either faster or slower, about three or four minutes are required for an accurate speed reading.
- (4) The accuracy of the SPD reading is seriously affected by the lines of position (LOP) crossing angles, the lines of position (LOP) intervals, and any vessel speed or course changes.
- (5) As a general rule, the more rapidly the vessel intersects the lines of position (LOP), the greater the accuracy and stability of the SPD reading.

- (6) SET mode number 04 displays the speed averaging factor value. The normal value is 2, but it may be set from 1 to 5.
- (7) An increase in the speed averaging factor value means an increase in lag time.
- (8) A decrease in the speed averaging factor value means a decrease in lag time.
- (9) To stabilize the SPD reading, the speed averaging factor value must be increased.

c. STG

- (1) The bearing, or steering direction, to the entered waypoint is indicated.
- (2) Unless corrected in CMP mode (function 02), the bearing is displayed in terms of a true bearing.
- (3) When the vessel is on the course, set it between the point of origin and the waypoint, the course deviation is displayed as 0:0. The navigation computing is always carried out with respect to the vessel's current location.

d. TIME

- (1) The time elapsed since turning on the power is displayed on S2 display.
- (2) It is reset by pressing the CLR key.
- (3) In the CPN mode, TIME function becomes independent and is initiated by pressing --- key to move mark 1 to Lop or L/L, and then by --- key to move mark 3 to V/CMG position.
TIME is set in twenty-four hour format using the numeric keypad to enter the necessary six digits for: days; hours; minutes; followed by pressing the ENT key.

e. HDG

- (1) An average heading is displayed in degrees, on the right side of the navigation display area.
- (2) The heading display is unstable when the cross angle of lines of position (LOP) is small, the lines of position are widely separated or the vessel speed is slow.
- (3) When the vessel stops, the fluctuation of heading display increases. During a navigation, it takes two to four minutes for the heading display to stabilize.
- (4) The same as the speed, the heading is computed from the location data.

- (5) The same as the average speed, the velocity averaging factors affect the heading information.
- (6) For heading, the destination cannot be entered.

f. TTG

- (1) Indicates the time required for arriving at the predetermined destination when navigation at the current vessel speed and heading.
- (2) The reading is in hours and minutes.
- (3) The reading appears on the four digits of the navigation display.
- (4) It takes about four minutes for the reading of required time to stabilize and be usable.
- (5) When the vessel moors, the reading of TTG is 99:99 or maximum required time.
- (6) When several waypoints are set, pressing the **[1/N]** and **[ENT]** keys changes over the required time to the next waypoint into the required time to the final waypoint.

g. DIST

- (1) The distance between two points is displayed.
- (2) The distance from the current location to a waypoint entered as a desired waypoint is displayed.
- (3) With DIST function, reading appears on the four right digits of the navigation display area.
- (4) At one nautical mile or less, the minimum resolution of reading is 0.01 nautical mile.
Example: three tenths of a nautical mile is indicated as 0.30.
- (5) When several waypoints are set, pressing the **[1/N]** and **[ENT]** keys changes over the distance to the next waypoint into the distance to the final waypoint.

1.3 Alarm Types

1.3.1 Audible alarms

a. Waypoint arrival alarm

Intermittent audible sound is heard when getting near the waypoint set as a desired waypoint for navigation computing. The alarm stops as soon as the vessel leaves the limit of predetermined area.

The audible sound is stopped by pressing **CLR** key.

The alarm area radius is changeable by SET mode function 01 and entering a value out of 0.1 to 9.9 nautical miles. Entering 0.0 inhibits the arrival alarm, thereby overriding the sound.

b. Anchor watch alarm

When an anchored vessel leaves a predetermined area, and intermittent "pip" sound is developed. The anchor watch alarm is activated by pressing **0** and **ENT** keys in this order in WP mode. Press **CLR** to silence the alarm. The alarm area radius is set at SET mode function number 05. The radius of anchor watch alarm area is settable between 0.1 and 9.9 nautical miles. To inhibit the anchor watch alarm, select SET mode function 02, set the alarm area radius to 0.0 nautical mile, and press the **ENT** key.

c. Cross track error alarm

A continuous sound is developed as soon as the cross track error exceeds a predetermined value. This function warns the operator of an abnormal off course status.

The limit of cross track error alarm is set at SET mode function 03.


The limit of cross track error alarm is set by keying in a value within the range of 0.1 to 9.9 nautical miles and then **ENT**. An alarm is stopped by pressing **CLR** key. To override the cross track error alarm, key in 0.0 as an alarm limit value.

Note: Once waypoints are entered, the waypoint alarm sounds for any entered waypoint. If such is undesirable, override this function.

1.3.2 Visible alarms

a. CS alarm CAUTION

The colon (:) visible under CS of location/navigation display indicates the current location computed and indicated according to Loran signal may not be correct.


When CS alarm is indicated for the master station or a secondary station, the tracking point of Loran C signal may be dubious. CS alarm can forcibly be reset by moving the mark 1 onto TST mode via  key and then resuming the tracking mode. Note that it does not remedy the problem but just stops the alarm display.

b. S/N alarm CAUTION

The colon under S/N on location/navigation method display is a signal-to-noise alarm notifying a faulty status of Loran signal. It shows the received Loran signal is not intense enough to carry out tracking properly.

It is caused by operation beyond the receivable range, poor grounding, improper antenna position, alternator noise, wireless noise on hand or many others.

S/N alarm cannot be reset manually. Its cause must be corrected or the secondary stations or GRI must be replaced with wave of higher intensity.



c. When colon decimal points blink (correction display)

Decimal points blink when current position correction, bearing correction, or compass correction has been entered (about every 12 seconds), and when automatic correction has been activated. It is indicated when lat/long is displayed.


- d. When middle digits (2 digits) blink on time difference display (blink signal display)

Indicates an alarm (blink signal) is sent from the transmitting station of Loran C chain used.


This alarm is usually sent when the transmission status of at least one station in the employed chain is problematic.

When the received signal is not intense enough or because of noise, this alarm may be displayed erratically.

When the time difference is indicated on the display, the third and fourth digits blink. When the latitude/longitude is displayed, mark 1 blinks.

When a blink signal is displayed, the alarm is reset by moving the mode display bar to TST position via either  key and then resuming LOP or L/L.

Colon (:) blinks indicating correction in progress.



- e. When WP mark blinks

Indicates the automatic waypoint changeover function is active with a schedule course entered. The automatic waypoint changeover is cancelled by entering a new waypoint.

- f. When MEMO mark blinks

Indicates the information recalled from the memory is displayed. Immediately below MEMO, the destination memory number of displayed information is indicated by two digits.




- g. When MEMO mark is displayed


The stored location is displayed and not the current location of your own vessel.

2. OPERATION PROCEDURE

2.1 Initial Setting


Loran C station chain and S1 and S2 secondaries are selected for acquiring Loran signal.






- Notes: 1. When the initial setting has been completed, make sure the displayed time difference is correct. If not correct, carry out an operation in "2.3.3 Correction in ten microsecond steps in terms of time difference".
2. Do not proceed to the next operation before CS mark disappears. Otherwise, a correct location may not be displayed.

a. To display current location LOP





b. To display current location L/L



c. Precautions when turning off power



(1) Make sure the mark 1 is at LOP or L/L.




2.2 Usual Operation

This is for routine, day-to-day operation after once completing "2.1 Initial Setting."


2.2.1 Precautions and operations when power is turned on



Note: 1. If the mark 1 is located at other than the position of GRI neither CS mark nor S/N mark is displayed and, instead, mark 1 will blink. Even if mark 1 blinks from time to time during operation, the current location display remains correct. If blinking continues, an error may be produced. Turning power off and then on may correct this situation, however, if this occurs often, the cause must be located and corrected.




When mark 1 is displayed within this range, CS mark and S/N mark are indicated.




When mark 1 is within this range, mark 1 blinks.

a. Power-ON when mark 1 is not at LOP or L/L




2.2.2 Changing display brightness





2.2.3 Precautions and operation when turning off power


Before turning off power, make sure the mark 1 is at LOP or L/L.



2.2.4 Changing secondary station








- (4) Press  key to move the mark 1 to LOP or L/L.
The current location is displayed.


2.2.5 Changing the Loran C chain

During navigation, the vessel may enter another Loran C chain, and the location data may be incorrect. In such a case, Loran C chain must be altered by the following operation.



- (6) Press the **S1** key when the desired time difference of secondary station 1 is displayed.
- (7) Press the **S2** key when the desired time difference of secondary station 2 is displayed. Settling ends when CS mark and S/N mark for master station and secondary stations 1 and 2 go off.
- 




- (8) Press the **←** key to move the mark 1 to LOP or L/L. The current location is displayed.
- 

2.3 Correcting Current Location


2.3.1 Correction in terms of latitude and longitude

When the exact latitude and longitude of the current location are known, a correction is available by the following operation.





a. How to interpret correction amount

Move the mark 1 to CMP and develop 01 on the memory number column. The correction amount will be displayed as illustrated below.



b. Clearing correction











Note: 1. The location correction is cleared also by "2.1 Initial setting".

2.3.2 Correction in terms of time difference
(when correction range is 0.1 - +9.9 microseconds)


The following operation is for when the exact time difference of the current location is known and the difference from the displayed time difference is 0.1 - 9.9 microseconds.



a. Correction of S1 time difference.

- (1) Press  key to move the mark 1 to GRI.
- (2) Press  and numeric keys (0-9) followed by  key when the correction amount is positive or  key when negative, to set the correction amount (2 digits) of time difference for secondary station 1.
- (3) If a numeric key,  key or  key is pressed mistakenly, press the  key.








b. Correction of S2 time difference.

- 
- (4) After making sure of the correction amount for secondary station 1 indicated on the navigation display, press the **ENT** key.
- (5) Press **→** key to move the mark 1 to GRI.
- (6) Press **2/S** and numeric keys (0 - 9) followed by **+M** or **-R** key to set the correction amount (2 digits) of time difference for secondary station.
- (7) If a numeric key, **+M** key or **-R** key is pressed mistakenly, press the **CLR** key.

- 
- 
- (8) After making sure of the correction amount for secondary station 2 indicated on the navigation method display, press the **ENT** key.
- (9) Press **→** key to move the mark 1 to LOP or L/L.

a. Clearing correction


- (1) Press  key to move the mark 1 to GRI
- Press  key to clear secondary station 1.
- Press  key to clear secondary station 2.




NOTE: ALL CORRECTION IS CLEARED WHENEVER THE GRI IS ENTERED BY THE INITIAL SETTING PROCEDURE.

2.3.3 Manual assist for cycle selection (See Note B).

On the border of the service area or when affected by surrounding noise, the time difference displayed may be off in increments of ten microseconds. It tends to occur when the transmitting station is distant.



Typical time difference display



Time difference of master station and secondary stations and acquiring position

The LOP display is different between acquisition errors of the master station and secondaries. A skill is required for judging which acquisition position to correct.

Generally, when receiving three stations, the master station and secondary stations 1 and 2, at least one station has a strong signal and is acquired correctly.

With this assumption, a station having an acquisition error is judged in the following manner.

- a. When either secondary station 1 or 2 has acquisition error:

The secondary station having an acquisition error gives a wrong time difference.

- b. When both secondary stations 1 and 2 have acquisition error

Both secondary stations give a wrong time difference


- c. When master station has acquisition error



The time difference displayed for both secondary stations is off by the acquisition error of the master station.

- d. When master station and secondary stations 1 or 2 have acquisition error:

The time difference is displayed as if the secondary station suffering from an acquisition error were normal or have less error. The time difference is displayed as if the secondary station free from error had an acquisition error.

Carry out the following correcting operation after judging which of the four conditions is causing the error.





Note: 1. To move acquisition position of master station
Set mark 1 to GRI, and then press **0** and
+/M or **-/R** key
 To move acquisition position of secondary station 1
Set mark 1 to GRI, and then press **VN** and
+/M or **-/R** key
 To move acquisition position of secondary station 2
Set mark 1 to GRI, and then press **2/S** and
+/M or **-/R** key

- a. When either secondary station 1 or 2 has acquisition error:
- (1) Press **→** key to align the mark 1 to GRI erroneous secondary the station.
 S1 when secondary station 1 has acquisition error, press **1/N** key.
 S2 when secondary station 2 has acquisition error, press **2/S** key.
 - (2) Press **+/M** or **-/R** key repeatedly until the displayed time difference is correct. Every pressing moves ten micro-seconds.
 - (3) Press **↔** key to move the mark 1 to LOP or L/L.

Note: 2. Under a receiving status where this correction is required, the column may continue to blink. Disregard it and pursue the operation.

b. When both secondary stations 1 and 2 have acquisition error

- (1) Press key to move the mark 1 to GRI.
- (2) Press and or key repeatedly until the displayed time difference for secondary station 1 is correct. Every pressing moves ten microseconds.
- (3) Press or key to return to original GRI display.
- (4) Press and then or key repeatedly until the displayed time difference for secondary station 1 is correct. Every pressing moves ten microseconds.

Note 3: Under a receiving status where this correction is required, the CS and S/N marks may continue to blink. Disregard it and pursue the operation.

c. When master station has acquisition error

- (1) Press key to move the mark 1 to GRI.
- (2) Press and then or key repeatedly until the displayed time difference for master station is correct. Every pressing moves ten microseconds.

Note: 4. key ... when displayed time difference is greater than correct value.
 key ... when displayed time difference is smaller than correct value.

- (3) Press key to move the mark 1 to LOP or L/L.

Note: 5. Under a receiving status where this correction is required, the CS and S/N marks may continue to blink. Disregard it and pursue the operation.

d. When both master station and secondary station 1 (or 2) have acquisition error

- (1) Press key to move the mark 1 to GRI.
- (2) Press and then or key repeatedly until the displayed time difference for secondary station not suffering the acquisition error is correct. Every pressing moves ten microseconds.

Note: 6. key ... when displayed time difference is greater than correct value.
 key ... when displayed time difference is smaller than correct value.

(3) Press for secondary station 1 or for secondary station 2 and or key repeatedly until the displayed time difference for secondary station set in (3) is correct. Every pressing moves ten microseconds.

(4) Press key to move the mark 1 to LOP or L/L.

Note: 7. Under receiving status where this correction is required, the mark 1 may continue to blink. Disregard it and pursue the operation.

Note: 8. CAUTION IS REQUIRED WHEN USING MANUAL ASSISTED CYCLE SELECTION.
Under certain conditions of high level noise and very weak loran signals, the unit may never obtain complete cycle selection and setting. However, when the TIME DIFFERENCE numbers become very stable and not fluctuating, move the Mode Mark 1 to the TST position and observe the signal strength. Refer to Section 2.11 for signal status display.

Note: 9. When multiple correction among master, and are required, press S1 key between corrective operation to return to normal GRI display status.



2.4 Correction of Radio Wave Propagation (ASF)


Some error may be produced between the time difference on the chart and that displayed on the receiver.

One reason for it is that the time difference displayed on the receiver is slightly longer than the time difference on the chart by the amount corresponding to the propagation on land from the terrestrial transmitting station. The correction for the delay in time difference due to this propagation on land is referred to as a radio wave propagation correction (ASF).

This correction is either automatic or manual ("2.3.2 Correction in terms of time difference").

The operation procedure for automatic correction is as follows.




- (5) Press  key to move the mark 1 to LOP or L/L. The corrected position is displayed.


Note: 1 In this correction mode, ASF is displayed in the left side navigation display.

a. Display during automatic ASF correction mode.

When mark 1 is at <LOP>




When mark 1 is at <L/L>



Note: 1. About one minute thirty seconds after the step (3) of automatic correction, blinking starts and, every twelve seconds, the point or colon (:) blinks.

b. Operation procedure for manual ASF operation


- (1) Press key to move the mark 1 to CMP.
- (2) Press or key repeatedly until 04 is displayed on the memory number column.
- (3) Enter ASF correction value (-9.9 to +9.9) through numeral keys.
- (4) If the value is negative, press and then keys. If positive, press key.





Note: 2. The correction is also cleared by "2.1 Initial setting".


2.5 Complementary Latitude/Longitude Solution

Each group of loran C stations is located geographically to provide the best coverage within a certain area. When the loran C unit is used outside of the normal coverage area, a special computation is required. This is named a "COMPLEMENTARY SOLUTION". This special computation can be selected either manually or automatically using the following procedure.





a. Manual selection and automatic selection





b. Typical display of manually selected position.



NOTE: Using this operation is not normally required except when the loran C unit is used in or near the area requiring special computation. Some knowledge of the local area of operation is helpful to determine this selection and the true Latitude/Longitude position. When the displayed Lat-Lon is obviously not correct, press **S1** or **S2** key to obtain the correct readout.

2.6 Instant Memory and Recall


The current position can be stored, and the stored position can be recalled.

Notes: 1. When it is attempted to store eleven or more points, the oldest points are erased so that the ten most recently entered points are stored at all times. Store a position to be saved by transferring it to the permanent memory. (See "2.7.3 Changing number from instant memory to permanent memory.")

2. The ten locations stored in instant memory are retained even when the power is turned off.

2.6.1 Operation of instant memory


As current location data, any time difference and latitude/longitude can be stored in the instant memory.






- Notes:
1. To store the current location again, repeat the steps (2) and (3).
 2. The time difference is stored when the time difference is being displayed, or the latitude and longitude are stored when the latitude and longitude are being displayed.
 3. The instant memory number starts at 90, which is increased to 91 and 92 at every storage. 99 is followed by 90, whereby the contents of previous 90 are lost.
 4. Repeating the step (2) only does not renew the instant memory number.
A renewal is made sequentially by repeating (2) and (3).

2.6.2 Recalling location stored in instant memory

a. Sequentially recalling instant memory numbers



b. Recalling designated instant memory number




2.7 Storing and Recalling Location or Waypoints


A desired location can be stored, and the stored location can be recalled. Up to eighty-nine destinations or other locations can be stored.

NOTE: The stored 89 locations are retained in memory even when the power is turned off.


2.7.1 Storing location



a. Storing in terms of time difference








b. Storing in terms of latitude and longitude






2.7.2 Recalling stored location



- (1) Press  key to move the mark 2 to WP.
- (2) Press  key.
- (3) Press two numeric keys to set a memory number (01 - 89) to be recalled.
The memory mark is displayed.
To recall another memory number successively, repeat setting of the memory number.



- (4) Press  key to move the mark 1 to LOP or L/L. Then the usual navigation display is resumed.




a. Using recalled location as destination waypoint

Press  key to move the mark 2 to WP.



b. Transferring a recalled location into another memory number

Press  key to move the mark 2 to WP.






2.8 Setting Waypoint

A destination is set for navigation display. Either a desired waypoint is set, or a stored location is recalled and set.


2.8.1 Setting waypoint of desired location

a. Direct entry of LOP Waypoint







b. Direct entry of Latitude/Longitude Waypoint





NOTE: LATITUDE IS DESIGNATED 1/N NORTH OF THE EQUATOR, 2/S SOUTH OF THE EQUATOR. LONGITUDE IS DESIGNATED 3/E EAST FOR ALL LONGITUDE 0-180 DEGREES EAST OF GREENWICH, ENGLAND, AND 4/W WEST FOR ALL LONGITUDE 0-180 DEGREES WEST OF GREENWICH, ENGLAND.





c. Clearing waypoint setting


Pressing the **CLR** key after the steps (1) and (2) above clears the waypoint and indicates all 0's on the display.



2.8.2 Enter Waypoints stored in instant memory


- (1) Press  key to move the mark 2 to WP.
- (2) Press  key.
- (3) Press the numeric keys (0 - 9) to set a memory number (91 - 99) to be recalled. The memory mark is displayed.



- (4) Press  key. The memory mark goes off. The mark and memory mark of the waypoint are displayed.

- (5) Press the  key to move the mark 1 to LOP or L/L position.


- (6) Press  or  key to select the navigation display to be used.



Steering and Distance
are selected.

2.8.3 Setting of two or more waypoints


Up to 10 waypoints can be preset. If two or more points are preset, changeover from one waypoint to another is automatically accomplished, and the total navigation distance to the final waypoint can be displayed.



Note: 1. In case a wrong key is pressed, press the correct number immediately after the wrong one.


"MEMO" indicator bar blinks.

Memory number




Set the mark 1 in the <LOP> or <L/L> position, and then the mark 2 in the <WP> position

- (5) Verify the displayed position and memory number of waypoint and press the **ENT** key. The "MEMO" indicator mark is turned OFF, and the WP indicator bar blinks periodically.





Note: 2. If depression of a wrong key is detected after pressing the **ENT** key, press the **CLR** key and repeat the subsequent steps again.




- (6) Set the second and third waypoints by going through the steps (3), (4) and (5). Up to 10 waypoints can be set.


Note: 3. The memory number and position of the waypoint set first are displayed when the **ENT** key is pressed.

When the vessel arrives at the each waypoint, the WP number will advance to the next waypoint number.







(7) Press  key to shift the mark 2 to a position other than WP. Setting of waypoints is completed by this step.








a. To clear display of waypoint settings

The display can be cleared of the waypoint settings by pressing the  key after going through the steps (1) and (2).




b. To determine total distance to final waypoint

After entering a sequence of waypoints, perform the following:


- 
- (8) Press  key to move the mark 1 to LOP or L/L.
- (9) Press  key to set the mark 3 to the DIST position.
If the mark 3 is not blinking, the distance from the current position to the current waypoint is displayed.
- (10) When the  key is pressed, the navigation distance from the current position to the final waypoint is displayed.
- (11) The data displayed at (9) can be recovered by pressing the  key again.

(Distance to current waypoint <01>)

(Distance to final waypoint <07>)




Mark 3 lights up
3.7 miles (NM)
Current waypoint




Mark 3 blinks
156.7 miles (NM)

c. To determine navigation time needed to reach final waypoint.

After entering a sequence of waypoints, perform the following:




(Navigation time needed to reach current waypoint <01>)



Mark 3 lights up.
Navigation time needed
(hours : minutes)

(Navigation time needed to reach final waypoint <07>)



Mark 3 blinks
Navigation time needed
(hours : minutes)


Notes: 4. As shown in these examples, 99:99 is displayed while the vessel is stopped.

5. Upon the lapse of approximately 4 minutes after the vessel starts moving again, the navigation time (TTG) will be displayed.


d. Actions after waypoint setting

After the vessel approaches a waypoint, changeover from that waypoint to the next one is automatically made. That change over is made, the moment the vessel gets to a point 0.1 mile inside the arrival alarm line. If the course is to be changed before arrival at the waypoint changeover point, follow the procedure described below to change the next waypoint manually.

Notes: 6. Automatic changeover is not effected while the mark 1 is blinking. In that case, follow the procedure described below to change over to the next waypoint manually.



e. To change over to next waypoint manually





2.8.4 Waypoint arrival alarm (intermittent sound)

When the waypoint gets near, an intermittent pip-pip sound is emitted, thereby notifying the vessel is arriving at the waypoint. The alarm sounds when the predetermined waypoint arrival alarm range is reached but the mark 1 does not blink.

a. Setting alarm range

Notes: 1. The settable range is 0.1 - 9.9 nautical miles.
When 0.0 nautical mile is set, the waypoint arrival alarm does not work.
Performing "2.1 Initial setting" sets 0.5 nautical mile.



b. Automatic changeover of alarm range and waypoint

When several waypoints are set, the waypoint is automatically changed over to the next at a location of 0.1 nautical miles inside of the limit of arrival alarm.

c. Stopping audible alarm

Pressing the **CLR** key stops the audible alarm.

NOTE: THE AUDIBLE ALARM WILL SOUND AGAIN AFTER LEAVING AND RE-ENTERING THE PRESET RANGE.

2.8.5 Anchor watch alarm (intermittent sound)


When the vessel leaves an anchor site and goes beyond the predetermined anchor watch alarm range, and provided the mark 1 is not blinking, an intermittent audible alarm will sound.

a. Setting alarm range


Notes: 1. The settable range is 0.1 - 9.9 nautical miles.

2. When 0.0 nautical mile is set, the anchor watch alarm does not work.

3. Performing "2.1 Initial setting" sets 5.0 nautical miles.




Develope <02>



b. Setting anchorage site

The following operation sets the current location as an anchorage point and initiates the alarm function.

Notes: 4. Setting an anchorage point deletes the already set destination.



c. Stopping audible alarm

Pressing the **CLR** key stops the audible alarm.

Re-entering the alarm range automatically stops the audible alarm.

d. Clearing anchor watch alarm

It is necessary to set a different waypoint to deactivate and totally clear the Anchor Watch alarm.

2.9 Navigation Display



The Loran displays the navigating information: Cross Track Error, Distance, Speed, Heading, Steer to Go, Time to Go, Timer and Route.

In order to display the navigating information except the vessel speed and heading, a waypoint must be set beforehand. (See 2.8 "Setting Waypoint".)


2.9.1 Displaying cross track error

The deviation of the actual vessel course with respect to a straight course to the waypoint is called Cross Track Error (XTE).

Note: The display range of cross track error is 0.01 - 9.9 nautical miles.



- a. How to interpret XTE cross track error display.



Perform steering slowly so the cross track error is reduced.

Notes: 1. The cross track error is displayed (a) in one hundredth nautical mile steps when its alarm range is set to below one nautical mile, or (b) in one tenth nautical mile steps when alarm range is one nautical mile or more.

2. The start point of course is the position where the waypoint is set or changed over.
3. The current location can be set as a new start point (new point of origin). Move mark 2 to WP and press **[1/N]** **[ENT]** keys.

The cross track error will be reset to 00 and the new course to steer is computed.


4. When the course deviation is displayed in one hundredth nautical mile steps, a deviation of 0.99 nautical mile or more, if any, gives a display of "99". In case of one tenth nautical mile steps, a cross track error of 9.9 nautical miles or more, if any, gives a display of "9.9".
5. When the anchor watch alarm function is valid, the cross track error is not displayed and remains blank.
6. In addition, there is an off course alarm function which sounds an audible alarm if the cross track error becomes excessive. This function is valid even in an operation mode where off course is not displayed.

2.9.2 Cross track error alarm (continuous sound)

A continuous sound is emitted as soon as the cross track error is beyond the predetermined off course alarm range.

a. Setting alarm range

- Notes:
1. The settable range is 0.1 - 9.8 nautical miles.
 2. Setting 0.0 or 9.9 nautical miles invalidates the cross track error.
 3. Executing "2.1 Initial setting" sets 5.0 nautical miles automatically.
 4. The cross track error is displayed in one hundredth nautical mile steps when the setting is below one nautical mile, or in one tenth nautical mile steps when one nautical mile or more.





b. Stopping audible alarm

Pressing the key stops the audible alarm.

2.9.3 Indicating distance to go


The great circle route (0.01 - 999.9 nautical miles) from the current location to the waypoint is displayed.




Notes: 1. When the distance is below 0.1 nautical mile, two digits below decimal point are displayed.
0.01 nautical mile is displayed as 0:01.

2.9.4 Display of vessel speed and repeated setting of average vessel speed.

The current vessel speed (0.1 knot steps) with respect to land is displayed.






Note : 1. When the speed is below one knot, 00.0 is displayed as illustrated above.


a. Repeated setting of average speed

When the speed display fluctuates excessively while the vessel is navigating at a constant speed, the fluctuating display can be decreased to an approximate speed.



(3) Set a number (1 digit) greater than 2 by numeric keys (3 - 5).



Note: 2. When the speed response is expected to be faster, set a number smaller than 2 by the numeric key 1. 1 through 5 are average constants.



Note: 3. Carrying out "2.1 Initial setting" sets a constant 2 automatically.

2.9.5 Display and correction of heading

The vessels forward 'HEADING' direction is displayed in the true bearing (0.1 degree steps).




a. Correcting heading




The displayed heading can be corrected to match with the compass when the heading on the navigation display differs from the heading indicated by a gyro or magnetic compass.

Notes: 1. Carry out this correction when the heading display is stable during navigation.

2. The correctable range is ± 0.1 to $\pm 30^\circ$.




- (3) Press the numeric keys (0 - 9) to set the correction amount (0.1 deg steps).
- (4) Press **+/-M** key when the correction amount is positive, or **-/R** key when negative.
- (5) After making sure of the correction amount indicated on the display, press the **ENT** key.
- (6) In about ten seconds, the corrected heading is indicated on the right of the navigation display.



b. Display after correcting heading


LOP Displays

Point goes off about every twelve seconds.







Latitude/Longitude Displays

Point (.) goes on about every twelve seconds.



c. Clearing heading correction






Note: The correction is also cleared by "2.1 Initial setting".


2.9.6 Display of route

When several waypoints are set, the distance and required time to the final waypoints are displayed. For the display procedure, refer to "2.8.2 Setting of two or more waypoints."

2.9.7 Display of steer to go

The direction to the waypoint is indicated in the angle with respect to north (either true or magnetic).




- 
- (1) Press  key to move the mark 1 to LOP or L/L.
 - (2) Press  key to move the mark 2 to STG.
- The steer to go with respect to true north is displayed. Magnetic correction can be applied. See 2.9.5a.




2.9.8 Display of time to go


Estimated time to go to the waypoint is displayed.

Note: When the speed display is unstable, a correct time to go is not displayed.

- 
- (1) Press  key to move the mark 1 to LOP or L/L.
 - (2) Press  key to move the mark 3 to TTG.
- The time to go to the next waypoint is displayed when the mark 3 is not blinking, or to the final waypoint when blinking.




- (3) Pressing **1/N** key displays the time to go to the final or next way-point alternately.



a. How to interpret display

While mooring 99:99 is displayed as shown below.


While navigating ... hours and minutes are displayed at the positions illustrated below.




2.9.9 Display of timer

The time elapsed since turning on power or from manual reset is displayed. The time can be set by numeric keys (0 - 9).

- (1) Press key to move the mark 1 to LOP or L/L.
- (2) Press key to move the mark 3 to V/CMG.
- At the position illustrated, the time elapsing since turning on the power or from a resulting is displayed.






- (4) In this mode, it shows TIME in S2 display area, and velocity and heading in CPN display area. Using the numeric keyboard to enter six digits--two for days, two for hours in 24-hour format, and two for minutes, followed by pressing ENT key sets the TIME function.

2.9.10 Display of imaginary course distance and bearing


An imaginary course interconnecting two stored points with a straight line is set, and the great circle distance and bearing of that course are displayed.

Note: The distance range which can be displayed is 0.1 - 999.9 nautical miles.





- (4) Press the numeric keys (0 - 9) to set the memory number (01 - 99) of an end point.

The location and memory number of the end point are displayed, and the memory mark blinks.



- (5) Press the **ENT** key.
The distance and bearing from the start point to end point are displayed.



Start point <05>



Imaginary course

End point <06>





2.10 Converting from Time Difference to Latitude/Longitude

To convert a time difference (TD) into Latitude/Longitude (L/L).

a. Converting time difference in same chain by numeric keys




b. Converting time difference stored memory



c. Converting time difference of other Loran C chain

Note: Altering the GRI does not affect Loran signal tracking.




(5) Enter the TD's to be converted by using the keyboard, or by recalling the TD's from memory.

(6) Press the **CLR** key.
To pursue the operation, press the **CLR** key, and repeat the procedure.

d. Storing converted latitude/longitude

Following the steps in a, b or c above, carry out the steps below.




Latitude/Longitude Conversion Table


<u>GRI Number</u>	<u>GRI Designation</u>
4990	CENTRAL PACIFIC
5930	CANADIAN EAST COAST
5970	COMMANDO LION
5990	CANADIAN WEST COAST
7170	SOUTH SAUDI ARABIA
7230	LABRADOR SEA
7960	GULF OF ALASKA
7970	NORWEGIAN SEA
7980	SOUTHEAST U.S.
7990	MEDITERRANEAN SEA
8290	NORTH CENTRAL U.S.
8970	GREAT LAKES
8990	NORTH SAUDI ARABIA
9610	SOUTH CENTRAL U.S.
9940	U.S. WEST COAST
9960	NORTHEAST U.S.
9970	NORTHWEST U.S.
9980	NORTH ATLANTIC
9990	NORTH PACIFIC

2.11 Displaying Signal Status and Frequency Deviation

The status of Loran C signal while acquiring and tracking and oscillator frequency deviation can be monitored.



a. How to read display



Allowable range of frequency deviation is -20 to +20.

Display of +20:


Display of 0 : or

Display of -20:


2.12 Displaying Error Signal

A display appears on the Loran when an error signal is sent from a transmitting station (master station or secondary station 1 or 2).


a. How to read display



b. Clearing error signal display



The station blink is usually transmitted to indicate that the Loran C station is not operating properly. Select a different station or, if necessary, a different chain.




2.13 Selecting Connected Devices

There are five types of output data for LR-791. Each is selectable according to the particular connected device.


OUTPUT FORMAT	DATA NUMBER	DEVICE NAME
KODEN-717	1	KODEN-717 COMPATIBLE DEVICE, UR-7
NMEA-0182	2	NMEA-0182 COMPATIBLE DEVICE, UR-7
NMEA-0183(LOP) SELECTED DATA	9	NMEA-0183 COMPATIBLE DEVICE
NMEA-0180	8	AUTOPILOT (NMEA-0180 TYPE)
NMEA-0183 (L/L)	3	NMEA-0183 COMPATIBLE DEVICE

a. Checking output format



b. Changing number for data output format

- (3) Press a numeric key(1, 2, 3, 8, 9)to set a new data number (1 digit).



- (4) After making sure of the displayed data number, press the **ENT** key.

Note: The data number is not changed by "2.1 Initial setting".

3. MAINTENANCE


3.1 Replacing Fuse


Major circuits are protected by a fuse. If they are faulty, the fuse will blow.

a. Precautions

- (1) If the fuse has blown, locate its cause, repair it and then replace the fuse.
- (2) Turn off power and then replace with a new rated fuse.

b. How to replace

- (1) Press the  Key to turn off power.
- (2) Locate the fuse holder on the back panel. Remove the fuse holder by turning it in a counter-clockwise fashion.
- (3) Replace the blown fuse with same value replacement fuse (1 Amp, 125 Volt).



Rear panel

3.2 When Trouble is Suspected

- a. All displayed digits are 7's when a lat/lon display is expected.

The secondary station selection has not been completed. Return the mark 1 to GRI mode position, press **S1** or **S2** key, select the secondary stations 1 and 2, and perform a fixed display. Then select L/L mode. The latitude and longitude of the current location will be displayed.

NOTE: IN AN AREA HAVING ONLY TWO SECONDARY STATIONS, FIXING ON STATION 1 AUTOMATICALLY FIXES ON STATION 2.

- B. All displayed digits are 9's.

When the chain is not set, 9's are displayed for all digits. In such a case, pressing the **CLR** key does not change the display. Return the mark 1 to GRI mode and key in the correct four-digit GRI chain code.

- c. Display is frozen.

A frozen display may result from any or all of the following:

- (1) Excessive RF noise from external causes
- (2) Signal is lost (Loran signal is not transmitted)
- (3) Operation mode is incorrect (example: WP).

- d. CS alarm and S/N alarm is displayed at all times

CS alarm and/or S/N alarm is displayed because of one of the following external factors:

- (1) Signal is lost
- (2) Interfering RF noise (AC, electric motor, TV, etc.)
- (3) Antenna or receiver grounding is poor
- (4) Noise from other wireless equipment has invaded power line
- (5) Poor installation of antenna

e. Displayed cross track error is erroneous

When Loran position measurement is working properly, no internal error of cross track error is conceivable usually. Therefore, one of the causes enumerated below may cause this kind of trouble.

- (1) Antenna or receiver ground is poor
- (2) Interfering radio wave noise or alternator/generator noise.
- (3) Poor handling of cross track error function
- (4) Comparison difference between cross track error information and visual criterion
- (5) Comparison difference between cross track error information and compass
- (6) Keying error for waypoint
- (7) Lines of position (LOP) are widely spaced, or lines of position are intersected at small angle

NOTE: DO NOT USE THE CROSS TRACK ERROR WHEN THE LORAN UNIT IS NOT OPERATING PROPERLY.

f. Displayed speed or heading is erroneous

The displayed speed or heading does not quickly respond to an abrupt change of the vessel speed or heading. Therefore, it may differ from reading on the speedometer or compass.

Note that the speed and heading display tends to be affected by:

- (1) Dispersion or intersection angle of lines of position
- (2) Poor Ground
- (3) Improper mounted position of antenna
- (4) Poor setting of averaging speed in SET mode (average setting increases as vessel speed increases)
- (5) Interfering radio wave noise
- (6) Unstable route variation

g. Time difference display is faulty

The time difference display becomes faulty as a result of:

- (1) Poor ground
- (2) Interfering radio wave noise
- (3) Improper mounted position of antenna
- (4) Correction not cleared
- (5) Wrong operation mode

h. Latitude/longitude display is erroneous

The latitude and longitude are computed from the time difference. Therefore, a faulty display may be attributed to:

- (1) Correction of position is not cleared
- (2) Position is corrected by secondary propagation correction
- (3) Selection of normal or special operation range for conversion of time difference to latitude/longitude is wrong.
- (4) Secondary station is not selected properly

i. Power cannot be turned on

- (1) Poor connection of power cable
- (2) Fuse has blown out.

If neither of the two points above is the cause, contact the nearest agent.

4. EQUIPMENT INSTALLATION

4.1 Locations of Antenna and Its Coupler

Install the antenna and its coupler at a highest position on the vessel. Even if it has inevitably to be installed at a low position, do not mount them under or inside a place where metals are collected. A metallic object which intervenes between the transmitting station and antenna might not allow a reception even within the service area.

- (1) As an installation site, select a place free from any metallic objects.
- (2) Install the antenna coupler at least one meter away from the receiver or remote display.
- (3) A correct installing location for the antenna and coupler is as follows according to different types of vessels.

On a yacht, an insulated aft stay is usable as an antenna.

In case of central cabin vessel, perform an installation on a side or top of the cabin.


On a motor boat, install the equipment on a bridge passage, on the top or side of the cabin.

- (4) Select a place where the antenna can be mounted vertical.
- (5) Install the Loran receiver antenna as far away from other antennas, particularly transmitting antennas of intermediate or high frequency as possible.
- (6) To select an optimum antenna mounting position, change the locations to test the signal conditions. (See "2.11 Displaying signal status and frequency deviations".)
- (7) Keep away from TV set and receiving antenna. While using Loran receiver, do not turn on a TV set.

4.1.1 Reference diagrams for receiving antenna mounting position


a. For small vessel

Select an optimum location from A, B and C below.




- (1) Location C (above radar mast)
A short receiving cable suffices.
The installation is available at an elevated place.
- (2) Location A (on mast)
Installation is possible at an elevated position, but the receiving cable length may fall short.
- (3) Location B (bridge)
A short receiving cable suffices.
However, installation at an elevated place is impossible.

b. For medium to large sized fishing boats



Good example for medium to large sized fishing boats (1)


- (1) Location (A)
Mount the antenna at least one meter above the yard and as away from the transmitting antenna as possible.
- (2) Location (B)
Mount the antenna on the end of the bridge and as away from the transmitting antenna as possible. Mount the antenna coupler so the horizontal antenna element will be positioned below the middle of the whip antenna.
- (3) Location (C)
Tilt the antenna outward at least two meters away from the loop antenna. Even this may slightly affect the bearing measurement.



Good example for medium to large sized fishing boats (2)


- (1) Locations (A) and (B)
Mount on the bridge end as far away from the transmitting antenna as possible.
- (2) Location (C)
Mount at least one meter above the yard and as far away from the transmitting antenna as possible. Tilt outward at least two meters away from the loop antenna. Even this may slightly affect the bearing measurement.
- (3) Location (D)
Mount at least one meter above the yard and away from the transmitting antenna as possible.

If no location is available matching the above conditions and when the operation is made only on the sea area where Loran C signal is intense enough, refer to the following.



No good example for medium to large sized fishing boats (1)

- (1) Location (A)
Absolutely avoid a place immediately below the transmitting antenna.
- (2) Locations (B)' and (C)'
Separate as far away from the transmitting antenna. Mount the receiving antenna so its top end is located above the transmitting antenna. Separate as far away from the radar mast and other obstacles as possible.
- (3) Location (D)'
Absolutely avoid a place surrounded by obstacles.




No good example for medium to large sized fishing boats (2)

- (1) Locations (A)' and (B)'
Separate as far away from the transmitting antenna as possible, and mount the receiving antenna so its top end is located above the transmitting antenna. Separate as far away from the radar mast and other obstacles.

- (2) Location (C)'
Absolutely avoid a place immediately below the transmitting antenna.

4.2 Typical Installation of Receiving Antenna



4.3 Power Supply and RF Ground

4.3.1 Source voltage

The employed voltage range is 11 - 15 VDC. Within this voltage range, a connection is available as it is without modification or readjustment.


A battery or power supply capable of supplying 11 - 28 VDC, 1.0 amperes is required.

Since the power consumption is low, the power capacity need not be considered too strictly.

4.3.2 Connecting power

Before connecting power to the receiver, check the power voltage and polarities.

As shown in Figure 2.6, connect the positive side to the power connector pin 1, and negative side to the pin 2.





WARNING

- Notes:
1. If the polarity is reversed, the receiver might be destroyed. Damage caused by a reversed polarity is excluded from the warranty clause.
 2. Do not use external switch or circuit breaker as a power switch for Loran navigator.
 3. Before connecting power to the receiving indicator, connect between the negative side of power supply and ground a circuit tester set at DC range, and make sure the reading is 0 V. Otherwise, change the power connection to obtain 0 V.
 4. If the same power source is used for another electrical appliance, turning it on or off may generate a voltage. Make sure 0 V remains unchanged even after turning on the other appliance.
 5. On the Loran C navigator, the negative side of power circuit is isolated from the ground terminal of the case.


4.3.3 RF ground

In order that Loran receiver operates properly, correct RF ground is required. If the grounding status is wrong, an erratic or no operation might occur.


The equipment conditions differs from one vessel to another. In case of an engine ship, extend the ground wire direct to the engine block or engine outer case.



4.4 External Dimensions



Dimensions are in millimeters.
To convert to inches, divide
mm by 25.4



CERTIFICATE OF LIMITED WARRANTY

Providing you present a valid proof of purchase, SI-TEX Marine Electronics Inc. warrants all parts of each new product against defect in material and workmanship under normal use and will repair or exchange any parts proven to be defective at no charge for a period of two years for parts and one year for labor from the date of purchase, except as provided below under Limited Warranty Exceptions.

Defects will be corrected during normal working hours by an authorized SI-TEX Marine Electronics Inc. dealer, service center, or at the SI-TEX office in St. Petersburg, Florida. There will be no charge for labor for a period of one year from the date of purchase, except as provided below under Limited Warranty Exceptions.

This Warranty and Proof of Purchase must be made available to the authorized SI-TEX Marine Electronics Inc. service location or dealer at the time of service.

LIMITED WARRANTY EXCEPTIONS

SI-TEX Marine Electronics Inc. will not be responsible for equipment which has been subjected to water or lightning damage, accident, abuse, or misuse nor any equipment on which the serial number label has been removed, altered or mutilated.

SI-TEX Marine Electronics Inc. assumes no responsibility for damage incurred during installation.

This Limited Warranty is effective only with respect to the original purchaser.

Any cost associated with transducer replacement, other than the cost of the transducer itself, is specifically excluded from this Limited Warranty.

Travel cost incurred will not be accepted for SI-TEX Marine Electronics Inc. products.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE FACE HEREOF.

SPECIFIC EXCLUSIONS

Charges for overtime, stand-by, holiday, and per diem are specifically excluded from the Limited Warranty.

Chart paper, stylus, stylus belt, lamps, and fuses are consumable items and are not covered by this Limited Warranty.

Installation workmanship or materials except as provided directly by SI-TEX Marine Electronics Inc. are not covered by this Limited Warranty.

SI-TEX Marine Electronics Inc. equipment or parts thereof which have been repaired or altered except by an authorized SI-TEX Marine Electronics Inc. dealer or service center are not warranted in any respect.

Transducer, software update, battery, microphone, magnetron, and microwave components and water damage on water resistant VHF radio are items excluded from the two-year warranty and are covered by warranty for a period of one year for both parts and labor.

SI-TEX Marine Electronics Inc. will not, at any time, assume any costs or labor charges for checkout or external line fuse replacement or problems not found to be at fault in equipment itself.

THERE ARE NO WARRANTIES OR GUARANTEES EXPRESSED OR IMPLIED WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY. SI-TEX MARINE ELECTRONICS INC. HAS NO OTHER LIABILITY TO PURCHASE FOR DIRECT OR CONSEQUENTIAL DAMAGE OR ANY THEORY INCLUDING ABSOLUTE LIABILITY, TORT, OR CONTRACT. THIS LIMITED WARRANTY CANNOT BE ALTERED OR MODIFIED IN ANY WAY AND SHALL BE INTERPRETED IN ACCORDANCE WITH THE LAWS OF THE STATE OF FLORIDA. THIS WARRANTY IS LIMITED TO THE CONTINENTAL U.S.A., ALASKA, HAWAII, AND CANADA.

HOW TO OBTAIN SERVICE UNDER THIS WARRANTY

To provide better flexibility, SI-TEX Marine Electronics Inc. gives you the option of obtaining service under this warranty by either:

- a) Contacting an authorized SI-TEX Marine Electronics Inc. service station (The closest service station may be found by contacting your dealer of purchase.)
or
- b) Shipping your equipment prepaid via UPS or truck with insurance prepaid to SI-TEX Marine Electronics Inc. at the address provided below. SI-TEX Marine Electronics Inc. will, whenever possible, make all repairs covered by Limited Warranty within two weeks of receiving the equipment in Florida and return same to you, freight prepaid.
- c) You must present a copy of your Purchase Sales Slip at the time you request warranty service.

Shipping/Mailing Address:

SI-TEX Marine Electronics Inc.
11001 Roosevelt Blvd., Suite 800
St. Petersburg, FL 33716
727-576-5734

SI-TEX Marine Electronics Inc. offers a complete line of quality marine electronics including fishfinders, electronic charting systems, radars, autopilots, GPS/WAAS/Loran receivers, SSB receivers, direction finders, VHF radios, VHF marine & TV antennas, and integrated systems.

For more information, contact your SI-TEX dealer or the main office, located in St. Petersburg, Florida.

4.5 Connecting Antenna Coupler

