

# LORAN C NAVIGATOR

XJ-9

# OPERATION MANUAL

**SITEX** ®

DOC NO. XJ-9 10-94

---

# For Proper Operation

## Tips for mounting the navigator

Avoid following locations or situations:

- A place exposed to direct sun or near a heating device.
- A place adjacent to Magnetic Compass.
- A place exposed to strong vibration or shock.

### Special note for LCD (Liquid Crystal Display)

Avoid following conditions to insure good LCD visibility.

- Long-time exposure to direct sun rays or UV.
- Extremely hot (surrounding temperature more than 50°C, 120°F) or cold (less than 0°C, 32°F) environment.

# Welcome to Loran C navigator

The Loran C navigator receives signals from a master station and 2 secondary stations in a Loran C chain to show your position either in LOP or LAT/LONG in the chain coverage. An additional GPS receiver module makes the navigator a combination system of Loran C and GPS and you can enjoy the benefits of both navigational systems.

Please read this manual carefully before turning the power on, as you will find important information on navigating with your navigator.

## IMPORTANT

This device is an aid to navigation.

When in actual use, carefully compare data of your GPS navigator with all available navigation sources such as Loran C, Decca, other navigators, charts, visual navigation, depth, water temperature, etc., for good navigation judgment.


Navigation judgment is your responsibility.

## Table of Contents

For Proper Operation .....	1
Tips for mounting the navigator .....	i
Display Unit .....	3
Getting Started .....	4
Entering Loran C chain number and secondary stations .....	4
When center two digits (L/L or LOP) are blinking (blink alarm) .....	5
When right most digits (L/L or LOP) are blinking (CS and S/N alarm) .....	5
Switching screens .....	6
Operation of NAV1 screen .....	6
How to Find Out Your Position .....	7
Storing present position (EVENT) .....	7
Recalling event or MOB position .....	7
MOB (Man Over Board) function .....	8
Average speed/course/elapsed time .....	8
How to Get Distance and Bearing to WPT .....	9
Navigation to WPT .....	9
Storing waypoints (LAT/LONG or LOPs data) .....	10
Storing a new position .....	10
Copying between memory areas .....	12
Changing a comment of storage data .....	12
Changing position data .....	13
Storing navigation route .....	14
Erasing a single point of position data .....	14
Erasing a single route of data .....	15
Erasing entire data from memory .....	15
Setup of Waypoints .....	16
Setting waypoint navigation .....	16
Recalling a waypoint .....	16
Reentering the origin of waypoint navigation .....	17
NAV1 screen during waypoint navigation .....	17
NAV2 screen during waypoint navigation .....	17
Canceling waypoint navigation .....	17
Cross track error and course deviation angle .....	18
Route Setup .....	19
Selecting route navigation .....	19
Checking a route position or a route point position .....	20
Skipping an in route point during route navigation .....	20
Switching between distance to WPT and total distance .....	21
Switching between time to go and total time .....	21
NAV1 screen during route navigation .....	22
NAV2 screen during route navigation .....	22
Canceling the route navigation .....	22
Alarms .....	23
Setting and Disabling an Anchor Watch Alarm .....	24
What is an anchor watch alarm? .....	24
Setting an anchor watch alarm range .....	24
Setting the anchor watch alarm .....	24
Disabling the anchor watch alarm .....	24


Setting and Disabling a Proximity Alarm .....	25
What is a proximity alarm? .....	25
Setting a proximity alarm range .....	25
Disabling the proximity alarm .....	25
Setting and Disabling an XTE Alarm .....	26
What is an XTE alarm (course deviation)? .....	26
Setting an XTE alarm range .....	26
Disabling the XTE alarm .....	26
<b>Setup Procedure</b> .....	27
Menu options .....	27
Selecting a Menu option .....	27
Displaying position data in LAT/LONG mode .....	28
Displaying position data in Loran C LOP mode .....	28
Entering Loran C chain number and secondary stations .....	28
Display LOPs of different chain .....	29
Monitoring Loran C signal reception .....	29
Changing the distance or speed unit .....	29
Correcting your position .....	30
LOP correction by 10 $\mu$ sec steps .....	33
Restarting the navigator for acquisition and tracking .....	35
Incorrect LAT/LONG position despite good signal condition .....	35
Compensation of compass .....	36
Selecting and editing an output format .....	37
Setting average constants (measuring position, speed and course) .....	38
Calculating the distance and bearing between two points .....	38
Calculating Loran C LOPs based on LAT/LONG data .....	39
Calculating LAT/LONG based on Loran C LOPs data .....	40
Calculating Loran C LOPs in different chain based on LOPs in chain in use .....	41
<b>Operation as a GPS navigator</b> .....	42
How to change to GPS .....	42
Selecting GPS receiver module .....	42
Setting antenna height (above sea level) .....	42
Selecting a geodetic datum .....	43
Selecting a measuring system mode .....	43
Getting started (as a GPS navigator) .....	44
Monitoring GPS satellite signal reception .....	44
Adjusting LOPs from GPS position to Loran C LOPs .....	45
<b>Troubleshooting Guide</b> .....	46
Nothing appears when you press PWR/DIM key .....	46
No information appears on the screen (during initial setup) and language selection .....	46
Error message appears as you power on (Self-test function) .....	46
Nothing appears but buzzer sounds during power-on .....	47
Unstable signal reception : Loran C navigator .....	47
Unstable signal reception : GPS navigator .....	47
Checking frequency deviation of the crystal oscillator .....	47
<b>Specifications</b> .....	48
Major Specifications .....	48
Standard equipment list .....	49
Options .....	49
Latitude/longitude convertible chains .....	49
Outline and Dimensions .....	50
Interconnecting Diagram .....	51
<b>Installing (Loran C navigator)</b> .....	52
Positions of antenna and its coupler .....	52
Reference diagrams .....	52
Cable connections .....	53
RF ground .....	53
Antenna installation .....	54
<b>Installing (GPS navigator)</b> .....	55
Installation site .....	55
Cable connections .....	56
Antenna installation .....	56
<b>Appendix Local Geodetic systems</b> .....	57

# Display Unit



<b>Screen switching</b> 	Selects either NAV1, NAV2 or NAV3 screens.	<b>Emergency</b> 	Activates MOB (Man Over Board) function.
<b>Menu</b> 	Recalls the menu.	<b>Power/dimmer</b> 	Turns the power on and changes the brightness of the display (2 levels).
<b>Clear</b> 	Clears a numeric or optional parameter or stops alarm sound temporarily.	<b>Power-Off</b> 	Turns the power off.
<b>Entry</b> 	Enters a numeric or optional parameter.		Numeric keypads for recall of memory position, entry of numerical values, and selection of North or South latitude or East or West longitude.
<b>Event</b> 	Stores an event position		
<b>Contrast</b> 	Changes the LCD contrast in 8 levels.	<b>Cursor shift</b> 	Shifts the cursor in direction of the respective key on the screen when you select an option or enter a numeric value.
<b>Selection</b> 	Selects parameters.		

# Getting Started



On-screen messages change in the following sequence.

**PWR DIM** Press to turn NAVIGATOR on.

Dim/bright the display:

**PWR DIM** Press to dim/brighten the screen.

Change the contrast:

**CTRS** Press to change the LCD contrast (intensity) in 8 levels.

Power off:

**OFF** Press to turn NAVIGATOR off. All data before power-off is kept in memory for later use.

**What is failure of positioning?**

At least master and two secondary station signals should be received for positioning.

LORAN  
ROM No. KM-AD0  
checking

Initial message during power-on

LORAN  
ROM No. KM-AD0  
check OK

Message to indicate checking of Loran C receiver and display has been completed.

NAV1 . . .  
SPEED . kt  
COURSE . . .

Display with no chain data.

When the navigator is turned on for the first time, entry of chain number and two secondary stations is required (refer to "Selection of Loran C chain number and combination of secondary stations"). Normally chain data is retained in the memory for the next operation.

Blinking

NAV1 14248.8  
44713.8  
SPEED 15.0kt  
COURSE 359.9°

Display when Loran C signals are acquired and tracked.

During the process of receiving Loran C signals, the last digits of LOPs in LOP mode or N (or S) and E (or W) in L/L mode are kept blinking.

After reception of Loran C signals is completed, blink stops.


No blinking

NAV1 27°54.00N  
82°41.67W  
SPEED 15.0kt  
COURSE 359.9°

Loran C LOP

Latitude/  
longitude

## Entering Loran C chain number and secondary stations



Press to display Menu options 1 to 4.

Select 2:  
LORAN MON.

Press to move **←** cursor to the (4-digit) Loran C chain entry field.

Enter a (4-digit) Loran C chain number.

Enter the most significant digit (10 thousand microseconds) of two Loran C secondary stations.

Press until NAV1 screen appears.

Press to enter Loran C chain data.

**Correction of input error**

**←** **→** Locate **←** cursor onto incorrect number and enter correct one.

**CLR** Press to clear incorrect input. You can reenter numeric data.

MENU 1:WAYPOINT  
2:LORAN MON  
3:GPS MON  
4:COMP

2:LORAN 2980 1-4  
MASTER 068 0  
20071.5 059 0  
55747.3 078 0

Chain number      Most significant digit of two secondary stations

### When center two digits (L/L or LOP) are blinking (blink alarm)

This means a Loran C station or more than two stations in the chain are in trouble and the users are advised not to use the chain. False alarm is indicated seldom due to poor signal conditions.

#### Loran C LOP

NAV1	14248.8
	44713.8
SPEED	15.0kt
COURSE	359.9°

Blinks when secondary 1 station transmits blink signal.

Blinks when secondary 2 station transmits blink signal.

#### Latitude/longitude

NAV1	27°54.00N
	82°41.67W
SPEED	15.0kt
COURSE	359.9°

How to reset  
blink alarm

CLR

CLR key press stops blinking momentarily. But it will come back as long as blink alarm signal exists.

### When right most digits (L/L or LOP) are blinking (CS and S/N alarm)

If either one of the above fails, following alarm is indicated. The detailed status can be confirmed in a menu screen. Main cause of the alarm comes from out of coverage use, poor grounding of the unit, inappropriate antenna location, alternator noise and near band radio noise.

#### Loran C LOP

NAV1	14248.8
	44713.8
SPEED	15.0kt
COURSE	359.9°

Blinks when either one of master, secondary 1 or 2 signal becomes unstable.

#### Latitude/longitude

NAV1	27°54.00N
	82°41.67W
SPEED	15.0kt
COURSE	359.9°

How to reset S/N  
or CS alarm

CLR

CLR key press stops blinking but it will come back as long as unstable signal exists. Detail of trouble can be monitored in a menu screen.

### How to find out Loran C signal with trouble

MENU ⇒ 2/N

Select 2: LORAN MON.

Press to display Menu options 1 to 4.

MENU 1: WAYPOINT
2: LORAN MON
3: GPS MON
4: COMP

Proper cycle selection (cs) is not made for master signal

2: LORAN 7980 1-4	
MASTER 001	X
14248.8 059	O
44713.8 078	O

Proper cycle selection (cs) is not made for secondary 1 signal

2: LORAN 7980 1-4	
MASTER 068	O
14248.8 001	X
44713.8 078	O



Proper cycle selection (cs) is not made for secondary 2 signal

2: LORAN 7980 1-4	
MASTER 068	O
14248.8 059	O
44713.8 001	X

If signal strength is too low, number becomes 0 and it initiates the alarm (S/N alarm)




When cycle selection is not made it initiates the alarm (cs alarm)

## Switching screens



## Operation of NAV1 screen

Data on line 3 and 4 are independently selectable.



# How to Find Out Your Position

You can find your position by simply reading the NAV1 display either in LAT/LONG or LOPs.

**MODE** Press this key to recall NAV1 (Navigation 1) screen.

## NAV 1 screen

NAV1	14248.8	8
	44713.8	8
SPEED	15.0	kt
COURSE	359.9	°

Blinks if positioning is interrupted.

Present position  
Secondary 1 station LOP  
Secondary 2 station LOP  
Speed in knots  
Bearing in degrees

Blinks when compensation to position or bearing is imposed.

NAV1	27°54.00	N
	82°41.67	W
SPEED	15.0	kt
COURSE	359.9	°

Blinks if positioning is interrupted.

Present position  
North or South latitude  
East or West longitude  
Speed in knots  
Bearing in degrees

## Storing present position (EVENT)

You can store up to 10 points (point number 01 to 10) in memory. When you store more points, old ones are overwritten. Use memory data when you check the pass through points (tidal hours and fishing areas). Also use it to determine the waypoint or pass through points of your route.


I'm storing present position...

Present position

Track

**EVT**

**CLR** Returns to previous display screen.



Press this key to store the present position. You can store up to 10 points, and then the oldest data will be replaced with a new one in numerical order.

**EVT** key precedes any other key on any screen except Menu. You can also store the present position (memory number 00) using **MOB** key.

Latest event point number is shown.

The position data of event point number 01.

EVT	14248.8
	44713.8
01	14249.9
	44713.3

When you press **MOB** key, your present position is stored in memory number 00.

## Recalling event or MOB position

MENU → 1 → [ ] [ ]

Enter an event number (one of point number 00 to 10) you wish to recall. Point number 00 contains the position data when you have pressed **MOB** key.

Select 1: WAYPOINT.

Press to display Menu options 1 to 4.

Specified event point number is shown.

Event or MOB position recalled.

WPT	01 =
	14249.9
	44713.3

**CLR** Use this key if you have entered an incorrect number. You can reenter an event point number.

## MOB (Man Over Board) function

MOB function is provided for an emergency situation to make it easier to return to MOB point.

Caution: MOB key does not function if positioning is not available.

**MOB** Press to store present position and to select the MOB (Emergency Navigation) screen.

MOB mode has been selected.

	<b>MOB</b>	<b>14248.8</b>	Present position
		<b>44713.8</b>	
Distance from present position to the point where you pressed MOB key	<b>2.7</b>	<b>14249.9</b>	Point where you pressed MOB key
Bearing from present position to the point where you pressed MOB key	<b>270°</b>	<b>44713.3</b>	

**CLR** Clears the MOB mode and returns to the previous screen.

You can use only the following four keys in MOB mode.

**CLR** **CTRS** **PWR DIM** **OFF**

## Average speed/course/elapsed time

**MODE**

**CLR**

Press to reset the elapsed time.


Press until NAV3 screen appears.

When you turn the power switch on, the average speed and average bearing since time reset are shown and (they are updated every one minute)

Press CLR key to reset the elapsed time. The average speed is an average of ship's speed from the origin (that is, the point where you have reset the elapsed time) to the present position. The average bearing is an average of true bearing from origin to present position.

Elapsed time  
Velocity made good  
Course made good

<b>NAV3</b>	
<b>TIME</b>	<b>:05h59m</b>
<b>VMG</b>	<b>:15.0kt</b>
<b>CMG</b>	<b>:100.0°</b>



This display is also available during both WPT and route navigation.

**VMG (Velocity made good):** VMG is velocity in the direction of the desired course. It is the speed at which you are closing on the "active to" waypoint.



**CMG (Course made good):** CMG is the bearing from the "active from" waypoint to your position.

# How to Get Distance and Bearing to WPT

You can obtain the following navigation information to destination (waypoint WPT):

- Distance and bearing from present position to a WPT or the final destination
- Ship's speed and time to go

You can store up to 89 points (numbers 11 to 99).



## Navigation to WPT

Use the following steps (see Page 11 for operation details).

1. Determine your waypoints and/or final destination by sea charts or other sources.
2. Store position data of waypoints.
3. Create a new route combining stored data and new input data.
4. Check the waypoints on the store screen and correct them if necessary.
5. Start navigation.

## Waypoint navigation

"Prepare sailing.  
Power On! Everything OK!"

See Page 4 for operation.

### Setup


"We'll sail to point 17 today.  
Set it as waypoint."

See Page 16 for setup.

"Check the bearing and distance.  
Now, let's go!"

Store event  
"A buoy! Store this position."

See Page 7 for storage.




## Route navigation

Point switching range  
during route navigation

See Page 25 to set proximity alarm.



Route navigation See Page 14 to store route.  
See Page 19 to select route navigation.

When you enter the point switch  
range, the course is set to the  
next point automatically.






# Skipping comment entry





To store Loran C LOPs data, see the "Displaying position data in Loran C LOP mode" (page 30).

**CLR** Press to clear incorrect input. You can reenter numeric data.



## Copying between memory areas

You can store up to 10 event points in memory by event function. When you store more than 10 points, the oldest points are overwritten by a new point. However, you can copy important data to Mark Storage area (point numbers 11 to 99) and keep them permanently. You can also copy the position data in the Mark storage area (11 to 99) and change or edit it.




Warning! Check the position data existing at the destination point number. That data is replaced by this operation. Copy important data to another area first.


## Changing a comment of storage data

You are advised not to change the position data which is currently used as the waypoint or included in the current route.

Select a character or symbol on the comment character and symbol table using ← cursor or type a numeric key.





**CLR** Press to clear incorrect input. You can reenter numeric data.









## Erasing a single route of data



## Erasing entire data from memory



# Setup of Waypoints


The positional data of each waypoint must be registered prior to setting up waypoints. Then specify the point number via NAV 2 menu to allow the waypoints to be set.

	Point number (17)	Point number (17)	
NAV1	27°54.00N	NAV2	0.00
☒ 17	82°41.67W	☒ 17	:00:
SPEED	15.0kt	WPT 17=JACK 1	
COURSE	359.9°	15.0kt 359.9°	

NAV1 screen                      NAV2 screen

## Setting waypoint navigation



Use waypoint navigation to sail to a single point as the destination.



Waypoint (17)


Note:

If you have modified waypoint data in memory, you must set the waypoint navigation again.




## Recalling a waypoint

You can recall and check the present waypoint on the Menu screen during waypoint or route navigation.




## Reentering the origin of waypoint navigation


Once reset, the present position is used as new point of origin for waypoint navigation.



## NAV1 screen during waypoint navigation




## NAV2 screen during waypoint navigation



## Canceling waypoint navigation



To cancel waypoint navigation, turn WPT to OFF on NAV2 screen.



"WP" and numbers are cleared (Display Off).

"OFF" message appears.


"WP" and number are cleared.



## Cross track error and course deviation angle

Check the cross track error (XTE) and course deviation angle together with the distance and bearing to the waypoint during navigation. You have to set the waypoint or route navigation to utilize these pieces of navigational information.


**This chart gives a relationship between original course and ship's position.**



XTE amount	Steer to Left	Steer to Right
0.00 nm	0.00	0.00
0.01 to 0.09 nm	<0.01 to <0.09	0.01> to 0.09>
0.10 to 0.49 nm	<<0.10 to <<0.49	0.10>> to 0.49>>
0.50 to 0.99 nm	<<<0.50 to <<<0.99	0.50>>> to 0.99>>>
1.00 nm or more	<<<<1.00 to <<<<9.99	1.00>>>> to 9.99>>>>




# Route Setup

Following procedure shows how to set up new navigation route using previously entered route number and route point number. Specify the first waypoint in NAV2 screen, by entering the registered route and route point number respectively. If you want to trace back the route, direction of navigation can be reversed.



## Selecting route navigation

You can navigate on a route following the route point, which is automatically updated as you enter each point. You can also reverse the navigation route to return to the start point.



### What is the route point number?

ROUTE: 01 ↓ 08 / 84
60 → 35 → 31 → 22 → 67 →
70 → 11 → 18 → 32 → 91 →
52 → 78 → 83 → 37 → 25 →

Order on the route:

01 → 02 → 03 → 04 → 05 →
06 → 07 → 08 → 09 → 10 →
11 → 12 → 13 → 14 → 15 →

A route point number is the numerical order to the point numbers previously entered

Point number  
Press ▼ or ▲ key to scroll the screen.

### Route point numbers during forward and reverse navigation

ROUTE: 01 ↓ 08 / 84  
 60 → 35 → 31 → 22 → 67 →  
 70 → 11 → 18 → 32 → 91 →  
 ↕ 52 → 78 → 83 → 37 → 25 →

WPT numbers during route setup  
 60 → 35 → 31 → 22 → 67 →  
 70 → 11 → 18 → 32 → 91 →  
 52 → 78 → 83 → 37 → 25 → (Continued to next screen page)


If you activate a route at point number 18 (route point number 08), the forward ( ↓ ) and backward ( ↑ ) navigation are as follows:

Forward ( ↓ ) navigation  
 18 → 32 → 91 → 52 → 78 → 83 → 37 →  
 → 25 → (Continued to next screen page)

Backward ( ↑ ) navigation  
 18 → 11 → 70 → 67 → 22 → 31 →  
 35 → 60



### Checking a route position or a route point position

You can check a route and its points in the Menu screen.



### Skipping an in route point during route navigation


You can skip the next waypoint and go to a new waypoint



NAV2 0.00  
 ▾ 32 :00:  
 RTE 01 ↓ = 09 / 84  
 15.0kt / 359.9°

Waypoint number to be calculated in skipping WPT mode

## Switching between distance to WPT and total distance




To switch the display between the distance (DIST) to the next waypoint and the total distance (T. DIST) to the final destination:

NAV1 screen

NAV1	14248.8
F 83	44713.8

Display field 1

Display field 2



9999

Positioning has failed or the required distance has exceeded 9999 nm, sm, or km.

When "DIST (Distance)" is shown:

The distance to the next waypoint is shown.

When "T. DIST (Total Distance)" is shown:

The total distance required to arrive at the final destination is shown (9999 nm, sm, km maximum).

DIST

27.3 nm


Press key.

← Press key

T. DIST

627.3 nm

## Switching between time to go and total time




To switch the display between the time to go (TTG) to the next waypoint and the total time (T.TTG) required to the final destination:

NAV1 screen

NAV1	14248.8
F 83	44713.8

Display field 1

Display field 2



When "TTG (Time to Go)" is shown:

The time to go to the next waypoint is shown.

When "T. TTG (Total Time)" is shown:

The total time required to arrive at the final destination is shown (99 hours 59 minutes maximum).

TTG

02h21m

Press key

← Press key

T. TTG

32h21m

99h99m

Positioning has failed or the required time has exceeded 99 hours 59 minutes.

## NAV1 screen during route navigation

	NAV1	14248.8
Next waypoint number	W 32	44713.8
	SPEED	15.0kt
	COURSE	359.9°

Present position (LAT/LONG or Loran C LOPs)

The last figures blink during positioning interruption.

See page 6 to select a desired column.

## NAV2 screen during route navigation

	NAV2	0.72>>>
Next waypoint number	W 18	: :31°
	RTE 01	↓=08/84
Speed	15.0kt	359.9°
Route number		
Forward (↓) or backward (↑) navigation		Next route point number.

Cross track error (XTE) (See page 18.)


Course deviation angle (See page 18.)

Total number of points in the route

Course

## Canceling the route navigation

To cancel route navigation, get NAV2 display off screen and press ENT.



"WP" and number are cleared.

NAV2	:	:
OFF		
15.0kt		359.9°

"OFF" message appears.

"WP" and number are cleared.

NAV1	14248.8
	44713.8
SPEED	15.0kt
COURSE	359.9°

# Alarms

## Three functions

- Anchor watch alarm
- Proximity alarm
- Cross track error (XTE) alarm

To set cross track error (XTE) alarm, go to page 26.

Long beep  
(You are outside XTE range.)

XTE alarm

XTE alarm range

Start point  
(origin)

Proximity alarm

Proximity alarm range

To set proximity alarm, go to page 25.

Short beep  
(You have arrived at the  
waypoint.)

Course line

Anchor watch alarm

Short beep  
(Boat has moved from anchor  
watch point.)

To set an anchor watch  
point, go to page 24.



To set a waypoint, go to page 16.

# Setting and Disabling an Anchor Watch Alarm


## What is an anchor watch alarm?

The buzzer sounds when boat has moved outside of anchor watch alarm range.


Anchor watch setup position




## Setting an anchor watch alarm range



## Setting the anchor watch alarm




## Disabling the anchor watch alarm




# Setting and Disabling a Proximity Alarm

## What is a proximity alarm?

The buzzer sounds when you have arrived at the waypoint during waypoint or route navigation. This alarm is set automatically when you have selected the waypoint or route navigation. However, the proximity alarm does not operate if its alarm range is set to 0.00 or if an anchor watch alarm has been set. (Initial set :0.00)




## Setting a proximity alarm range



You cannot operate both proximity alarm and anchor watch alarm simultaneously.

CLR Press to clear incorrect input. You can reenter numeric data.

## Disabling the proximity alarm




When you set an anchor watch alarm, the proximity alarm is canceled automatically.


# Setting and Disabling an XTE Alarm

## What is an XTE alarm (course deviation)?


The buzzer sounds if you have shifted from the preset range of rhumb line course during waypoint or route navigation. However, the XTE alarm does not operate if its alarm range is set to 0.00 or if an anchor watch alarm has been set.



## Setting an XTE alarm range




## Disabling the XTE alarm



When you set an anchor watch alarm, the XTE alarm is canceled automatically.

# Setup Procedure

## Menu options




1. **WAYPOINT**  
Store, edit, copy, and erase waypoints.  
(see pages 9 to 18).
2. **LORAN MON (Loran C monitor)**  
Displays Loran C signal reception status  
Enters chain number and secondary stations.  
Shifts master, secondary 1 or secondary 2, signal tracking point in 10  $\mu$ sec steps.  
Resets whole, secondary 1 or secondary 2 signal reception for reacquisition.
3. **GPS MON (GPS monitor)**  
Displays GPS signal reception status by satellite numbers and DOP figure.
4. **COMP (Correction and compensation)**  
Latitude/Longitude position correction  
LOPs position correction (ASF correction)  
Compass bearing compensation
5. **ROUTE**  
Store, set, cancel, and erase a route  
(see pages 10 to 15 and 19 to 22)
6. **ALARM**  
Enter alarm range and inhibit alarms for XTE alarm, proximity alarm, and anchor watch alarms
7. **CALCULATE (Calculation)**  
Distance and bearing between two points  
Position conversion from LAT/LONG to LOPs  
Position conversion from LOPs to LAT/LONG  
LOPs position conversion from one chain to the other chain
8. **INITIAL (Initial setup)**  
Sets average constant.  
Select distance and speed units.  
Select data output format and edit NMEA-0183 format.
9. **DISPLAY (Display setup)**  
Select the position indication (LAT/LONG or Loran C LOPs)  
Select position source (Loran C or GPS)  
Setup real time conversion from the receiving chain to a different chain.


## Selecting a Menu option

You can select an option on the Menu screen in two ways: by direct numeric number entry and by selection using  $\underline{\quad}$  cursor. This section explains numeric key entry for easy understanding, but you can also use the cursor for option selection. The following compares these two methods when you enter Loran C chain number and secondary station pair (page 28) as an example:

### Numeric number entry




### $\underline{\quad}$ cursor selection




## Displaying position data in LAT/LONG mode

You can select LAT/LONG position by following operation.




## Displaying position data in Loran C LOP mode

You can select LOP position by following operation.




## Entering Loran C chain number and secondary stations



**Correction of input error**


◀ ▶ Locate — cursor onto incorrect number and enter correct one.

CLR Press to clear incorrect input. You can reenter numeric data.




## Display LOPs of different chain

When an old Loran C chain is replaced by a new chain, position in the new chain can be converted into LOPs in the old chain and displayed as a special function. If you have position information previously obtained by LOPs in the old chain and prefer to operate in the old chain, this function gives you the accustomed old chain operation as if you still have the old chain.




**Correction of input error**

◀ ▶ Locate **—** cursor onto incorrect number and enter correct one.




Enter your LOP positions in the old chain into waypoint memories to utilize them.

## How to return to normal operating chain




## Monitoring Loran C signal reception

Loran C signal receiving status is monitored.




## Changing the distance or speed unit

You can change the measuring unit of distance and speed which are simultaneously converted.



8-1 : AVERAGE 3  
2 : UNIT **nm** ← cursor  
3 : FORMAT  
4 : GPS SET




**Unit conversion**

	km	nm	sm
1 km	1	0.540	0.622
1 nm	1.852	1	1.152
1 sm	1.609	0.869	1

## Correcting your position

You can compensate your present position given by GPS as follows. To do so, enter the latitude and longitude (or Loran C LOPs) of your actual position using numeric keys


Actual position



Compensated position





Your ship is repositioned by the correction function.

Position given by GPS



## Correction by LAT/LONG data entry

When your present position is shown in LAT/LONG mode, you can correct it by entering the LAT/LONG correction data.




Present position	Entered position	Correction amount
Latitude 27° 54.00 N	Latitude 27° 54.80 N	Latitude 00.80 N
Longitude 82° 41.61 W	Longitude 82° 45.07 W	Longitude 03.46 W

## Correcting LOP by ASF (Additional Secondary Factor)



There is some discrepancy between actual measured LOPs and a Loran C chart. This is caused by the fact that a Loran C signal from a Loran C station travels slower on the land than on the sea and LOP lines are distorted while a Loran C chart is nearly theoretically computed. Correction against this discrepancy by land pass is called ASF correction (Additional Second Factor). This correction has both manual and automatic (limited to the chains with published correction tables) compensation.

### Automatic correction



### Manual correction


If correct LOPs are known and difference in LOP with measured LOPs is 0.1 to 9.9  $\mu\text{sec}$ , use take following operation. If compensation by  $\pm 10 \mu\text{sec}$  steps is required, perform operation "LOP correction by 10  $\mu\text{sec}$  steps" (see page 33).



**Correction of input error**

◀ ▶ Locate — cursor onto incorrect number and enter correct one.  
 Press to clear incorrect input.  
 You can reenter numeric data.


⊗ CLR



Present position	Correction amount	Corrected position
Secondary 1 station 14248.8 $\mu\text{sec}$	Secondary 1 station +1.1 $\mu\text{sec}$	Secondary 1 station 14249.9 $\mu\text{sec}$
Secondary 2 station 44713.8 $\mu\text{sec}$	Secondary 2 station -1.5 $\mu\text{sec}$	Secondary 2 station 44712.3 $\mu\text{sec}$


### Check the correction amount

You can check the correction amount as follows.



### Cancel the position correction

You can cancel the position correction as follows:



## LOP correction by 10 μsec steps

10 μsec or multiple of 10 μsec error of LOP is observed in the fringe coverage area or by influence of surrounding noise. (Cycle selection error). This phenomenon tends to happen to the farthest station signal.

NAV1	14248.8
	44713.8
SPEED	15.0 kt
COURSE	359.9°

Fig. 1 LOP display example




Fig. 2 Master and secondary signals and LOPs

As indicated by Fig. 1 and Fig. 2, relationship of LOP error direction is opposite between master and secondary signals and correction of error requires some skill to find which station is to be corrected. Generally speaking, there is a station with strong signal level among received master and two secondary stations and usually the strongest station is locked in to the correct cycle (LOP). Station with error is decided by following procedure based on the above fact.


If either secondary 1 or secondary 2 has cycle selection error, the secondary with error displays incorrect LOP.

If both secondary 1 and 2 have cycle selection error, both secondaries display incorrect LOPs.


If master has cycle selection error, LOPs of both secondary 1 and 2 have error equivalent to the master error.

If master and one of secondaries have cycle selection error, the secondary with error displays correct or less erroneous LOP, as if it is locked on the correct cycle. On the contrary, the station locked on the correct cycle displays erroneous LOP.


### Correction of secondary 1




### Correction of secondary 2




### Correction of both secondary 1 and 2



### Correction of master



### Correction of master and secondary 1 or 2




## Restarting the navigator for acquisition and tracking


Following operation restarts reception of entire chain or selected secondary.

### Restart of entire reception


This operation makes the same sequential display changes as the navigator is turned on. For change screen, see the "Getting started" (page 4).



### Restart of secondary 1 reception





### Restart of secondary 2 reception




## Incorrect LAT/LONG position despite good signal condition

A LAT/LONG position is computed as a crossing point of secondary 1 and 2 LOPs. There are two LAT/LONG positions derived as solutions. This is due to the fact hyperbolic LOPs of secondary 1 and 2 meet, at two points (A area and B area in the figure) it is easy to find wrong point because two points are located obviously apart. If a LAT/LONG position is clearly different from an estimated position, switch to the other computed position by following operation.



# Compensation of compass


The course and bearing to waypoint are shown in true bearing. You can adjust the GPS true bearing to the magnetic compass bearing.



## 1 Automatic compensation

In the Auto mode, the magnetic compass is compensated based on the built-in global magnetic variation maps. However, avoid to using this mode if you are higher than 75 degrees North or South latitude. Also, the compass may have a small error as the system contains world maps. Correction manually is recommended.

(Initial setup: Manual)




4-3 : MAGNETIC VAR  
AUTO  
+008.0

An error (compensation amount) from true bearing is shown.

Compass compensation sequence  
Auto → Manual

## 2 Manual compensation




(Initial setup: 0°)  
(Setup range: -180.0° to +180.0°)

4-3 : MAGNETIC VAR  
MANUAL  
+000.0

4-3 : MAGNETIC VAR  
MANUAL  
+008.0

An error (compensation amount) from true bearing is shown.






CLR Press to clear incorrect input. You can reenter numeric data.

Correction of Input error  
Locate cursor onto incorrect number and enter correct one.

## Selecting and editing an output format

Initial setup: Format ..... NMEA-0183  
 Sentence ..... GLL and VTG  
 Interval ..... 1 second

Select data output formats by following operation. If NMEA-0183 is selected, proceed to selection of output data sentences.



### If NMEA-0183 format is selected

Activate required sentences by pressing ENT key. Press CLR key for unnecessary sentences. Numbers of ">" marks represents ratio of information amount to the maximum capacity (Single ">" mark represents approx. 10%). Be careful not to make marks to MAX when selecting sentences. Data output interval is approx. 6 seconds at the maximum capacity.

If it exceeds the maximum capacity, output data interval will be longer than anticipated

**AAM → BOD → BWC → GGA → GLL → GTD → SGR → VTG → WDC → XTE**


Output data		
KODEN 717		Data output interval: approx. 4.5 seconds
NMEA-0182		Data output interval: approx. 3.0 seconds
NMEA-0183 (Ver 1.5)	AAM waypoint arrival alarm. BOD Bearing, origin to destinations BWC Bearing & distance to waypoint GGA Global positioning system fix data GLL Geographic position latitude/longitude. GTD Loran C LOPs SGR Loran C GRI VTG Track made good and ground speed. WDC Distance to waypoint XTE Cross track error measured	Data output interval: approx. 1.0 seconds

## Setting average constants (measuring position, speed and course)

(Initial setup: 3)

Averaging can be imposed to data derived from Loran C information. This can stabilize the measured position (latitude and longitude), speed and course data. The maximum averaging rate is 5 and the minimum rate is 1. When you select a larger value, data is averaged more often and the display data have smaller variation. However delay for updating occurs. When you select a smaller value, data is less averaged but the display data responds quickly.


```
MENU 5 : ROUTE
      6 : ALARM
      7 : CALCULATE
      8 : INITIAL
```




**Note:** Try to use an averaging rate appropriate to your ship's speed so that you can get the stable measuring position, speed and course data.

## Calculating the distance and bearing between two points

You can calculate the distance and bearing between two stored points by great circle.







*This example is shown in LAT/LONG mode.*







# Calculating Loran C LOPs based on LAT/LONG data

When you enter a Loran C chain number and the first digit of two secondary stations, NAVIGATOR calculates the Loran C LOPs based on the specified LAT/LONG data and displays the LOP values.








## Calculating LAT/LONG based on Loran C LOPs data

When you enter a Loran C chain number, NAVIGATOR calculates the Loran C LOPs based on the specified LAT/LONG data and displays the LAT/LONG values.



# Calculating Loran C LOPs in different chains based on LOPs in chain in use

This operation allows you to convert LOPs from one chain (origin) to another destination chain.



# Operation as a GPS navigator

Be sure the GPS receiver module is properly connected before turning on the navigator.

This Loran C navigator also works as a GPS navigator if an optional GPS receiver module (GPS-10 or GPS-6) is attached and setup for following parameters.

- Change of positioning system from Loran C to GPS.
- Selection of GPS receiver module between normal and differential ready.
- Selection of geodetic datum.
- Selection of positioning system between 2D (two dimension) and 3D (three dimension)


A GPS receiver module, other than specified above, may be interfaceable with the navigator if it transmits NMEA-0183 GGA sentence. However, initial parameter setting should be taken care of at the GPS receiver module side. In this case, only position information is used at the navigator. When both GPS receiver module and a differential beacon receiver are connected, disconnect the beacon receiver while setting GPS receiver module parameters. Parameters set once are retained by backup memory.

Displays when a GPS receiver module is not connected.

3: GPS No Connection	8-1: No Connection 2: 2D/3D 2D 3: ANT. H 0000 4: DATUM 02
-------------------------	--

## How to change to GPS

(Initial: LR)




9-1: DISPLAY LOP 2: POSITION LR 3: LOP. CONV OFF	9-1: DISPLAY L/L 2: POSITION GPS 3: LOP. CONV OFF
--	---

Position source selection sequence:  
LR → GPS

## Selecting GPS receiver module

(Initial: DGPS)

Depending on the type of GPS receiver module, selection of the type is required.




GPS receiver module selection sequence:  
NORM → DGPS

MENU 5: ROUTE 6: ALARM 7: CALCULATE 8: INITIAL	8-1: AVERAGE 3 2: UNIT nm 3: FORMAT 4: GPS SET	8-1: GPS set DGPS 2: 2D/3D 2D 3: ANT. H 0000 4: DATUM 02
---	---	---

## Setting antenna height (above sea level)

(Initial: 0 m)

Enter the antenna height (above sea level) as accurately as possible. It determines the positioning accuracy. The antenna height error must be less than 5 meters. The antenna height can be set in either metric or standard (feet) system (see page 29 for unit switching)



**Correction of input error**


← → Locate — cursor onto incorrect number and enter correct one.

CLR Press to clear incorrect input. You can reenter numeric data

MENU 5: ROUTE 6: ALARM 7: CALCULATE 8: INITIAL	8-1: AVERAGE 3 2: UNIT nm 3: FORMAT 4: GPS SET	8-1: GPS set DGPS 2: 2D/3D 2D 3: ANT. H 0000 4: DATUM 02
---	---	---


## Selecting a geodetic datum

The latitude and longitude are calculated based on the WGS-84 with GPS system. However, the charts used in each country are based on different geodetic datum. You can compensate difference from your chart by converting GPS position data into your actual chart system. To select a geodetic datum, see "Geodetic datum list" on page 58.



**Correction of input error**


- ◀ ▶ Locate — cursor onto incorrect number and enter correct one.
- CLR Press to clear incorrect input. You can re-enter numeric data.



## Selecting a measuring system mode

(Initial setup: 2D)


If there is no height difference (such as a ship on the sea), use the 2D (two-dimensional measurement) mode. The DOP value is small and the measuring accuracy increases.  
If you cannot receive signals from four satellites or if the PDOP value has exceeded the limit, the 3D (three-dimensional measurement) mode is automatically switched to the 2D mode.



**When 3D is switched to 2D:**  
The antenna height measured in 3D mode is shown in 3-3 ANT. H field.  
To manually change the antenna height, see "Setting antenna height (above sea level)" (see page 42).


**Measuring system switching sequence**  
→ 2D (2-dim. measurement) → 3D (3-dim. measurement) →

2D: Positioning is based on the antenna height you have set in ANT. H field of Menu option 3: GPS.  
3D: The antenna height is determined by use of positioning data and shown on ANT. H field of Menu option 3: GPS.



## Getting started (as a GPS navigator)

When you first use NAVIGATOR, it must first receive the orbital data from satellites and it may take approximately 15 minutes to display your position (COLD START). Once this step is completed, your position is displayed immediately any time you wish. To make NAVIGATOR operational (to store orbital data of GPS satellites in system memory), use the following steps. Functions not mentioned in this section are common to indicated Loran C section.



**PWR DIM** Press to turn NAVIGATOR on.

**Dim/bright the display:**

**PWR DIM** Press to dim/bright the screen.

**Change the contrast:**

**CTRS** Press to change the LCD contrast (intensity) in 8 levels

**Power off:**

**OFF** Press for 2 seconds to turn NAVIGATOR off. All data before power-off is kept in memory for later use.

**What is failure of positioning?**  
If signals from three or more satellites are not received your position cannot be fixed

On-screen messages change in the following sequence when NAVIGATOR receives satellite signals and displays latitude/longitude data.

**LORAN ROM No. KM- A00 checking** Initial message during power-on

**LORAN ROM No. KM- A00 check OK** Message to indicate checking of GPS receiver and display has been completed.

Blinking.

**NAV1 27°54.008N**  
**82°41.613W**  
**SPEED 15.0kt**  
**COURSE 359.9°**  
Blinks when NAVIGATOR is searching GPS satellites. N (or S) and W (or E) blinks during interruption of position.

No blinking



**NAV1 27°54.008N**  
**82°41.613W**  
**SPEED 15.0kt**  
**COURSE 359.9°**  
When NAVIGATOR receives signals from 3 or more satellites, it displays present latitude and longitude position with solid N (or S) and W (or E).

**LAT/LONG positions are down to 1/1000 minutes digit.**

## Monitoring GPS satellite signal reception

You can monitor the signal monitor status from GPS satellites. The receiver receives signals from 3 satellites during two-dimensional positioning, but it receives signals from 4 or more satellites during three-dimensional positioning.


**H:** HDOP value (for 2-dimensional positioning)  
**P:** PDOP value (for 3-dimensional positioning)  
The system stops positioning if DOP has exceeded the limit. When this value is large, the positioning accuracy is degraded.



This function is available only when the navigator is interfaced with a GPS -10 or GPS-6.


## Adjusting LOPs from GPS position to Loran C LOPs

This function adjusts LOPs by GPS to Loran C LOPs if they don't match each other.




Loran C LOP	GPS LOP	Adjusting amount
Secondary station 1 14248.8 $\mu$ sec	Secondary station 1 14249.3 $\mu$ sec	Secondary station 1 -000.5 $\mu$ sec
Secondary station 2 44713.8 $\mu$ sec	Secondary station 2 44713.6 $\mu$ sec	Secondary station 2 +000.2 $\mu$ sec

## Comparing GPS LOPs and Loran C LOPs



## Cancel of adjust




# Troubleshooting Guide

If NAVIGATOR does not function properly, check the following points. If the problem continues, call for service.

## Nothing appears when you press PWR/DIM key

Check the following points:


- Blown fuse
- Low battery voltage
- Poor contact of power cable to display unit
- Poor contact of power cable to battery socket



## No information appears on the screen (during initial setup) and language selection

Check the following points.

- The antenna cable may not be connected securely between the antenna and receiver.
- If signals not received, or key operation not effective, try the following steps.



When the above procedure is carried out:

- The stored position data is lost even when you perform these steps.
- The present positioning data is erased and NAVIGATOR returns to the initial setup.
- All setup parameters are initialized and you need to set them again.

## Error message appears at power on ( Self-test function)

The following messages continue one or two seconds during power on.


**LORAN**  
**ROM No. KM-A00**  
**check ERROR** — Error display

- If you have replaced the ROM chip, the ROM changed message may appear. In this case, turn on the power switch again.
- If an ERROR display continues and nothing changes on the screen, call for service.

### Nothing appears but buzzer sounds during power-on

- The receiver CPU has failed.
- Call for service.

### Unstable signal reception Loran C navigator



```

MENU 1 :WAYPOINT
      2 :LORAN MON
      3 :GPS MON
      4 :COMP
    
```


```

2 :LORAN 7980 1-4
  MASTER 068 0
  14248.8 059 0
  44693.8 001 X
    
```

1. If there is an obstacle around the antenna, NAVIGATOR cannot receive Loran C signals. You must change the antenna position.
2. Monitoring Loran C signals reception
  - Acceptable if 0 or 1 is displayed.
  - It may show number bigger than 2 in the vicinity of the station.
  - Acceptable if 1 to 9 is displayed.
  - Better with bigger number
  - Acceptable if bigger than the left number.

X: No good CS  
O: Good CS

### Unstable signal reception GPS navigator



```

MENU 1 :WAYPOINT
      2 :LORAN MON
      3 :GPS MON
      4 :COMP
    
```

```

3 :GPS H 02.1
  02 32 20 14
  SN 15 10 12 10
  EL 12 74 30 10
    
```


1. Check the DOP of satellites.
  - H: HDOP value (for 2-dimensional positioning)
  - P: PDOP value (for 3-dimensional positioning)
  - If the HDOP has exceeded 20, NAVIGATOR stops positioning. Also, its positioning accuracy drops if HDOP gets larger in value.

HDOP value	Accuracy
1 to 6	Normal
7 to 12	Acceptable
13 to 20	Low

Satellite PRN number  
PRN: Pseudo Random Noise  
Elevation angle of satellite  
The angle of satellite from horizon

2. Check the S/N of each satellite signal.
  - If elevation angle is 10 degrees or more, the S/N values may be 10 to 20 normally.
3. If there is an obstacle between the antenna and satellites, NAVIGATOR cannot receive GPS satellite signals. You must change the antenna position.

### Checking frequency deviation of the crystal oscillator



Frequency deviation  
Allowable range: - 20 to + 20.

```

NAV1xtal 14248.8
F 17 -04 44713.8
SPEED 15.0kt
COURSE 359.9°
    
```

When frequency deviation is not displayed

```

Menu 9: DISPLAY
1 : DISPLAY LOP
2 : POSITION LR
3 : LOP . CONV OFF
    
```

Display LOP.  
Display LR.

# Specifications

## Major Specifications

\* Specifications subject to change without notice.

Loran C receiver section	
Receiving frequency	100 kHz
Acquisition	Automatic
Tracking	Automatic
Setting time	Approximately three minutes
Signal level	110 dB $\mu$ V/m maximum
Tracking speed	80 knots maximum
Notch filter	Presel : 4
Tracking station	Master and five secondary stations
GPS receiver section: GPS receiver module GPS-10 (optional)	
Receiving frequency	1575.42 MHz $\pm$ 1 MHz
Receiving channel	Digital 6-channel parallel
Receiving code	C/A code
Sensitivity	Better than -130 dBm (elevation angle: 5° or over)
Tracking speed	200 knots maximum
Accuracy	Position 15 meters RMS (without SA), 100 meters 2DRMS (with SA)
(PDOP $\leq$ 3)	Velocity 0.1 knot RMS (without SA)
Note: Accuracy is subject to change in accordance with DoD civil GPS user policy.	
Loran C/GPS display section	
Display	LCD with backlight (16 x 4 characters, usual picture area: 85 x 42 mm)
Display mode	NAV1, NAV2, NAV3, MOB (Man Over Board), MENU
Position data display	Loran C LOPs (0.1 $\mu$ sec) or converted Latitude/longitude in increments of 1/100 minute
Navigational display	Speed, course, velocity made good/course made good/elapsed time, distance/bearing/cross track error/course deviation/time to go to waypoint, total time to go and distance on route, distance/bearing between two points, MOB display GPS (optional): altitude, DOP value, satellite status
Instant (event) memory	10 points
Waypoint memory	89 points (usable as waypoint)
Route memory	10 routes (Max. 89 waypoints) with reverse trail
Alarm	Proximity, cross track error, anchor watch
Position compensation	Loran C LOPs, latitude/longitude, Datum (GPS navigator)
Magnetic compensation	Auto or manual
Parameters	Latitude/longitude conversion, memory of position marks and comment (up to 8 letters), selection of measuring unit (nm, sm, km), averaging (smooth) factor GPS (optional): antenna height, position mode (2D or 3D automatic selection)
Input data format	NMEA-0183 (GGA, VTG, PKODA, PKODG 1): GPS only
Output data format	KODEN 717, NMEA-0182, NMEA-0183 (AAM, BOD, BWC, GGA*, GLL, GTD, SGR, VTG, WDC, and XTE) *:GGA is GPS only output.
Data output interval	Approx. 4.5 seconds (KODEN 717), approx. 3.0 seconds (NMEA-0182), and 1 to 10 seconds selectable (NMEA-0183)
Memory protection	By built-in battery
Power supply	11 to 40 VDC
Power consumption	5 W or less (24 VDC)
Environmental condition	Display unit: 0° to +50°C (32° to 122°F) Antenna unit: -30° to +70°C (-22° to 158°F)

## Standard equipment list

No.	Article	Type	Remarks	Weight/length	Quantity
1	Display unit	LR-792/XJ-9	With mounting bracket and vinyl cover	0.9 kg (1.9 lbs)	1
2	Receiving antenna	RA-14	2.45 m whip	0.3 kg (0.6 lb)	
3	Antenna coupler	AC-21	With antenna cable	1.0 kg (2.2 lbs)	1
	Antenna cable	CW-191A	Connected to AC-21/ BNC connector	10 m (32.8 ft)	1
4	DC power cable	CW-219	With a connector	1.8 m (5.9 ft)	1
5	Fuse	F-7161, 1A	For spare		1
6	Truss tapping screw	TPT M5 X 20U	For mounting bracket		2
7	Operation manual				1

## Options

No.	Article	Type	Remarks	Weight/length
1	Remote display	UR-7	With power and connecting cable	
2	GPS receiver module	GPS-10	With cable (10 m.32.8 ft)	0.45 kg (1.0 lb)
3 -1	Receiving antenna	RA-14	2.45 m whip	0.3 kg (0.6 lb)
		RA-16	4 m whip	1.0 kg (2.2 lbs)
4 -1	Antenna holder	RAH-20	For receiving antenna (RA-16)	
		RAH-22A	For antenna holder (RAH-20) mounting	
		RAH-26		
5	Terminal adapter	TJ-1	For receiving antenna (RA-16)	
6	Antenna adapter	KCAD-02		
7	Hose band	738-1015	For antenna coupler	
8 -1	Connecting cable	CW-326	With 6-pin and BNC connectors	5 m (16.4 ft)
		CW-327	With 6-pin connectors	5 m (16.4 ft)
		CW-328	With 6-pin connector and lugs	5 m (16.4 ft)
9	Power rectifier	PS-003A	With two 5A fuses	
10	AC power cable	VV-2D8	Both ends plain, for power rectifier	3 m (9.8 ft)
11	Flush mount kit	FMK-1	Flush mount frame with screws	


## Latitude/longitude convertible chains

5930	CANADIAN EAST COAST	8290	NORTH CENTRAL U.S.
5970	COMMAND LION	8930	NORTHWEST PACIFIC
5990	CANADIAN WEST COAST	8940	FRENCH
7170	SOUTH SAUDI ARABIA	8970	GREAT LAKES
7270	NEWFOUNDLAND EAST COAST	8990	SAUDI ARABIAN NORTH
7930	LABRADOR SEA	9610	SOUTH CENTRAL U.S.
7950	CHAYKA EASTERN ASIA	9940	U.S. WEST COAST
7960	GULF OF ALASKA	9960	NORTHEAST U.S.
7970	NORWEGIAN SEA	9970	NORTHWEST PACIFIC
7980	U.S. EAST COAST	9980	ICELANDIC
7990	MEDITERRANEAN SEA	9990	NORTH PACIFIC
8000	CHAYKA EUROPEAN		

# Outline and Dimensions


Scale differs among drawings

## Antenna coupler (AC-21)




Weight: 1.0kg (2.2 lbs)  
Excluding cable

## Mounting of Flush mount kit (FMK-1)




## Display unit




Mounting dimensions  
Weight: 0.9 kg (1.9 lbs)  
Unit: mm (inch)

## GPS receiver module (GPS-10)



Weight: 0.45 kg (1.0 lb)  
Excluding cable

# Interconnecting Diagram



## Grounding Notes:

The vessel with a ground alarm system, floating power system or positive side grounding may damage the navigator if the ground terminal on the back side is connected to the vessels hull earth. In this case, a navigator with floating power supply is available and recommended.

# Installation (Loran C navigator)

## Positions of antenna and its coupler

Install the antenna and its coupler at the highest position on the vessel. Even if it has inevitably to be installed at a low position, do not mount it under or inside a place where metal is collected. A metallic object which intervenes between the transmitting station and antenna might not allow a reception even within the service area.

### Notice for installation

As an installation site, select a place free from any metallic objects.

Install the antenna coupler at least one meter away from the receiver or remote display. An appropriate installation position for the antenna and coupler is as follows according to different types of vessels.

- On a yacht, an insulated aft stay is usable as an antenna.
- In case of central cabin vessel, install the coupler on a side or top of the cabin.
- On a motor boat, install the coupler on a bridge passage, on the top or side of the cabin.


Select a place where the antenna can be mounted vertically.

Install the coupler as far away from other antennas, particularly transmitting antennas of intermediate or high frequency as possible. Keep away from TV set and receiving antenna.

## Reference diagrams

Select an optimum position.

### For small vessel



#### Position A (above radar mast)

A short antenna cable suffices. The installation is available at an elevated place.


#### Position B (on mast)

Installation is possible at an elevated position, but the antenna cable length may fall short.

#### Position C (bridge)

A short antenna cable suffices. However, installation at an elevated place is impossible, and a reinforcement is troublesome.

### For medium to large sized fishing boats



#### Position A


Mount the antenna at least one meter above the yard and as far away from the transmitting antenna as possible

#### Position B

Mount the antenna on the end of the bridge and as far away from the transmitting antenna as possible. Mount the antenna coupler so the horizontal antenna element will be positioned below the middle of the whip antenna

#### Position C

Tilt the antenna outward at least two meters away from the loop antenna. Even this may slightly affect the bearing measurement on the two MHz band.



#### Position A and B

Mount on the bridge and as far away from the transmitting antenna as possible.

#### Position C



Mount at least one meter above the yard and as far away from the transmitting antenna as possible.

Tilt outward at least two meters away from the loop antenna. Even this may slightly affect the bearing measurement on the two MHz band

#### Position D

Mount at least one meter above the yard and as far away from the transmitting antenna as possible.

**If no position is available matching the above conditions and when the operation is made only where the Loran signal is strong enough, refer to the following.**



**Position A**  
Absolutely avoid a place immediately below the transmitting antenna.


**Position B**  
Separate as far away from the transmitting antenna. Mount the receiving antenna so its top end is located above the transmitting antenna. Separate as far away from the radar mast and other obstacles as possible.

**Position C**  
Absolutely avoid a place surrounded by obstacles.

**Position A and B**  
Separate as far away from the transmitting antenna as possible, and mount the receiving antenna so its top end is located above the transmitting antenna. Separate as far away from the radar mast and other obstacles.



**Position C**  
Absolutely avoid a place immediately below the transmitting antenna.

### Cable connections



### RF ground

In order that Loran receiver operates properly, RF ground may be required. If the grounding status is wrong, an erratic or no operation might occur. The equipment conditions differ from one vessel to another. In case of an engine vessel, extend the ground wire direct to the engine block or engine outer case.




#### Grounding Notes:

The vessel with a ground alarm system, floating power system or positive side grounding may damage the navigator if the ground terminal on the back side is connected to the vessel's hull earth. In this case, a navigator with floating power supply is available and recommended.


# Antenna installation

## 2.45 m receiving antenna (for wooden and FRP vessel)




Connect the grounding wire to the ground terminal of the unit or ship's bottom hull steel plate earth.


## Antenna unit holding pipe (Screw: W1-14 threads)




## Antenna unit holding pipe (Screw: G3/4) Antenna adapter KCAD-02 is required.



## 4 m receiving antenna (for steel vessel)




## 4 m receiving antenna (for wooden and FRP vessel)




## Antenna holder

### RAH-20



### RAH-22




# Installation (GPS navigator)

## Installation site

Scale differs among drawings.

Make sure to install the GPS receiver module with a clear view of the horizon.  
 Objects placed above the GPS receiver module or too close to the GPS receiver module may cause signal to noise ratio degradation and shorten measuring time.  
 If possible, allow the following separations.

- (1) As far away from the metallic object as possible.
- (2) At least 4 meters (13.2 feet) away from the MF/HF reversed L-type TX antenna, VHF or HF whip antenna.
- (3) At least 1.5 meter (4.9 feet) above the MF/HF reversed L-type TX antenna.
- (4) At least 1 meter (3.3 feet) away from the receiving antenna.
- (5) Outside radar transmitting beam ( $30^\circ$  to  $40^\circ$ ).
- (6) At least 5 meters (16.5 feet) away from the Inmarsat antenna.
- (7) At least 3 meters (9.8 feet) away from the loop antenna.
- (8) At least 0.5 meters (1.6 feet) above the large metal surface.




\* At least 0.5 meters (1.6 feet) above the large metal surface.


Should you find no place is available under the conditions as described in (1) through (8), then find the largest metal object and set up the antenna as far away as possible.

Guide line		
Object	Size in diameter	Minimum distance
Pole	10 cm (3 15/16 inches)	1.5 m (4.9 ft)
Pole	30 cm (11 13/16 inches)	3.0 m (9.8 ft)

## Cable connection



## Antenna installation



# Appendix ... Local Geodetic Systems

In alphabetical order

Name	No.	Name	No.
ALASKA/CANADA	04	LIBERIA 64	57
ARC 50	29	MAHA 71	58
ARC 60	30	MALAYSIA	23
ARGENTINA	39	MALDIVE	48
ASCENSION	31	MARCUS	35
AUSTRALIAN 84	06	MARSHALL	82
BAHRAIN	27	MASCARENE	73
BERMUDA	37	MIDWAY 61	62
BRAZIL	45	MOROCCO	61
CANARY	68	NAD-27	03
CAYMAN BRAC	56	NAD-83	10
CHATHAM	43	NEW GEORGIA	46
COCOS	28	NEW ZEALAND	13
COLOMBIA	38	NIGERIA	63
CORVO/FLORES	65	OMAN	67
DIEGO GARCIA	52	PARAGUAY	44
DJAKARTA	22	PHILLIPPINES	19
EAST FALKLAND	76	PHOENIX	40
EAST MALAYSIA	79	PITCAIRN	69
EASTER	47	PORTO SANTO	77
EFATE	36	PUERTO RICO	71
EGYPT	66	QATAR	72
ENGLAND	20	ROME 40	15
ERITREA	60	SALVAGE	59
ETHIOPIA	25	SANTA MARIA	75
EUROPEAN 50	05	SANTO	74
EUROPEAN 79	14	SAUDI ARABIA	17
FAIAL	78	SOMALIA	26
FIJI	81	SOUTH AFRICA	16
FLORIDA	41	SOUTH AMERICA	08
GREENLAND	09	SOUTH ASIA	07
GUADAL CANAL	50	SOUTH CHILE	70
GUAM 63	49	SRI LANKA	54
HAWAII	21	ST. HELENA	34
HONG KONG 63	51	SURINAM	83
ICELAND 55	11	TERN	33
IRELAND 65	12	TOKYO	02
INDIAN/NEPAL	18	TRINIDAD	64
IWO JIMA	32	TRISTAN	80
JAPAN	24	TUNISIA	42
JOHNSTON	53	WGS-72	01
KELGUELEN	55	WGS-84	00

In numerical order

No.	Name	No.	Name
00	WGS-84	42	TUNISIA
01	WGS-72	43	CHATHAM
02	TOKYO	44	PARAGUAY
03	NAD-27	45	BRAZIL
04	ALASKA/CANADA	46	NEW GEORGIA
05	EUROPEAN 50	47	EASTER
06	AUSTRALIAN 84	48	MALDIVE
07	SOUTH ASIA	49	GUAM 63
08	SOUTH AMERICA	50	GUADAL CANAL
09	GREENLAND	51	HONG KONG 63
10	NAD-83	52	DIEGO GARCIA
11	ICELAND 55	53	JOHNSTON
12	IRELAND 65	54	SRI LANKA
13	NEW ZEALAND	55	KELGUELEN
14	EUROPEAN 79	56	CAYMAN BRAC
15	ROME 40	57	LIBERIA 64
16	SOUTH AFRICA	58	MAHA 71
17	SAUDI ARABIA	59	SALVAGE
18	INDIAN/NEPAL	60	ERITREA
19	PHILLIPPINES	61	MOROCCO
20	ENGLAND	62	MIDWAY 61
21	HAWAII	63	NIGERIA
22	DJAKARTA	64	TRINIDAD
23	MALAYSIA	65	CORVO/FLORES
24	JAPAN	66	EGYPT
25	ETHIOPIA	67	OMAN
26	SOMALIA	68	CANARY
27	BAHRAIN	69	PITCAIRN
28	COCOS	70	SOUTH CHILE
29	ARC 50	71	PUERTO RICO
30	ARC 60	72	QATAR
31	ASCENSION	73	MASCARENE
32	IWO JIMA	74	SANTO
33	TERN	75	SANTA MARIA
34	ST. HELENA	76	EAST FALKLAND
35	MARCUS	77	PORTO SANTO
36	EFATE	78	FAIAL
37	BERMUDA	79	EAST MALAYSIA
38	COLOMBIA	80	TRISTAN
39	ARGENTINA	81	FIJI
40	PHOENIX	82	MARSHALL
41	FLORIDA	83	SURINAM

## CERTIFICATE OF LIMITED WARRANTY

Providing you present a valid proof of purchase, SI-TEX Marine Electronics Inc. warrants all parts of each new product against defect in material and workmanship under normal use and will repair or exchange any parts proven to be defective at no charge for a period of two years for parts and one year for labor from the date of purchase, except as provided below under Limited Warranty Exceptions.

Defects will be corrected during normal working hours by an authorized SI-TEX Marine Electronics Inc. dealer, service center, or at the SI-TEX office in St. Petersburg, Florida. There will be no charge for labor for a period of one year from the date of purchase, except as provided below under Limited Warranty Exceptions.

This Warranty and Proof of Purchase must be made available to the authorized SI-TEX Marine Electronics Inc. service location or dealer at the time of service.

### LIMITED WARRANTY EXCEPTIONS

SI-TEX Marine Electronics Inc. will not be responsible for equipment which has been subjected to water or lightning damage, accident, abuse, or misuse nor any equipment on which the serial number label has been removed, altered or mutilated.

SI-TEX Marine Electronics Inc. assumes no responsibility for damage incurred during installation.

This Limited Warranty is effective only with respect to the original purchaser.

Any cost associated with transducer replacement, other than the cost of the transducer itself, is specifically excluded from this Limited Warranty.

Travel cost incurred will not be accepted for SI-TEX Marine Electronics Inc. products.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE FACE HEREOF.

### SPECIFIC EXCLUSIONS

Charges for overtime, stand-by, holiday, and per diem are specifically excluded from the Limited Warranty.

Chart paper, stylus, stylus belt, lamps, and fuses are consumable items and are not covered by this Limited Warranty.

Installation workmanship or materials except as provided directly by SI-TEX Marine Electronics Inc. are not covered by this Limited Warranty.

SI-TEX Marine Electronics Inc. equipment or parts thereof which have been repaired or altered except by an authorized SI-TEX Marine Electronics Inc. dealer or service center are not warranted in any respect.

Transducer, software update, battery, microphone, magnetron, and microwave components and water damage on water resistant VHF radio are items excluded from the two-year warranty and are covered by warranty for a period of one year for both parts and labor.

SI-TEX Marine Electronics Inc. will not, at any time, assume any costs or labor charges for checkout or external line fuse replacement or problems not found to be at fault in equipment itself.

THERE ARE NO WARRANTIES OR GUARANTEES EXPRESSED OR IMPLIED WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY. SI-TEX MARINE ELECTRONICS INC. HAS NO OTHER LIABILITY TO PURCHASE FOR DIRECT OR CONSEQUENTIAL DAMAGE OR ANY THEORY INCLUDING ABSOLUTE LIABILITY, TORT, OR CONTRACT. THIS LIMITED WARRANTY CANNOT BE ALTERED OR MODIFIED IN ANY WAY AND SHALL BE INTERPRETED IN ACCORDANCE WITH THE LAWS OF THE STATE OF FLORIDA. THIS WARRANTY IS LIMITED TO THE CONTINENTAL U.S.A., ALASKA, HAWAII, AND CANADA.

### HOW TO OBTAIN SERVICE UNDER THIS WARRANTY

To provide better flexibility, SI-TEX Marine Electronics Inc. gives you the option of obtaining service under this warranty by either:

a) Contacting an authorized SI-TEX Marine Electronics Inc. service station (The closest service station may be found by contacting your dealer of purchase.)

or

b) Shipping your equipment prepaid via UPS or truck with insurance prepaid to SI-TEX Marine Electronics Inc. at the address provided below.

SI-TEX Marine Electronics Inc. will, whenever possible, make all repairs covered by Limited Warranty within two weeks of receiving the equipment in Florida and return same to you, freight prepaid.

c) You must present a copy of your Purchase Sales Slip at the time you request warranty service.

#### Shipping/Mailing Address:

SI-TEX Marine Electronics Inc.  
11001 Roosevelt Blvd., Suite 800  
St. Petersburg, FL 33716  
727-576-5734

SI-TEX Marine Electronics Inc. offers a complete line of quality marine electronics including fishfinders, electronic charting systems, radars, autopilots, GPS/WAAS/Loran receivers, SSB receivers, direction finders, VHF radios, VHF marine & TV antennas, and integrated systems.

For more information, contact your SI-TEX dealer or the main office, located in St. Petersburg, Florida.

**NOTES PAGE**

**NOTES PAGE**

**NOTES PAGE**

**SI-TEX MARINE ELECTRONICS INC.**

**11001 ROOSEVELT BLVD. SUITE 800  
ST. PETERSBURG, FL 33716**

**PHONE: 727-576-5734**

**FAX: 727-576-5547**