



MODEL 787C

**DUAL-AUTOMATIC
LORAN C RECEIVER**

JANUARY 1984

**INSTALLATION-OPERATION
MANUAL**

SPECIFICATIONS

SI-TEX Model 787C

| | |
|--|--|
| Frequency | 100 KHz |
| Sensitivity | Less than 5uVolts/Meter |
| Maximum Input Level | 0.3 Volts |
| Tracking Velocity | 0-40 knots |
| Settling Time | 3 minutes at 0 db (nom) |
| Power Drain | 11 - 15 VDC 0.5A <u>NEGATIVE GROUND ONLY</u> |
| Ambient Temperature | 0 - 50°C |
| *** Notch Filter | 3 Internal, Preset |
| ** ComPuNav Course Computer | Built-in For TD and Lat/Long Operation |
| Data Output | Serial Cross Track For Auto Pilot |
| Coordinate Converter-Lat/Long | Built-in |
| Mounting Dimensions/Weight | 5.8W x 6.6H x 3.2D inches/1.3KG, 3lb. |
| Antenna Coupler with 15 Meters (49') of Cable | May be mounted directly on extension Pole or attached with hose clamps |
| Case Construction | Super Splash proof |
| Display | LCD Backlighted with Dimmer Control |
| Controls | Membrane Keyboard Backlighted |
| Alarms Audible | Touchtone Keyboard, Proximity Alarm |
| Alarms Visual | Anchor Watch and Cross Track In LCD Display for Cycle Select, Sig/Noise, Station Blink |
| Position Correction | Manual TD or Lat-Long. |
| Compass Heading Correction | Manual |
| Elapsed Time Counter, Clock | Day, Hours, Minutes |
| ** Data output includes 1) Autopilot, 2) Latitude-Longitude data only for Dead Reckoning input to SI-TEX 747 Satellite Navigator | |
| *** Readjustment of Notch Filters may be recommended for operation in certain areas: | |
| a) Anywhere within 20 miles of a high power, high frequency radio transmitter such as High Seas Ship to Shore stations, High Power Navy stations on East and West Coast USA. | |
| b) In areas where LORAN A and DECCA NAVIGATION systems are in operation, such as East and West Canada and other foreign countries of Europe and Asia. | |
| c) The U.S. Coast Guard provides an Interference list in Loran C Users Handbook MI6562.3 which describes the areas of interference in the U.S. | |

FEATURES

Your Model 7B7C has been designed to provide accurate and reliable Loran C radio navigational data. The following list of features describes the capabilities which make it one of the most versatile Loran C receivers available:

- * Programmable GRI for operation in most Loran C chains located throughout the world.
- * Fully automatic, Microprocessor controlled operation. Once the GRI and Secondaries are selected, acquisition, cycle selection and settling are automatic.
- * Automatic tracking of Master station and all useable secondaries.
- * Dual LCD displays simultaneously display two TD's of the selected secondaries or Latitude and Longitude.
- * Repeatable accuracy, 50 to 1500 Ft. depending on TD's used and the gradient of TD's.
- * Always ON memory retains the entered GRI, the secondary stations selected and all data programmed or stored in memory locations even when Power is turned off. Once entered the data remains stored until it is cleared.
- * Auto-Start when receiver is turned on. You usually never need to enter the GRI again.
- * Waypoint programming in Fifty (50) memory locations.
- * Automatic entry of programmed waypoints.
- * Memory indicators when data is entered or recalled.
- * Instant Memory feature stores present position TD's or Latitude-Longitude.
- * Sealed keyboard with touch-tone operation.
- * Proximity alert - tone sounds at approximately 2 second intervals for Off-Course, anchor watch, waypoint arrival.
- * Elapsed time counter, 24 Hour clock.
- * ComPuNav Operation (computerized navigation), to compute and guide you along the course to the desired destination (waypoint), automatically computes the Cross Track Error, Distance to Go (Range) and Time to Go, Vessels Speed, Vessels Loran Heading, Bearing To Waypoint.

CONTENTS

MODEL 787C

| <u>SECTION/PARAGRAPH</u> | <u>Page</u> |
|--|-------------|
| SPECIFICATION | i |
| APPLICABLE LORAN C CHAINS | iv |
| GLOSSARY OF TERMS | viii |
| 1.0 INTRODUCTION | 1-1 |
| 1.1 Precautions When Using Loran C Charts | 1-2 |
| 1.2 Loran C Navigation. | 1-3 |
| 1.3 What is Loran | 1-3 |
| 1.4 Loran C Systems | 1-4 |
| 1.4.1 GRI Designation | 1-4 |
| 1.5 Using the Loran C System | 1-9 |
| 1.5.1 Selecting the Chain | 1-9 |
| 1.5.2 Selecting the Secondaries, LOP, Crossing Angles, LOP Gradient | 1-9 |
| 1.6 Baseline Extension. | 1-10 |
| 1.7 ASF, Land Path delay, Grid Warp | 1-10 |
| 1.8 Converting TD Microseconds to Nautical Miles. | 1-12 |
| 1.9 Accuracy of Loran, ASF Correction Tables. | 1-13 |
| 2.0 INSTALLATION | 2-1 |
| 2.1 Receiver Site Selection and Mounting Location. | 2-1 |
| 2.1.1 Receiver Installation | 2-1 |
| 2.1.2 Antenna/Antenna Coupler Site Selection | 2-3 |
| 2.2 Power Requirements | 2-5 |
| 2.2.1 Power Connection. | 2-5 |
| 2.2.2 Internal Battery Power. | 2-8 |
| 2.2.3 Radio Frequency (RF) Grounding. | 2-9 |
| 2.2.4 Fuses and Fuseholders | 2-9 |
| 2.5 Alternator-Generator | 2-10 |
| 3.0 OPERATION | 3-1 |
| 3.1 General | 3-1 |
| 3.2 Description of Controls and Indicators. | 3-1 |
| 3.2.1 Power ON/Power OFF/Lamp Dimmer. | 3-1 |
| 3.2.2 Operating Mode Indicators | 3-1 |
| 3.2.3 Operating Mode Select or Keys | 3-2 |
| 3.2.4 Keyboard | 3-2 |
| 3.2.6 Proximity Alert | 3-5 |
| 3.2.7 Notch (Interference) Controls | 3-5 |
| 3.2.8 Status Alarm Indicators | 3-5 |
| 3.2.9 CS and S/N Status Alarms. | 3-6 |
| 3.2.10 CS-Cycle Select Indicators. | 3-6 |
| 3.2.11 Signal/Noise (S/N) Indicators | 3-6 |
| 3.2.12 Blink Alarms. | 3-8 |
| 3.3 Modes of Operation. | 3-9 |
| 3.4 Operating Procedures. | 3-12 |
| 3.4.1 Initial Power On Operation/Initial Programming | 3-12 |

CONTENTS (Con't.)

| <u>Section/Paragraph</u> | <u>Page</u> |
|--------------------------|--|
| 3.4.2 | Selection of Secondary Stations 3-12 |
| 3.4.3 | Automatic Tracking using TD's 3-13 |
| | TD Offset, compensation of TD's 3-15 |
| 3.4.5 | Automatic Tracking using Latitude/Longitude 3-16 |
| | Compensation of Latitude Longitude 3-17 |
| | Complementary Latitude Longitude Position 3-17 |
| 3.4.6 | Instant Memory 3-20 |
| 3.4.7 | Course Computer Operation/Waypoints 3-20 |
| 3.4.8 | Waypoint Programming. 3-23 |
| 3.4.8.1 | Store Waypoints-Recall Waypoints. 3-23 |
| 3.4.8.6 | Steering the course to a waypoint 3-25 |
| | Compensation for Magnetic Variation 3-27 |
| 3.4.9 | Calculate Lat-Long for two TD's 3-28 |
| 3.4.10 | Automatic Waypoint Selection 3-29 |
| 3.4.11 | Setting Alarm Limits, Anchor Watch. 3-31 |
| | Arrival Alarm, Off-Course Alarm |
| 3.5 | Test Mode Operation 3-33 |
| 3.5.1 | Cancel Station Blinks 3-32 |
| 3.5.3 | Signal Analysis 3-34 |
| 3.6 | Skywave Operation 3-37 |
| 3.7 | Manual Assisted Cycle Select 3-43 |
| 3.8 | Special Test Functions. 3-45 |
| 3.9 | Manual Change of Cycle Tracking 3-45 |
| 3.10 | Interference Analysis 3-47 |

ILLUSTRATIONS

| <u>Figure</u> | <u>Page</u> |
|---------------|---|
| 1 | Typical Loran C Chain Configuration 1-6 |
| 2 | Sample Plots 1-7 |
| 3 | Baseline Extension 1-11 |
| 4 | Mounting Dimensions 2-0 |
| 5 | Typical Installation Wiring 2-2 |
| 6 | Antenna Coupler/Coupler Mounting. 2-6 |
| 7 | DC Power Plug Wiring 2-7 |
| 8 | Controls and Indicators 3-3 |
| 9A | Status Alarm Indicators 3-7 |
| 9B | Unuseable Complementary Lat/Long Position 3-18 |
| 10A | Typical ComPuNav Operation 3-21 |
| 11 | Route Plan for Automatic Waypoint Sequencing 3-30 |
| 12 | Sample Digital Readouts 3-35 |

APPLICABLE LORAN-C CHAINS

| GRI | M/S | STATION | CHAIN | CODING DELAY |
|------|-----------------------|--|------------------------|--|
| 4990 | M X Y | JOHNSTON IS UPOLO PT, HAWAII KURE IS, HAWAII | CENTRAL PACIFIC | 11,000 μ sec 29,000 μ sec |
| 5990 | M X Y Z | WILLIAMS LAKE, BC SHOAL COVE, AK GEORGE, WA PORT HARDY | CANADIAN WEST COAST | 11,000 μ sec 27,000 μ sec 41,000 μ sec |
| 7930 | M W X | FOX HARBOR, CANADA CAPE RACE, NEWFOUNDLAND ANGISSQ, GREENLAND | LABRADOR SEA | 11,000 μ sec 26,000 μ sec |
| 7960 | M X Y | TOK, AK NARROW CAPE, AK SHAOL COVE, AK | GULF OF ALASKA | 11,000 μ sec 26,000 μ sec |
| 7970 | M X W Y Z | EJDE, FAROE ISLANDS BO, NORWAY SYLT, GERMANY SANDUR, ICELAND JAN MAYEN, NORWAY | NORWEGIAN SEA | 11,000 μ sec 26,000 μ sec 46,000 μ sec 60,000 μ sec |
| 7980 | M W X Y Z | MALONE, FL GRANGEVILLE, LA RAYMONDVILLE, TX JUPITER, FL CAROLINA BEACH, NC | SOUT.EAST U.S. | 11,000 μ sec 25,000 μ sec 43,000 μ sec 59,000 μ sec |

APPLICABLE LORAN-C CHAINS (cont)

| GRI | M/S | STATION | CHAIN | CODING DELAY |
|------|-----------------------|---|----------------------|--|
| 7990 | M X Y Z | SIMERI CRICHI, ITALY LAMPEDUSA, ITALY KARGADARUM, TURKEY ESTARTIT, SPAIN | MEDITERRANEAN SEA | 11,000 μ sec 29,000 μ sec 47,000 μ sec |
| 8970 | M W X Y | DANA, IN MALONE, FL SENECA, NY BAUDETTE, MN | GREAT LAKES | 11,000 μ sec 28,000 μ sec 44,000 μ sec |
| 9940 | M W X Y | FALLON, NV GEORGE, WA MIDDLETOWN, CA SEARCHLIGHT, NV | U.S. WEST COAST | 11,000 μ sec 27,000 μ sec 40,000 μ sec |
| 9960 | M W X Y Z | SENECA, NY CARIBOU, ME NANTUCKET, MA CAROLINA BEACH, NC DANA, IN | NORTHEAST U.S. | 11,000 μ sec 25,000 μ sec 39,000 μ sec 54,000 μ sec |
| 9970 | M W X Y Z | IWO JIMA, VOLCANO ISLAND MARCUS ISLAND, JAPAN HOKKAIDO, JAPAN GESASHI, JAPAN YAP ISLAND, U.S.A. TRUST | NORTHWEST PACIFIC | 11,000 μ sec 30,000 μ sec 55,000 μ sec 75,000 μ sec |

APPLICABLE LORAN-C CHAINS (cont)

| GRI | M/S | STATION | CHAIN | CODING DELAY |
|------|------------------|--|------------------------|--|
| 5930 | M X Y Z | CARIBOU, ME NANTUCKET, MA CAPE RACE, NEWFOUNDLAND FOX HARBOR LABRADOR | CANADIAN EAST COAST | 11,000 μ sec 25,000 μ sec 38,000 μ sec |
| 9990 | M X Y Z | ST PAUL PRIBILOFF IS. AK ATTU, AK PORT CLARENCE, AK NARROW CAPE, AK | NORTH PACIFIC | 11,000 μ sec 29,000 μ sec 43,000 μ sec |
| 5000 | M X Y | SAKHALIN KAMCHATKIY VLADIVOSTOCK | | 11,000 μ sec 30,000 μ sec |
| 5970 | | NOT AVAILABLE AT PRINTING | KOREA | |
| 9980 | M W X | SANDUR, ICELAND ANGISSQ GREENLAND EDJE, FAEROE IS. DENMARK | ICELANDIC | 11,000 μ sec 30,000 μ sec |

GLOSSARY OF TERMS

A partial list of terms used with Loran C is presented herein. Additional information can be obtained from the sources referenced in this manual.

Accuracy. Absolute position accuracy as opposed to repeatable accuracy.

Acquisition. (or search) is the process of establishing the approximate location in time of the master and each of the selected secondaries with sufficient accuracy to permit subsequent settling and tracking.

Additional Secondary Factors ASF. Factors accounting for variations in Loran signal velocity caused by changes in the conductivity of the earth's surface.

Antenna. A device that converts electromagnetic waves to electrical signals.

Antenna Coupler. A device that converts and pre-processes the electrical output of the antenna to the signal level and impedance necessary to drive the receiver.

Baseline. A projection of the great circle line joining the Master and Secondary stations.

Baseline Extension. An extension of the Baseline formed by projecting the Baseline through the Master and Secondary stations in either direction.

Blink. A Loran system alarm warning the operator of technical problems or faulty timing at any of the Loran transmitters.

Chain. A group of Loran C transmitting stations identified by a specific GRI.

Coding Delay. The difference in time of transmission between the Master and secondary station.

ComPuNav CPN. The automatic computation of Cross-track-error, distance-to-go (RANGE) and time-to-go to a Waypoint (WP) which is presented on the Loran C receiver displays.

Conductivity. The electrical properties of the earth's surface which affects the speed at which loran signals travel over ground paths. See ASF Additional Secondary Factors.

Crossing Angle. The angle-from 0 to 90 degrees- at which the two Lines of Position (LOP's) intersect.

Cross-Rate/Cross-Chain Interference. Loran signal interference crossed by signals from another chain.

Cross Track Error XTE. The computed off-course deviation (to left or right) from the course between the point of origin (PO) and the desired destination or waypoint.

Cycle Slip. Failure of the receiver to maintain synchronization and alignment of the phase code of the Loran C pulses which can cause time difference measurement errors in multiples of 10 microseconds.

Desired Destination-DD. A Waypoint - a position or location to which the Loran C user wishes to travel consisting of the intersection of two Lines of Position (LOP's).

Dual Rated Station. A loran station which operates in two loran chains.

Fully Automatic Loran Receiver. Equipment that, after the initial selection of the chain, automatically acquires the master and secondaries, settles, cycle selects, tracks the signals, and periodically updates the lines of position without manual manipulation of knobs or panel controls.

Gradient. The Time Difference separation between Lines of Position, (specified in microseconds). Gradients vary accordingly with selection of Master-Secondary pairs.

GRI-Group Repetition Interval. The time coded delay a 4 digit number used to identify the group of transmitter stations in a specified Loran C Chain.

Ground Wave. The path along the curvature of the earth which the Loran C signals follow.

In-Band Noise. Any electrical interference which occurs within the Loran C band of 90 KHz to 110 KHz.

Ionosphere. An atmospheric layer above the earth's surface, varying in altitude between 25 and 250 miles, which reflects radio waves.

Land Path Variable. The factor used to compensate for the difference in Loran C signal velocity over seawater, flat land, mountains and various terrain.

Line of Position-LOP. A graphical plot of all observation points having the same constant measured time difference (TD) between the master station and the secondary stations. The graphical plot forms the line of position printed on the Loran C Chart.

Loran C System. A long range navigation system that operates at an assigned frequency of 100 KHz. It utilizes pulsed signals from widely spaced transmitting stations and measures the difference in arrival times of the pulses to determine position relative to the transmitting stations.

Loran Fix. The position or location established by the intersection of two LOP's.

Maximum Operating Range. The maximum distance within the prime coverage area where Loran reception is possible within a specified accuracy and a specified signal to noise ratio.

M-Master Station. The controlling station of the Loran C Chain which transmits the reference timing signals.

Minimum Operating Range. The range, 5 to 20 miles, wherein the receiver may not track the desired cycle, thus causing displayed errors in increments of 10 microseconds.

Notch Filters. A narrow band noise filter used to tune out interference near the Loran C Band.

Point of Origin. A starting point of a navigational operation. The position or location at the intersection of two LOP's, indicated by the receiver at the instant the ComPuNav (CPN) mode is initialized.

Receiver. A device that processes Loran signals from the antenna coupler and measures the difference in arrival time of the selected signals representing the measured parameter.

Repeatability. The ability to return to a particular position or location using Loran C navigation aids.

Secondary Station. Any transmitting station in the Chain that is not the master station. Secondaries are usually designated W, X, Y and Z and referenced to the master M station GRI.

Settle. Is the process of automatically aligning the phase codes, identifying the correct cycle zero-crossing, establishing ground-wave tracking, and indicating that time differences are valid.

Signal to Noise Ratio. The ratio of Loran signal strength, at the TIMING point, to the in-band noise.

Skywave. A Loran C signal transmission which is reflected by the ionosphere. These signals are less accurate than the ground wave signals.

Time Difference-TD. Time difference is the time of arrival of the secondary signal minus the time of arrival of the master signal, as observed on a single receiver.

Tracking. Is the process of maintaining the synchronization of the receiver with the selected signals.

Waypoint. A destination, a position or location, to which the Loran C user wishes to travel, consisting of the intersection of two Lines of Position (LOP's).

SECTION 1.0 INTRODUCTION

This instruction book provides the operator with a description of the operating capabilities of the Model 787 Loran C Receiver and how to use it as a navigation aid. Before you install your Model 787, it is recommended that you read the instructions carefully and thoroughly to become familiar with the installation requirements and the operating procedures. This fundamental knowledge is essential for proper operation.

CAUTION

Your new SI-TEX Model 787 Loran C Receiver is intended for use as a Navigation Aid. Navigational information derived using your Model 787 can be accurate, however, the information should always be double-checked using other means available to determine the accuracy and reliability of the data.

Your Model 787 Receiver must be used in conjunction with certified nautical charts containing LORAN-C information. Nautical chart catalogs are available from local chart dealers who can help you determine which charts are required for your area of interest. Charts may be obtained from local chart dealers or they can be obtained by mail from the following sources.

National Ocean Survey
Distribution Division (C-44)
Riverdale, MD 20804
301-436-6990

Chart catalogs are also available from N.O.S. at no charge. The catalogs show which charts are available and whether they contain Loran C data for U.S. Coastal waters.

Canadian Hydrographic Services issues Loran C chart catalogs and charts for the Canadian East Coast, West Coast and Great Lakes areas and can be obtained from:

Canadian Hydrographic Services
Department of Fisheries and Environment
Ottawa, Ontario K1A 0E6, Canada

For other areas outside of U.S. Coastal waters, (i.e., Mexican waters and other areas of the world) chart catalogs and charts can be obtained from:

Defense Mapping Agency
Topographic Center, ATTN: DDCP
6500 Brookes Lane
Washington D.C. 20315

1.1 PRECAUTIONS WHEN USING LORAN C CHARTS

First editions of Loran C charts are based on predicted coverage rather than on actual field measurements. In most cases the predicted data is quite accurate. However, in a few instances, there may be some large errors. The user of Loran C navigation equipment should know about these problems. Loran C coverage for subsequent chart editions have to be verified by actual measurements, but the user is advised to check regularly to determine navigational changes or other problems.

The U.S. Coast Guard provides information related to Loran C and it is available from the local District offices. Write or telephone:

Loran C Education and Information
U.S. Coast Guard Headquarters (G-NRN/TP14)
Washington D.C. 20593 Telephone 202-472-5857

Owners and operators of Loran C equipment are advised to obtain a copy of the "LORAN-C USERS HANDBOOK" COMDTINST M16562.3.

The handbook provides information to the user concerning the Loran C system, the use of Loran C receivers, interference problems, nautical charts and tables and list of other sources of information useful to the navigator.

1.2 LORAN C NAVIGATION

Loran C is a valuable aid to navigation, however, it should always be used in conjunction with other navigation aids available to the mariner. The compass provides the indications for direction of travel to a destination and should always be used for navigation. Buoys, lights, landmarks, depth soundings, radar, range markers, radio direction finding and celestial observations provide additional means to establish your position and to verify information provided by your navigational instruments.

Loran C and computerized navigation systems can provide accurate navigational data. It can save travel time, increase safety and reduce cost. Various factors influence the accuracy of the system. Each component in the system contributes some error because of accuracy limitations. How you operate your navigational equipment and plot your position using charts is important. This also contributes some inaccuracies to the navigation system. The prudent mariner should never rely on any one system.

1.3 WHAT IS LORAN

LORAN is an acronym meaning Long Range Aid to Navigation. It is an electronic navigation system using shore-based radio transmitters and shipboard receivers. Loran provides the means to allow mariners to determine their position or location at sea.

Using Loran C does not require any special technical skill or knowledge. Although the Loran C system is very complex, it is not necessary to understand the system completely to use it as a navigation aid. However, a more extensive knowledge will provide more effective use of the system.

1.4 LORAN C SYSTEM

The Loran C system is a pulsed low frequency (100 KHz) hyperbolic radio-navigational system that utilizes a chain or group of shore-based transmitting stations. Each chain or group is comprised of a Master (M) transmitting station and two or more Secondary transmitting stations. The stations of the Loran C Chain transmit groups of pulses at specified Group Repetition Intervals (GRI). This GRI is used to identify the Loran C Chain for a designated area of coverage.

- 1.4.1 GRI Designation. The Group Repetition Interval (GRI) is specified in microseconds and the GRI for each chain is selected such, that it contains a sufficient time interval for transmission of pulse groups from each station, plus, allowing time between each pulse group, so that the signals from two or more stations cannot overlap (in time) anywhere in the coverage area.

The Group Repetition Interval rate structure used for Loran C operation will be between 40000 microseconds and 99990 microseconds.

A Loran C GRI chain is designated by the first four (4) digits of the GRI rate. For example, 7980 designates the GRI rate for the Southeastern United States Loran C chain. The GRI's for all other areas of coverage is presented in this manual.

Each station transmits one pulse group per GRI. The Master (M) pulse group consists of eight pulses spaced 1000 microseconds apart and a ninth pulse 2000 microseconds after the eighth pulse. Each secondary station pulse group consists of eight pulses spaced 1000 microseconds apart.

The ninth pulse of the Master is used to provide identification of the Master station. Secondary stations having transmission error problems also blink by turning the first two pulses of the group off and on to activate the receiver alarm circuits.

Further information related to blink codes can be obtained from the references cited in this book.

1.4.2 LORAN C CHAIN

Each Loran C chain provides navigational data for a predetermined coverage area. Within the chain, one transmitter is designated the Master (M) station and provides the basis for identification and synchronization of the Loran C chain. The other transmitters are designated as Secondary stations and for convenience are generally identified as station W, X, Y and Z and are referenced to the specific Master station. All pulsed signals transmitted by Secondary stations are synchronously timed with the Master station. These synchronized pulses are transmitted at precise time intervals, and the intervals are adjusted such that signals transmitted by each secondary will arrive at the receiver at a different time. The Loran C receiver is used to process the pulsed signals and to measure the difference in the time-of-arrival, that is, the slight difference in time required for the transmitted pulses to reach the shipboard receiver from each of the transmitters. This difference in time is referred to as Time Difference (TD). TD's are measured in microseconds (millionths of a second). Loran C derives its accuracy from the precise measurement of the TD's in microseconds and from the inherent stability of low frequency signal propagation.

The following examples will provide the user with a better view of the system.

The Loran C hyperbolic navigation system operates on the principle that the measurement of the difference in time-of-arrival of signals from two stations, when observed at a specific point in the coverage area, is a measure of the difference in distance from the observation point to the two stations. Thus, the Time/Distance relationship is established. Navigation using Loran C requires the use of the Master (M) station and any two Secondary stations W, X, Y or Z of the same Loran C chain, to measure the Time Difference/Distance Difference from the observation point to the two stations.

Generally, the Loran C receiver must be programmed to recognize and identify the Master station GR1 of the Loran C chain. Once programmed, the receiver can measure the TD's and present them on a digital readout display. Figure 1 illustrates a typical Loran C chain configuration. The Master (M) and Secondaries W, X, Y and Z are separated by several hundred miles.




Figure 1. Typical Loran C Chain Configuration

In Figure 2, the Master (M) and two Secondaries W and X are used for an example. The Master (M) station transmits synchronized Loran C pulses at precise time intervals. The receiver, located at an observation point, synchronizes on these pulses. At precise time intervals later (after the Master station transmission), each Secondary station, W and X, transmit synchronized pulses in timed sequence. The receiver at the observation point measures the slight TD's required for each of the pulses to reach the observation point from the transmitter stations. Your Loran C receiver presents each of the measured Time Differences on the display.

In the example of Figure 2, the TD measured from station W to the observation point is designated TDW and the TD measured from station X is designated TDX. A graphical plot (a line drawn through the locus of all points) of all observation points, having the same constant measured TD (i.e., distance difference) between M and W, the two stations, is a hyperbola and this line is called a Line Of Position LOP-W relative to stations M and W. From the example of Figure 2 it can be seen that the observation point (position) is located somewhere along LOP-W plotted on the chart.




Figure 2 Sample Plots
1-7

Likewise, from the example of Figure 2, a graphical plot of the same constant measured time difference between M and X forms a Line of Position LOP-X relative to stations M and X, and it can be seen that the observation point is also located somewhere along LOP-X. These Lines of Position are plotted on a Loran C nautical chart and used as navigation aids to determine your position. The intersection or crossing point of the two LOP's is the observation point or position where the receiver is located on a boat.

Since the Time Differences TD's are measured in microseconds, the graphical lines forming the LOP's are designated in microseconds. Thus, a LOP is designated by a number, in microseconds, having the same constant measured time difference. The LOP's are plotted on Loran C nautical charts for the designated areas of coverage of each Loran C chain. The LOP numbers displayed on the receiver are compared with the same numbers on the nautical chart and the intersection of the LOP's on the chart represent your position or location in the coverage area.

The operator of a Loran C receiver can navigate to and from positions located on the Loran C charts, using the Lines of Position indicated by the receiver to determine the course to a waypoint or destinations. Arrival at a destination is indicated when the LOP's displayed on the receiver correspond to the LOP's printed on the chart.

The example presented herein used secondary stations W and X to demonstrate the use of the Loran C system. Any two secondaries can be used in combination to provide the same navigational data and any other secondary can be used to verify the data when used in conjunction with either or both of the other secondaries.

1.5 USING THE LORAN C SYSTEM FOR NAVIGATION

Use of the Loran C system begins at the receiver. The user/operator must be familiar with all of the various factors which influence and affect the accuracy when establishing position. Overall accuracy is the result of individual accuracies such as the selection of the best secondary stations, plotting a loran fix indicated by the unit and interpolation between LOP's using the charts.

- 1.5.1 Selecting the Chain. The first step is to decide which chain to use and which secondaries to use. In certain areas, only one chain is available. In other areas, two chains provide overlapping coverage. You must select the chain which will provide the best coverage for your area of operation.
- 1.5.2 Selecting the Secondaries. The second step is to decide which secondary stations to use. The two secondary stations should be chosen to provide the greatest navigational accuracy. The chains have been designed to give two LOP fixes for all of the coverage area. You can use two secondaries in one section of the coverage area and then use two different secondaries in another section of the coverage area. Or, you can use any of the secondaries to cross check the accuracy of the fix provided by the two chosen secondaries. The most important factors to consider when selecting secondaries are (1) the crossing angle of the LOP's and (2) the gradient between the secondary LOP's. The operator should choose the best combination of crossing angle and gradient to obtain the desired accuracy.

LOP CROSSING ANGLES

Choose the secondary LOP's that provide the greatest crossing angle. A crossing angle of 90 degrees would be ideal, however, this is almost never possible. Therefore, choose the best possible crossing angle. Whenever possible, do not choose LOP's which provide a crossing angle of less than 30 degrees. Choosing

LOP's less than 30 degrees does not present a measurement problem. Your receiver will measure all Time Differences with equal accuracy. The problems occur when the LOP's are used for plotting a fix and when interpolating between LOP's. It becomes difficult to establish a position on the chart when the two LOP's cross at small angles and present nearly parallel lines.

LOP GRADIENT

Choose the secondary LOP's so that the gradient, or time difference separation, Figure 3, between the LOP's represents the smallest distance per microsecond. In certain locations, a gradient of 10 microseconds between the LOP's on the chart may represent one mile distance, where as, a gradient of 10 microseconds between the LOP's of another secondary may represent five miles distance, or more, depending on the location and the distance from the Master-Secondary pair.

1.6 BASELINE EXTENSION See Figure 3

Do not use the Master-Secondary pair in the vicinity of the Baseline Extensions. When operating in these areas, the microsecond gradients change rapidly because of the hyperbolic nature of the LOP's. There is great possibility of introducing large errors in position because you may not be able to determine which side of the baseline you are on. Baseline Extensions areas are marked on the Loran C charts. When encountering these conditions, choose an alternate secondary station and avoid the use of that secondary station in the Baseline Extension area.

1.7 ASF, LANDPATH DELAY OR GRIDWARP.

Another factor to consider when using the Loran C navigation systems is the Additional Secondary Factors (ASF) or land effect, which causes a small difference in the Time Difference readings on the receiver compared to the Lines of Position (LOP's) plotted on the charts. The LOP's printed on the charts are those which you would obtain on the displays if the Loran signals traveled over an all-seawater path. However, this is not the case. The Loran stations are usually located inland and the signals must travel some distance over a land path. This land effect causes the Loran signals to travel slower, thus, requiring a slightly

longer time difference to reach the receiver. Loran C charts contain adjustment factors for this ASF however an average value was used for making the charts. In some locations there will be a difference, since ASF can vary with location. Future charts are expected to contain more accurate information using varying values for ASF corrections.




Figure 3. Baseline Extension

Converting Time Difference Microseconds to Nautical Miles.

Some nautical charts contain mileage reference scales. In most cases nautical charts use Mercator projection which generally means that the LATITUDE side of the chart is drawn to a scale of one (1) nautical mile (6000 feet) per MINUTE OF LATITUDE. Either of the above reference can be used to determine the relationship between nautical miles and microseconds for a specific area. The same conversion does not apply for all areas of the loran C chain because the gradient or spacing between the loran lines of position continue to increase as the distance from the loran stations increases. For greatest accuracy the conversion should be made about every 5 or 10 miles or 5 to 10 minutes of Latitude.

"DO NOT USE THE LONGITUDE SCALE"

Procedure:

1. Using a pair of dividers or a ruler, measure the spacing or gradient between two lines of position on the chart. Determine the number of microseconds between LOP's.
2. Transfer this same measurement to the Latitude scale or mileage reference scale. Determine the number of miles for this measurement, 1 Minute of Latitude = 1 NM = 6000 FEET.

3. Example of conversion.

If the measurement of the LOP gradient produced 10 microseconds equal to 2.0 nautical miles on the Latitude scale,

10 microseconds = 2.0NM = 12000 feet

Divide all numbers by 100 to get

0.1 microsecond = 0.02 NM = 120 feet

Note that if the nautical mile measurement was 4.0NM then the distance in feet would be doubled, 240 feet. And if the measurement was 1.0NM, then the distance would be one-half or 60 feet per 0.1 microsecond.

.9 ACCURACY OF LORAN

Absolute Accuracy. This is the ability to determine your geographic position using the TIME DIFFERENCES or LATITUDE-LONGITUDE measured by your Loran C receiver. The absolute accuracy of Loran C varies from 0.1 to 0.25 nautical miles (using Loran C nautical charts), depending on your location in the coverage area. Absolute accuracy should be used to know your position if you were visiting a new area or crossing an ocean.

Repeatable Accuracy. This is the ability to return to a position where you have been before and have recorded the TIME DIFFERENCE numbers or LATITUDE-LONGITUDE coordinates. By using the Loran C numbers for a particular spot or location, you can obtain the greatest accuracy from Loran C. The repeatable accuracy also depends on your location in the coverage area.

Repeatable Accuracy can be more important and useful than absolute accuracy. You can take advantage of the stability of the Loran C system because the time difference numbers vary only slightly from day to day, for the same location. If you know the location of shoals, sand bars, bottom obstructions etc., you can easily avoid these areas. If you know several good fishing locations, you can return to the same spot with better accuracy.

The user is advised to obtain a copy of "Loran C Correction Tables" to determine the absolute accuracy of Loran for your specific area of coverage.

LORAN C ASF CORRECTION TABLES

| <u>Pub No.</u> | <u>Chain/Rate</u> |
|-----------------|--------------------------|
| LC PUB 2211100C | Canadian East Coast/5930 |
| LC PUB 2211200C | Northeast U.S./9960 |
| LC PUB 2211300C | Great Lakes/8970 |
| LC PUB 2211400C | Southeast U.S./7980 |
| LC PUB 2212100C | U.S. West Coast/9940 |
| LC PUB 2212200C | Canadian West Coast/5990 |
| LC PUB 2212300C | Gulf of Alaska/7960 |
| LC PUB 2212400C | North Pacific/9990 |

Each publication covers an entire chain and may be obtained from:

Defense Mapping Agency
Office of Distribution Services
Attn: DDCP
Washington, DC 20315

COORDINATE CONVERSION

Coordinate conversion from Time Differences to Latitude and Longitude can provide many advantages to the user. Where Time Differences can provide an accurate geographic position using Loran C charts, Latitude-Longitude can provide accurate geographic position using any marine chart containing Latitude-Longitude Coordinates. Interpolation using the charts is made easier, since Latitude-Longitude coordinates are more equally spaced, having a consistent gradient. The gradient refers to the number of microseconds change between TD Lines of Position or the number of Degrees/minutes change between Latitude-Longitude coordinates.

Using Latitude-Longitude for navigation provides the most direct course to a destination because it is not influenced by the curving Lines of Position produced by the TD's. When traveling short distances, the curving LOP's produce negligible effects on the distance traveled, except in areas close to a station which should be avoided.

The coordinate converter system uses a mathematical equation that is representative of the curvature of the earth surface and the propagation of Loran C signals over an all seawater path for calculating Latitude and Longitude. It does not, however, account for propagation anomalies, that is, differences in the time of arrival of Loran C signals, caused by the signals traveling over long land paths, the general physical characteristics of the land mass, large building structures, bridges and over the seawater path. These propagation anomalies generally increase the signal propagation time because signals travel slower over land masses.

Since most Loran C transmitting stations are located inland, the signals will usually travel over land for some portion of their travel. And, in some locations in the coverage area, the signals will travel over much longer land paths. This results in computations that differ from that obtained for signals traveling

over all seawater paths. These propagation anomalies are known as Secondary Phase Factor (SF) and Additional Secondary Phase Factor (ASF). Secondary Phase Factor is the predictable effect which change the Time Differences of loran signals traveling over a seawater path. The Secondary Phase Factors are considered in the calculations, however, the calculations will not be accurate when operating close to the station and at great distances from the station. The Additional Secondary Phase Factor (ASF) is the unpredictable effect which changes the Time Differences of loran signals traveling over land masses, around hills, mountains and structures and then over a seawater path. The Additional Secondary Phase Factors are not considered in the calculation because they can vary from location to location.

Since the receiver coordinate conversion calculations do not include the correction factors for the ASF, the positions you plot will not be as accurate as expected, unless compensation is included in the calculations. The Coordinate Converter system provides for correction of the ASF propagation effects by use of correction calculations, called COMPENSATION, which can be entered into the calculation. The Compensation is a quantity which consists of 1) Direction, which indicates addition to or subtraction from, the Latitude and Longitude calculated from the TD's and 2) Magnitude, which represents the numerical value of the compensation which must be added to or subtracted from the calculated Latitude and Longitude. Compensation is described in subsequent sections.




Figure 4. Mounting Dimensions


SECTION 2.0 INSTALLATION

2.1 RECEIVER MOUNTING LOCATION

Your unit is designed for easy installation, however, the following recommendations are important and should be followed to obtain the most effective use of your equipment:

1. Select a convenient location for the Receiver unit which will provide access for operation and for observing the display information.
2. Install the receiver unit in a location that will provide protection from extreme weather conditions such as direct sea spray, rain and other extreme weather conditions (see Specifications). Water damage is excluded from warranty provisions.
3. Route the Power cable and antenna coupler cable as far as possible from all other electrical cables and electrical equipment that may radiate electrical noise interference.
4. Before finalizing the mounting location for the receiver and antenna coupler, operate the unit for some period of time. Observe any interference or interaction that may occur when the vessel is running and when other equipment is operated.

2.1.1 Receiver Installation. Figure 4 Mounting Dimensions, illustrates the standard table-top mounting configuration with the trunnion mounting located on the bottom of the receiver. For bulkhead or overhead mounting, the trunnion must be repositioned at the top of the receiver.



After selecting the mounting location and position, prepare the mounting foundation as follows:

1. See Figure 4 for mounting hole dimensions.
2. The trunnion mount can be removed and used as a template for locating the mounting holes. To remove the trunnion from the unit remove the two mounting knobs on the side of the receiver. Move the receiver forward to disengage it from the mounting.
3. Use the trunnion mount to locate the mounting holes.
4. After the mounting surface has been prepared, mount the trunnion to the table top, bulkhead or overhead using four screws. Tighten all screws securely.
5. Allow adequate clearance around the receiver to provide for installation and connection of cables and ground cables.
6. Observe all precautions described for mounting location.

2.1.2 Antenna/Antenna Coupler Location. Ideally, the antenna and antenna coupler should be mounted on the highest part of the vessel. This is not always possible, however, the antenna must not be located under or within a mass of metal rigging. The metal rigging can cause blind spots within the reception area whenever the rigging is between the antenna and the transmitting station.

1. Choose a location clear of all metal rigging.
2. The antenna coupler should be mounted at least 3 feet or more from the receiver (and the remote display unit, if used).

- 3 Recommended locations for Antenna and Coupler.
Sail Boats-MIZZEN MAST, HORIZONTAL SPREADER,
top of stern rail. Insulated backstay can also be
used as an antenna.
Center Console boats-Mount on gunwale or at
top of console.
Power Boats-Mount on flying bridge, cabin
top or side.
4. The antenna should be mounted in the vertical position
and in a location that is accessible for servicing.
5. Locate the Loran antenna as far as possible from all
other antennas, particularly, medium and high frequency
transmitting antennas. 6 feet horizontal distance and/or
3 feet vertical distance is recommended.
6. The signal quality should be examined at various loca-
tions to choose the best location for the antenna.
See Operation Section - TEST MODE

2.1.2.1 Antenna Coupler. The Antenna Coupler is provided with 49 feet
of coaxial cable and connector attached. If required for
installation, the cable may be lengthened to a maximum of 150
feet or shortened to 10 feet minimum. Use type RG58A/U cable.
Determine the proper length of cable before finalizing site selection.
See Figure 5 for cable-to-plug connection requirements.

2.1.2.2 Antenna Selection. The antenna is not provided. The antenna
coupler has been designed and tested to use a standard 7 to 8
foot fiberglass whip antenna. The top of the coupler is designed
with a threaded insert (3/8" - 24 thread) to provide for direct
mounting of the whip antenna to the coupler.
A long wire antenna can be used (15 feet minimum) in place of the
standard whip antenna for emergency use only. Also, the antenna can
be mounted remotely from the coupler using insulated wire to extend
the connection to the antenna.

CAUTION

Do not use a stainless steel whip antenna. The
excessive weight and size may cause physical
damage to the coupler housing.

- 2.1.2.3 Antenna Coupler Mounting. The antenna coupler is designed to be mounted, (Figure 6) on an extension pole or swivel mount (not supplied). The lower section of the coupler housing is designed with a threaded mounting (1" - 14 thread) to mate with standard fiberglass extension poles or swivel mounts.

If a Laydown base mount is used, caulking or sealing compound must be applied around the base of the coupler and the cable entrance to prevent water leakage when coupler is in horizontal position.

As an alternative, the antenna coupler may be strapped to a vertical stanchion using stainless steel house clamps (not supplied).

2.2 POWER REQUIREMENTS AND RF GROUNDING

CAUTION Use NEGATIVE GROUND ONLY

Operating voltage range is from 11 to 15 Vdc only. No changes or adjustments are required for operation within this voltage range. A battery or power source capable of providing a continuous current of 1.0 amp at 11 to 15 Vdc is required. The proximity of the power source is not important because of low power consumption. When the operating voltage exceeds 15 Vdc, the unit will shut down automatically. It will not turn ON again until voltage is returned for proper voltage.

- 2.2.1 Power Connection. Check and verify the power source voltage and polarity before connection to the receiver unit. A three terminal connector is supplied for power connection. Assemble the connector to the power cable before connecting the cable to the power source.

CAUTION

Reverse polarity can damage the receiver unit. Reverse polarity damage is excluded from the warranty provisions.

Do not use an external switch or circuit breaker to energize the Loran unit.






Figure 6. Antenna Coupler Mounting



Before connecting supply voltage to the receiver, ensure that the polarity of the DC plug is correct.



81-210

Figure 7. DC Power Plug Wiring

Observe the terminal numbers on the body of the connector and

1. Connect the positive (+) wire to connector pin 1.
2. Connect the negative (-) wire to connector pin 2.
3. Assemble the connector to the housing using the screws provided and tighten securely.
4. Exercise caution and remove all excess solder to prevent shorting between terminals and the connector housing.
5. Connect the other end of power cable directly to the battery, if possible.
6. Recheck and verify the voltage polarity before connecting the receiver.
7. Observe the keyway on the power connector when connecting to the receiver. Do not force the connection.

2.2.2

Internal Battery Power. The receiver unit contains a small battery to enable the receiver memory system to store programmed information. The batteries are rechargeable and are continuously under charge only when the Power switch is ON. If the receiver unit is inactive for a long period of time, the batteries may become discharged. The receiver must be operated ON to recharge the batteries.

If the batteries become discharged, the data stored in the memory system will be lost and the receiver will require re-initialization in accordance with specified operating procedure when the unit is again operated ON.

NOTE

The internal batteries are soldered into the unit. If replacement is necessary, it should be done only by qualified technicians. Excessive damage can occur if they are improperly connected.

2.2.3 Radio Frequency (RF) Grounding.

NOTICE

This Loran unit requires a good RF Ground for proper operation. Failure to install a good ground will result in poor or erratic operation of the Loran and the course computer.

A wing-nut is provided on the rear panel of the receiver unit for connection of the RF ground. Use #10 AWG standard wire for connecting the receiver to the vessel's ground system. Connect ground wire directly to engine block or common seawater grounding plate. The battery negative terminal is NOT a good ground.

Certain types of boats require special grounding systems. Before finalizing the installation, be sure the grounding is effective. Grounding to the engine block may be sufficient, however, in some cases, additional grounding systems must be provided by the user.

- 2.2.4 Fuses and Fuseholders. Fuses are installed to protect the equipment from overload conditions. A blown fuse usually indicates a trouble condition in the equipment. If a fuse blows continuously, have the equipment checked and repaired by a qualified technician.

CAUTION

Do not install a higher rated fuse. Excessive damage may result and your warranty will become invalid.

- 2.2.4.1 Fuse Replacement. Fuses and fuseholders are located inside the unit on the subassembly. To change fuses:

1. Remove the screws that mount the rear cover.
2. Carefully pull to withdraw the rear panel from the unit.

NOTE: Cables are attached to the rear panel.

Exercise caution to prevent damage.

3. Replace blown fuses with 2.0 amp in (+) line and 5.0 amp in (-) line.
4. Carefully replace the rear panel onto the unit.
Be sure that cables are not broken or disconnected.
5. Replace the rear panel retaining screws.
6. Connect power cable, antenna cable and ground.
7. Operate the unit and check for proper operation.

2.5 ALTERNATOR-GENERATOR INTERFERENCE REDUCTION

Alternators and generators are the most common source of electrical interference to loran operation. In almost all cases, the engine alternator or generator will require some type of filter for noise reduction. The noise may be conducted over power cables or it may be radiated by the boats wiring system whereby it can be received at the antenna system.

SI-TEX recommends installation of a 20,000 microfarad capacitor as the best available noise filter for alternators and generators. This filter must be connected directly at the alternator terminals to be effective.

Specification for capacitor
20,000 μ FD, -20%, + 50%, 50WVDC, TEMP. 35°C

SEE INTERFERENCE SECTION FOR MORE INFORMATION ABOUT INTERFERENCE
AND NOISE REDUCTION

SECTION 3.0 OPERATION

3.1 GENERAL

This section provides instruction for operation of your Loran C Receiver.

Before operating the unit, be sure that it is properly installed in accordance with the instructions of Section 2, Installation.

3.2 DESCRIPTION OF CONTROLS AND INDICATORS

All controls, switches, displays and indicators required for operation are located on the front panel. See Figure 8.

The controls consist of keyboard type push button switches, which are referred to as keys throughout this book. Operation of the controls is performed by pressing the key(s). Each time a key is pressed, the operator will hear a tone or beep to indicate that an operation has been performed. The tone is useful to indicate when a key has been pressed more than one time, so that the operator will be aware that an operation has been performed that may or may not be desirable or required.


- 3.2.1 POWER ON-POWER OFF-LAMP DIMMER. The ON Key is used to turn power ON and OFF and to dim the backlights in the displays. Do not use external switches or circuit breakers to turn unit on or off. After Power ON, press the ON Key once to brighten or dim the backlights for night time viewing. To turn power OFF, press and hold the ON Key for at least 5 seconds until display and lights extinguish.

CAUTION


Once power is OFF, the unit must remain off for 5 seconds or more.





- 3.2.2 OPERATING MODE INDICATORS. The operating modes are marked on the front panel in the lower part of the display window. They are divided into two groups by two white BAR shaped lines drawn below the display window.

The five operating modes at the left side are Loran ID tracking and Latitude-Longitude tracking modes. They provide Time Difference position and Latitude-Longitude position information. The five operating modes at the right side are (CPN) ComPuNav Course Computer modes and they provide the course and steering information.



When the Power  Key is pressed, a small BAR shaped indicator will appear in the display directly above one of the operating modes printed on the panel. The position of the small BAR indicates the mode of operation. The operating mode can be changed using the Mode Control and the Operating Mode Selector Keys.

3.2.3 OPERATING MODE SELECTOR KEYS.

The four push button keys located at the lower right side of the panel are used to select the operating mode. The BAR  shaped key is used to select one of the two groups of operating conditions, either position information or CPN Course Computer information. Each time the BAR Key is pressed, the BAR indicator will move back and forth between the CPN group and the position information group. The BAR indicator will always return to the same operating mode which was selected by the last press of the BAR Key. This is useful to move between position information and course information while traveling a course.

The two ARROW shaped keys  and  are used to shift the BAR shaped mode indicator from one operating mode to another. Press the left  arrow Key to move the BAR indicator toward the left to select a different operating mode. Press the right  arrow Key to move the BAR indicator toward the right to select a different operating mode. These arrow keys will change the operating mode once per second within either group. The arrow keys can be pressed once or it can be held depressed for continuous shifting within either group until the desired mode is selected. Release the key when the BAR indicator is above the desired operating mode.

3.2.4 NUMBERED KEYBOARD The numbered Keyboard consists of 16 keys.

1. Numbered Keys  thru  are used to program the GRI for the Loran C Chain of operation, to program waypoints and to designate memory locations for stored waypoints.




FIGURE 8 CONTROLS AND INDICATORS

Certain keys are used to perform two different functions.

The **1/N** , **2/S** , **3/E** and **4/W** Keys are also used to designate the North or South Latitude and the East or West Longitude when programming waypoints.

2. The **ENT** is used to enter the GRI once it has been programmed and to enter the waypoint once it has been programmed.
3. The **S1** and **S2** Keys are used to change and to select information in the S1 and S2 displays, in several different operating modes. **S2** Key is also used to select and display course information in the T1, T2 and T3 course computer modes.
4. The **CL** (Clear)Key is used to cancel information that has been programmed into the displays. **CL** is also used to reinitialize the loran (reinitiate cycle select process).
CL cannot be used to clear information stored in memory.
5. **+M** Key is used to store waypoints in memory.
-R Key is used to recall stored waypoints from memory.
Number Keys are used in conjunction with **+M** and **-R** .
+M and **-R** Keys are also used for special test and display operation in various modes of operation which are described in the Operations Section.

The Proper operating mode must always be selected before using the numbered keyboard. Then, keyboard operations can be performed by pressing the required keys. Depending on the mode of operation, the position information will be displayed, course information will be displayed or programmed data will be displayed. Each time a key is pressed a tone will be heard, indicating that an operation has been performed.

3.2.5 DISPLAYS. The display contains two groups of digits to display loran or Lat-Long. position information and course information in CPN Modes. The decimal point between the 5th and 6th digits indicate the TD position to 0.1 or one-tenth of a microsecond. Colons separate Degrees and Minutes for Latitude-Longitude displays.

The S1 and S2 marked at the left side of the displays are used to identify the upper and lower displays. The S1 and S2 displays are associated with the **S1** and **S2** keys on the keyboard when

selecting or changing secondary TD's when entering waypoints and when choosing course information in CPN modes.

MEMO INDICATORS (Top left corner of display).

A MEMO number will appear in this display to show the number of an active memory or to show the number of a waypoint entered into the course computer. A small BAR above the number indicates active memory and a small BAR below the number indicates waypoint in use. When a waypoint is entered but not stored in any memory the display will be blank-no numbers.

STATUS ALARM INDICATORS are located in the center of the display to warn the operator of the operational condition of the loran receiver and the loran station transmitters. They are described in following paragraphs.

3.2.6 AUDIBLE ALARM FOR WAYPOINT ARRIVAL OFF COURSE AND ANCHOR WATCH

The loran receiver has a built in audible alarm which is activated for several conditions.

- a. The alarm will sound each time a key is pressed.
- b. If a waypoint has been entered into the course computer, the waypoint arrival alarm will sound when the boat arrives within 0.5 mile radius of the waypoint-destination. This alarm will also sound when the loran is first turned ON if you are within 0.5 miles of previously entered waypoint. The tone will sound at approximately two second intervals and will continue until cancelled by pressing the Clear Key. It will not be reactivated for the same waypoint unless the vessel leaves the 0.5 mile radius.
- c. The Off Course alarm and the Anchor Watch alarms are activated when the conditions exceed the limits preset by the user. When not preset, the limits are automatically 0.5 miles.

NOTE Always set the loran to NOR Normal position before pressing Key to cancel the alarm. Pressing will cause the loran to go into a cycle select mode if unit is set in GRI, SEL, S1, S2 Modes.

- 3.2.7 NOTCH (Interference) CONTROLS. Two (2) preset NOTCH filters are contained in the unit to reduce near-band interference. A third notch can be added if required. Internal adjustments are required to change the NOTCH frequencies. Adjustments are not described in this instruction book. Consult with your local dealer or the manufacturer for information.

3.2.8 STATUS ALARM INDICATORS. Status/Alarm indicators are provided to inform the operator of the operational status of the Loran receiver and the Loran C Chain station transmitter. Two types of status/alarm indications are used. See Figure 9.

1. The C/S and S/N indicators located in the center section of the displays are used:

To indicate the operational status of the Loran receiver.

To indicate Loran station BLINK alarms in Course Computer operation modes.

2. In addition, digits 3 and 4 in both displays are used to indicate Loran station BLINK alarms in S1, S2 and MOR modes of operation.

3.2.9 C/S and S/N STATUS/ALARMS. The status/alarms are arranged in three groups:

M group (M-CS and M-S/N) for the Master Station.


S1 group (S1-CS and S1-S/N) for the displayed secondary upper display.

S2 group (S2-CS and S2-S/N) for the displayed secondary lower display.

3.2.10 CS-CYCLE SELECT INDICATORS. The CS-Cycle Select indicators illuminate (steady-state ON) to indicate when the cycle selection process is not completed for a particular station. M-CS illuminates for the Master Station, S1-CS illuminates for the S1 Secondary station (upper display) and S2-CS illuminates for the S2 Secondary station (lower display). Settling is indicated when the CS indicators extinguish. Synchronous flashing of one or more of the CS indicators indicates receiver operational status conditions which are described in the various modes of operation. THIS MAY ALSO OCCUR because of signal propagation conditions.

3.2.11 SIGNAL/NOISE (S/N) INDICATORS. The S/N Signal to Noise indicators may illuminate (steady-state ON) periodically to indicate when the Loran signal from a particular station is deteriorating. M-S/N Master station deteriorating, S1-S/N Secondary station (upper display) deteriorating. S2-S/N Secondary station (lower display) deteriorating. Synchronous deteriorating. S2-S/N Secondary station (lower display) deteriorating. Synchronous flashing of one or more S/N indicators indicates receiver operational status conditions which are described in the various modes of operation.

LORAN STATION BLINK ALARMS



NOTES:

- C/S INDICATES CYCLE SELECT CONDITION FOR APPLICABLE STATION:
- M- MASTER, S1- UPPER DISPLAY, S2- LOWER DISPLAY.
- S/N INDICATES APPLICABLE STATION SIGNAL TO NOISE CONDITION.

Figure 9A. STATUS ALARM INDICATORS
AND STATION BLINK ALARMS

3.2.12 BLINK ALARMS. A Blink alarm is transmitted by a Loran station when it is experiencing technical or operational problems. See Figure 9.

3.2.12.1 BLINK ALARMS-TRACKING MODES. When the displays are indicating the Time Difference (TD) information of a secondary being tracked, synchronous flashing of digits 3 and 4 indicate a station Blink for that secondary. The operator should select a different Secondary for operation. When two or more secondaries of a chain transmit a Blink alarm, the technical problem is usually with the Master station. Caution is urged when using that secondary or that chain for navigation.

3.2.12.2 BLINK ALARMS-LATITUDE-LONGITUDE AND CPN MODES. When the receiver is operating in the L/L and ComPuNav modes, Synchronous flashing of ALL CS and S/N status/alarms indicates a station Blink for one or more secondaries. The operator should reset the receiver to the SEL mode (avoid passing through TEST mode with function select key. See Note) and determine whether the Blink alarm is from one Secondary or from two or more secondaries and, if possible, select a different secondary or a different chain. Caution is urged when using the secondary or the chain for navigation.

CANCEL BLINK ALARMS Once a Blink Alarm is detected by the receiver, the alarm indicator will not reset automatically. To reset a Blink alarm, set to SEL mode, press 0 to get into TEST mode. Press 0 again.

If the alarm is still being transmitted by the station, the receiver will again detect the Blink alarm and it will be indicated as previously described. Detection may require several minutes. This depends upon signal conditions.

3.3 DESCRIPTION OF OPERATING MODES.

Each operating mode is designated to perform specific operations and to display specific tracking position information or course computer information. This is how they are used to obtain navigation information SEL (SELECT). This mode is used to enter and to change the 4 digit GRI code for the Loran C Chain of operation. (See 1.4). Since each Loran chain covers a specific area there is no need to change the GRI code unless you travel to a different Loran coverage area.

SEL (SELECT). This mode is also used to permit the Loran to synchronize of the Loran signals for the selected chain. The synchronizing process is called ACQUISITION, CYCLE SELECT and SETTLING. All useable Loran

stations in the chain are automatically acquired by the loran receiver. Cycle Select is automatic but requires a short period of time for the receiver to detect and synchronize on the third cycle of the transmitted loran pulses. Settling of the receiver occurs when the receiver is completely synchronized on the master station and at least two secondary stations. The C/S Cycle Select indicators will extinguish when synchronization is completed. Then you can use the loran for navigation. Any time that the C/S indicators appear, the loran should be set to the SEL mode until the C/S indicators extinguish. When SETTLED, the loran displays your current loran position TD's. This mode is also used to select or change the displayed secondary TD's in conditions where the normally used secondaries become unuseable. Several additional operations can be performed in the SEL mode. However, they are not necessary for normal operation and are described in subsequent sections for Manually Assisted Cycle Selection, Skywave Operation and Testing Functions.

SEL-TEST MODE. The SEL Mode can be used for several testing operations. It is used (1) to activate all segments of the display, (2) to display the signal quality of the loran signals and (3) to cancel the loran station Blink signals and all status alarm indicators. When this mode is used to cancel or clear an alarm condition, if the alarm condition remains the status alarms will again appear in the displays when set to different operating modes.

NOR NORMAL. This mode is used for AUTOMATIC TRACKING of the loran C signals. The loran displays your present loran position in the coverage area. Using the Time Difference numbers displayed by the receiver you can determine your current position or location using Loran C Nautical charts for your area.

This mode inhibits cycle selection and in normal conditions will prevent the loran from loosing synchronization with the loran signals. Once settling is completed in the SEL mode, the NOR mode should be used for loran position information. This mode can be used to change or display the present position TD's for the other Secondary stations.

This mode is the Instant Memory mode whereby the present position TD's can be instantly stored in Memory 51 thru 60. The loran can be turned OFF in the NOR mode and when Power is turned on again, it will automatically acquire, cycle, select and settle on the previously selected TD's. This is called an AUTO-START mode of operation. However, if the loran is moved more than 30 microseconds from the position where power was turned OFF, the SEL mode should be used.

L/L LATITUDE-LONGITUDE. This mode is used for AUTOMATIC TRACKING and the unit displays your present LATITUDE-LONGITUDE position. Using the Latitude-Longitude numbers you can determine your current position using any nautical chart for your area. Once settling is completed in the SEL mode, the L/L mode can be used for position information and tracking.

The Latitude-Longitude position computed by the loran is based on the TD's of the two Secondary stations chosen for operation. Using different TD's will produce differences in the accuracy of the calculations. The TD's chosen for operation should be based on the best possible condition.

- (1) LOP crossing angles should be as close to 90 degrees as possible and not less than 30 degrees.
- (2) Good signal strength and quality.
- (3) Narrow gradient or the smallest number of microsecond spacing between TD Lines of Position on the charts.

Direction indicators N or S and E or W appear in Latitude-Longitude displays and colons (:) separate the degrees and minutes numbers in the display.

WP WAYPOINT. This is a course computer mode. It is used to program and enter waypoints using the TD's or LATITUDE-LONGITUDE of the desired destination. Waypoints can be programmed and stored in Memory 01 thru 50 and waypoints can be stored and entered into the course computer at the same time.

The WP mode is used to establish the starting point and point of origin for the current leg of a computed course. Any time the WP mode is selected, the present position is entered into the course computer as the point of origin and a new course to the destination is computed. All off-course conditions are cancelled and reset for the new course. Waypoints stored in memory can be transferred to a different memory in this mode.

T1, T2 and T3 - TRACK 1, TRACK 2 and TRACK 3.

These operating modes are used to display all of the course information that is computed by the loran course computer. The system computes the same course information when waypoints are entered using TD's or LAT-LONG positions.

T1 TRACK 1. When set to T1 mode the ON-COURSE or OFF-COURSE conditions (cross track error) are displayed in the upper display. Cross track

error is the lateral deviation from the course line to a waypoint. The Distance to the waypoint or Time To Go to the waypoint are displayed in the lower display.

T2 TRACK 2. When set to T2 mode, the ON-OFF COURSE conditions are shown in the upper display (same as T1). The Vessel's Speed or Vessel's Heading are shown in the lower display.

T3 TRACK 3. When set to T3 mode, the ON-OFF COURSE conditions are shown in the upper display (same as T1). The Bearing to the waypoint or the 24 hour Day-Time clock counter are shown in the lower display. The clock can be set for the day of the month and 24 hour time.

CNV CONVERTER. This mode is used for several operation.

- (1) TD positions can be converted to Latitude-Longitude positions either by direct entry using the keyboard or by recalling TD position from memory for the conversion.
- (2) The displayed Latitude Longitude position can be compensated to display the corrected Latitude-Longitude position by entering the True Latitude Longitude numbers.
- (3) The Vessel's Heading display can be compensated by entering amount of Magnetic Variation for the area of operation.
- (4) The Arrival Alarm can be preset to sound off anywhere within 0.1 to 9.9 miles of the entered waypoint.
- (5) The OFF-COURSE alarm can be preset to sound off anywhere between 0.1 to 9.9 miles from the course line to a waypoint.
- (6) The ANCHOR WATCH alarm can be preset to sound off anywhere between 0.1 to 9.9 miles if the vessel drifts from the anchored position.

S1 SECONDARY UPPER DISPLAY.

S2 SECONDARY LOWER DISPLAY.

If required for more accurate navigation, TD COMPENSATION for ASF FACTORS can be applied to both S1 or S2 Secondaries in these modes. See Section 1. These modes are designed for special operational requirements and are not normally required for operation. They display the present position TD's. Also, CYCLE SELECT is activated for S1 or S2 Secondary, depending on which mode is selected. These modes can be used for Manually Assisted Cycle Select, to assist in Skywave operation.

3.4 OPERATING PROCEDURE

First determine the GRI for your area of operation. The four (4) digit code can be obtained from the GRI table in this book or from Loran C nautical charts for your area of interest.

3.4.1 FIRST POWER ON OPERATION-ENTER GRI.

Repeat this procedure whenever the vessel enters an area covered by a different Loran C Chain.

1. Press the **[ON]** Key. The unit will come on. All zeros or some numbers may appear in the display.

Disregard these numbers.

2. Press **[←]** Key, then press **[←]** Key. Set BAR Indicator to SEL mode.
3. Use the Keyboard. Press the four digits for the GRI code.

Example: Press **[7]** **[9]** **[8]** **[0]** for the Southeast U.S. Chain.

Read the GRI in the upper display.

| | | | | | |
|---|---|---|---|---|---|
| 0 | 0 | 7 | 9 | 8 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |

4. Press **[ENT]** Key. Read the GRI in both displays

| | | | | | |
|---|---|---|---|---|---|
| 0 | 0 | 7 | 9 | 8 | 0 |
| 0 | 0 | 7 | 9 | 8 | 0 |

If a mistake is made press **[CL]** Key and repeat procedure.

The GRI is now entered for your Loran C Chain of operation.

It will remain stored even when power is OFF.

NOTE

If all 9's appear in the displays, the GRI has been dropped from the memory and GRI must be entered again using this procedure.

3.4.2 SELECT SECONDARY TD's FOR OPERATION.

The SEL mode is used to select and display the TD's of all Secondary stations for the GRI chain.

1. After the GRI has been entered, numbers will appear in both displays. As many as four different secondaries may be displayed, depending on the GRI in use.
2. Read the TD's sequencing in both displays. Using a Loran C nautical chart, choose the two TD's with the best crossing angle (closest to 90° crossing angle), provided they have adequate signal strength for your area.
3. Press **[S1]** Key when the desired TD numbers appear in the upper display. The upper display will stop rotating.
4. Press **[S2]** Key when the desired TD numbers appear in the lower display. The lower display will stop rotating. Once the TD's have been selected

the loran will automatically select the same two TD's whenever power is turned ON.

SETTLING

Observe the C/S CYCLE SELECT indicators in the center of the display. These C/S indicators are most important in the operation of your loran. When they are ON they indicate the Cycle Select process has not been completed. The loran must remain in the SEL mode until all C/S indicators go out. The TD numbers may fluctuate during the settling process and the S/N indicators may also appear.

The cycle select and settling process may require from 3 to 5 minutes depending on the signal strength and quality. When the C/S indicators go out the loran is ready to use.

3.4.2.1 CHANGING SECONDARY TD's.

Secondary TD's can be changed at any time.

1. Press ◀ or ▶ Key. Set to SEL mode.
2. Press **S1** Key. The TD's will sequence in the upper display.
3. Press **S1** Key again to choose different TD's and stop the rotation.
4. Repeat the procedure using **S2** Key to change lower display.

Example of TD's sequencing in upper or lower displays:

| | | |
|------------|--------------------|------------------|
| Sequence 1 | 1 4 2 4 8.8 | |
| 2 | 3 1 0 7 4.3 | TYPICAL TD's FOR |
| 3 | 4 4 7 1 3.9 | 7980 GRI CHAIN |
| 4 | 6 2 8 8 7.8 | |

TD's will continue sequencing until secondary TD's are selected by **S1** or **S2** Key press.


NOTE

If all 0's appear in either display, press **CL** Key. This will restart the Cycle Select process as described in 3.4.2. If all 0's remain in either or both displays, the loran is not receiving signals from the loran station. Check the antenna, the antenna coupler and cable connection for possible defects in the installation.



- #### 3.4.3 AUTO-START POWER ON OPERATION.
- The loran receiver has a memory feature which retains the GRI and the TD's of the two secondaries last displayed even when power is turned OFF. It also retains the last operating mode (position of BAR indicator) when power is turned OFF. If power is turned OFF in either the NOR mode or the L/L mode,

when it is turned ON again the loran will be in either the NOR mode or the L/L mode. The loran will automatically acquire the same GRI and the same two secondaries. The cycle select and settling will be automatic unless the boat has been moved more than 30 microseconds distance. In this case, set to SEL mode when power is turned ON. Status alarms will be on during the settling process. When the alarms go out the unit is settled and ready for operation.

3.4.4 AUTOMATIC TRACKING USING TD's. The NOR mode is used for automatic tracking of the TD's for your Present Position information.

Press  Key. Set Mode indicator to NOR. The TD's of your present position will be indicated in the two displays. The receiver will automatically track the TD's and update the displays to indicate the current position of the vessel.

At this point, to clarify the use of the automatic tracking mode, the operator should recall that the graphical plot of all observation points having a constant measured time difference (TD) forms the Lines of Position (LOP's) which are printed on the Loran C Chart. The Time Differences (TD's) measured by your Loran C receiver and indicated in the displays, represents your present position along the Lines of Position (LOP's). The TD's are measured to 0.1 or 1/10 of a microsecond, however, the spacing or gradient between LOP's presented on the charts may be in increments of 10 to 50 microseconds. Since every possible LOP cannot be printed on the charts, the operator is required to interpolate or estimate the time differences between the LOP's printed on the chart to determine his exact position from the TD's displayed. Interpolation scales are usually printed on the Loran C chart for the users convenience. Section 1 describes conversion of microseconds to nautical miles and feet. No further operations are required to remain in the NOR TRACKING mode unless the Status/Alarm indicators illuminate or flash to indicate that something is wrong. Then a change may be required. Status/Alarm indicators are described in preceeding sections.

Secondaries can be changed at any time in the NOR mode using the  and  Keys. Observe the CS Status/Alarm indicators when selecting secondaries. Other modes of operation may be selected

without interrupting or interfering with the automatic tracking of the Loran C signals.

Time Difference Offset and Compensation of Time Difference

TD's Position. The Time Differences measured by the loran receiver can be offset to correct for ASF Additional Secondary Phase Factors, which is, the errors introduced into the measured TD's when the transmitted loran signals must travel some distance over a land path before reaching the loran receiver. This ASF was discussed in Section 1.

Applying offset or compensation to the TD's will result in more accurate navigation and position fixing. In addition, the Latitude-Longitude coordinates computed from the compensated TD's will be more accurate, resulting in more accurate LAT/LONG position fixing.


The ASF and the required TD offset is different for each TD since they travel over different land path routes. Consequently the compensation of the TD to correct for the ASF Factors must be applied to each TD separately. Compensation can be positive or negative depending on the vessels position in the loran chain.

The actual amount of TD compensation for each TD should be determined from Defense Mapping Agency Loran C Correction Tables or they can be determined from local knowledge provided the local knowledge is determined to be reliable data before using it.


Entering TD Compensation.


The range of TD compensation that can be applied is from -9.9 microseconds to +9.9 microseconds. The compensation is retained in memory even when power is OFF.


Compensate the TD in the (S1 Upper Position Display.

1. Be sure the unit is settled, all CS indicators OFF.
2. Press . Set to S1 mode.
3. Read the TD in the display

POSITION DISPLAY


- 1 4 2 4 8.8
4. Press two (2) digits for the TD compensation e.g., 01, 02, 03, 1.1, 1.2, etc., as required (TENTHS OF MICROSECONDS).
Read the amount of compensation in MEMO display.
5. Press  Key for positive compensation.






Press  Key for negative compensation.

Press  Key for negative compensation.


Upper Bar indicates compensation added to TD

Lower Bar indicates compensation subtracted from TD.



6. Press  Key. Compensation  is entered into the TD in the S1 upper position display.
7. Press    key to clear compensation from S1 display.
8. Read compensation at any time in S1 or S2 mode.

Compensate the TD in the (S2) Lower Position Display.

1. Press . Set to S2 mode.
2. Repeat the procedures specified for the compensation of the S1 except read the TD in the (S2) lower display. The compensation procedures are the same.

NOTE


The compensation applied to the S1 and S2 secondaries is also applied to the Latitude-Longitude readings in the L/L mode.

CAUTION

Do not apply compensation to the Time Differences when compensation is applied to Lat/Long position in the CNV mode. Serious errors can result. The user should always check both TD and LAT/LONG compensation before using the Loran. TD and LAT/LONG compensation is not cleared when power is off. All compensation is cleared when the GRI is changed.

3.4.5 AUTOMATIC TRACKING USING LATITUDE-LONGITUDE.

The L/L mode is used for automatic tracking of Latitude and Longitude for your present position information.


Press  Key. Set mode indicator to L/L. The Latitude-Longitude is automatically computed from the TD's chosen for operation.

Read North or South Latitude in the upper display.

Read East or West Longitude in the lower display.

Colons separate degrees and minutes digits.

Typical Position Display



NOTE

Coordinate Conversion from different pairs of TD's will produce differences in the accuracy of the Lat-Long computed. Select the two TD's with the best crossing angle. Verify the position accuracy by using all available secondary TD pairs.




Complementary Latitude-Longitude Position Displays. Under certain conditions and in certain locations the coordinate converter will compute and display the undesired Complementary Latitude-Longitude position, Figure 9. This is most likely to occur near the areas formed by the Master-Secondary baseline extension and Secondary-Secondary baseline extension.

The complementary computation occurs because each pair of Lines of Position plotted on the chart can cross at two locations on the globe. This results in two different LAT-LONG computations for the same LOP's. Only one computation can be correct for your present position.

If this occurs, press **[S1]** key to select the correct complementary computation of Latitude and Longitude. Select one or two different secondaries to verify which computation is correct for navigation. When different secondaries are selected, press **[S1]** key to ensure the correct computation is displayed.

If the correct Latitude-Longitude position is being displayed, selecting the undesired complementary position is of no value for use in navigation.

Compensation of Calculated LAT/LONG Position. Coordinate conversion from Loran TD's to Lat/Long coordinates will not always produce geodetically accurate coordinates because of ASF Factors. The



Undesired Complementary Computation of Latitude-Longitude may occur in and near the shaded zones depending on chosen secondaries. Different chain configurations will present different characteristics within the shaded zone.

Figure 9B. Unuseable Complementary LAT/LONG Positions


Compensation Mode provides a means to manually enter compensation into the Lat/Long calculations (of your present position) for correction of these inaccuracies.

Display of Lat-Long Compensation.


Before compensation can be applied, certain observations should be made.

Press  Key, then press  Key. Set to CNV Mode.

Press  , then press  .

Read Latitude compensation in upper display  Min.

Leading "0" indicates negative compensation *  Max.

Read Longitude compensation in lower display  Min.

Leading "0" indicates negative compensation *  Max.




Apply Compensation to correct the Lat-Long Position.

Correction is applied by entering both the known accurate Lat-Long position using the keyboard.

The vessel must be at the known accurate Lat-Long position when the compensation is automatically computed by using the present position Lat-Long and the entered Lat-Long. When the compensation is entered, it is continuously applied to all subsequent Lat-Long readouts in the display until it is changed or cleared.

The maximum amount of correction that can be applied is 9:00 minutes for both Latitude and Longitude. It is necessary to enter both the Latitude and the Longitude even though the correction amount required applies only to the Latitude or Longitude.

Press  Key, then press  . Set to CNV Mode.


Press  . Press  .


Press  then the six digits for true Latitude position.

Press  then the six or seven digits for true Longitude position.

Read both corrected Latitude and Longitude in display.

Press  . Read the amount of correction.

Upper display - Latitude correction 

Lower display - Longitude correction 

Leading "0" negative correction 

Minutes

Hundredths of Minutes

Audible alarm may sound. Do not press **CL** at this time.

Press **←** then press **→**. Set to L/L mode.

Read corrected Lat-Long position in displays.

Press **CLR** to stop alarm signal.

TO CLEAR COMPENSATION FROM LATITUDE-LONGITUDE

Press **←**, then press **←**. Set to CNV mode.

Press **-/R**. Press **9****9**. Press **CL**

Read Compensation **0 0:0 0:0 0**

0 0:0 0:0 0

3.4.6 INSTANT MEMORIES Ten Instant memories 51 thru 60 are provided to store the present position TD's or Latitude-Longitude at any time. TO STORE TD's or LAT-LONG POSITION IN INSTANT MEMORY.

Press **←** or **→**. Set to NOR mode or to L/L mode.

Press **+M**. Read present position in displays. Read MEMO number.

The next position stored will be stored in the next higher memory number in sequence 51 thru 60.

Press **CL** to resume tracking TD's or Lat-Long.

TO RECALL TD's from Instant Memories.

Press **←** or **→**. Set to NOR mode or to L/L mode.

Press **-/R**. Read recalled position in displays.

Read MEMO number. Positions are recalled in reverse order

60 thru 51 beginning with the last memory number used.

Press **CL** to resume tracking TD's or Lat-Long.

NOTE

When +/M is pressed CS indicators flash.

When -/R is pressed SN indicators flash.

Flashing indicates non-tracking state.

Bar Indicator appears above MEMO number.

Flashing will cease when **CL** is pressed.

3.4.7 COURSE COMPUTER OPERATION (CPN Modes WP, T1, T2, T3).

The course computer modes are used to automatically compute and

guide you along the course from a particular starting point

(called a point of origin) to a predetermined destination or waypoint

The Point of Origin is the immediate position of the vessel when the course computer is activated for the entered waypoint.

The WP Mode is used to program and to enter the waypoint TD's or

- A- Is point of origin or present position. The TD's or Lat/Long at the intersection (Crossing Point) of the two TD's are displayed.
- B- Is destination. The TD's or Lat-Long entered as a waypoint.
- C- Is the course computed from the point of origin to the waypoint.
- D- Is Cross track error left or right from the course computed.
- E- Is an example of a position indicating cross track error to right, this position can be re-established as a new point of origin in case of excessive error. ComputNav then computes cross track error and navigation data from this position.
- F- Indicates the new course from new point of origin when reset to T1, T2 or T3 modes.
- G- Interpolation is required when point of origin or destination is not located exactly on grids printed on the chart.
- H- Is bearing to waypoint.
- J- Is vessel's loran heading

mercator projection
 Latitude Scale: 30-40.00
 Degrees
 Minutes and hundredths of Minutes
 Tenths and hundredths of seconds
 if chart graduation are in seconds
 Convert seconds to tenths and hundredths of minute




Figure 10A. Typical ComputNav Operation
 Using TD Mode




Figure 10B. Typical ComputNav Operation
 Latitude/Longitude Mode

Lat-Long position. The course computer is activated instantly by setting the BAR mode indicator from the WP mode to the T1, T2, or T3 mode. After a few seconds in the T1, T2 or T3 mode the course information will appear in the displays.

ON-OFF COURSE is read in the upper display in all three modes. The T1 mode displays distance to go or time to go to the waypoint. The T2 mode displays the vessel's speed or vessel's Heading. The T3 mode displays the bearing to the waypoint or the elapsed time-24 hour clock.

ON-OFF Course (cross track error) is displayed when the vessel moves to left or right from the computed course. OFF-Course is displayed in hundredths of a nautical mile or tenths of a nautical mile. Distance to Go is displayed in nautical miles up to 999.9 NM. Distance will decrease as the vessel moves toward the waypoint and will increase if the vessel moves away from the waypoint.

Time to Go is displayed in hours and minutes. The calculation is based on the average speed of the vessel as it moves toward the waypoint. The maximum time computed is 60 hours and the vessel must be moving to obtain the Time to Go reading. The first computations of Time to Go require about two minutes before it is displayed. Further computations are based on the vessels average speed to the waypoint. When the vessel is not moving, the display will increase to a maximum reading of 99 HRS - 99 MIN. Erratic steering on and off course will cause the Time to Go computation to increase. The most accurate time is obtained by keeping the vessel on course using the cross track error display and the compass.

Waypoints. Fifty waypoints can be stored in memories 01 thru 50 and recalled later as they are required for entry into the course computer. The waypoint stored in Instant Memory 51 thru 60 provides other waypoints. Any waypoint can be programmed and entered directly into the course computer for immediate use but this waypoint is not stored in any memory and it will be lost when another waypoint is entered. The waypoint number in use is read in the MEMO display.


Storing waypoints in memory is particularly useful when planning a trip and when programming along the way is not practical. This is also useful for retaining the ID's or Lat-Long of a frequently traveled course. Once stored, they remain in memory even when power is off.

3.4.8 WAYPOINT PROGRAMMING

Waypoints can be programmed for direct entry into the course computer or they can be stored in any of the 50 memories. TD's Time Differences or Latitude-Longitude can be used.

3.4.8.1 Waypoint Programming Using TD's.

Determine the two TD's for each waypoint. The TD's should correspond to the chosen secondaries in use.

Press . Set BAR indicator to NOR mode.

This primes the course computer to accept only TD waypoints.


Press  then press . Set to WP mode.

Using the keyboard:

Press six digits for the TD corresponding to S1 secondary.

Press the six digits for the TD corresponding to S2 secondary.

Read the TD's in the displays.




If a mistake is made press  and repeat the procedure.

Proceed to 3.4.8.3 Immediate Use of Waypoint.

Proceed to 3.4.8.4 Store Waypoint in Memory.

3.4.8.2 Waypoint Programming Using Latitude-Longitude.

Determine the Latitude-Longitude for each waypoint.

Press . Press  or . Set to L/L mode.

This primes the course computer to accept only Lat-Long waypoints.

Press . Press . Set to WP mode.

Using the Keyboard:

Press  or . Latitude direction key.

Press the six digits for Latitude.

Press  or . Longitude direction key.

Press the six or seven digits for Longitude.

Read the Lat-Long in the display with N or S and E or W indicators for Lat-Long displays.


If a mistake is made press  and repeat procedure.

Proceed to 3.4.8.3 Immediate Use of Waypoint.

Proceed to 3.4.8.4 Store Waypoint in Memory.

3.4.8.3 Immediate Use of Waypoint For Course Operation.

Program waypoint per 3.4.8.1 or 3.4.8.2.

Press . Waypoint is entered into course computer.

Press . Set to T1, T2 or T3 mode.

Proceed to 3.4.8.6 for course computer operation.

3.4.8.4 Store Waypoint in Memory.

Program waypoint per 3.4.8.1 or 3.4.8.2.

Press . Press two digits 01 thru 50 to designate the memory location. Read memory number in MEMO display. Waypoint is automatically stored.

Read waypoint in the display.

Press to program and store additional waypoints repeat procedures 3.4.8.1 and 3.4.8.4 for TD waypoints or repeat 3.4.8.2 and 3.4.8.4 for Lat-Long waypoints.

To Simultaneously store and enter a waypoint for course computer operation:

Program waypoint per 3.4.8.1.

Press . Press two digits 01 thru 50 to designate memory.

Press . The waypoint is automatically stored in memory and entered as a waypoint. Read the displays.

Waypoint number does not remain in display after entry. See NOTE below

Press . Set to T1, T2 or T3 mode.

Proceed to 3.4.8.6 for course computer operation.

3.4.8.5 Recall A Stored Waypoint for Course Computer Operation.

Press . Set to WP mode.

Press . Press two digits 01 thru 60 corresponding to memory location desired for recall. Read waypoint number in MEMO display. Read displays of TD's or Lat-Long. N or S and E or W indicators appear only for Lat-Long displays.

Press to cancel a recalled memory and to restore the previously entered waypoint.

Press . The recalled waypoint is entered for Course Computer operation.

Press . Set to T1, T2 or T3 mode.

Proceed to 3.4.8.6 for Course Computer Operation.

NOTE


Waypoint number entered for course computer operation remains in MEMO display only when entered using the procedure of 3.4.8.5.

COURSE COMPUTER OPERATION (CPN)

3.4.8.6 STEERING THE COURSE TO A WAYPOINT.

It is necessary to set the vessel to the correct compass course for the waypoint before activating the course computer. Otherwise, off-course conditions will appear in the display while the vessel is being positioned on course.

1. Enter waypoint per 3.4.7.3 or 3.4.7.4.

Press . Set to T1, T2 or T3 mode. The movement of the BAR mode indicator from WP to T1 initiates the course computer operation. The Present Position is entered as the Point of Origin for the course to be entered waypoint. All navigation information is computed from this point unless the Point of Origin is reset again at another location. See 3.4.8.

2. T1-TRACK 1 Displays.


Cross Track Error (ON or OFF Course) is indicated in the upper display. Distance to Go and Time to Go are indicated in the lower display.

| | | |
|---------------------------------|--------|----------------|
| ON-Course | :0 0: | |
| OFF-Course LEFT | :0 1 | .01NM to .99NM |
| Steer right to return on course | | |
| OFF Course Right. | 0 1: : | .01NM to .99NM |
| Steer left to return on course | | |


Off-Course distance decreases with proper steering.

The normal display of cross track error is from 01 to 99 Hundredths of a nautical mile. The cross track error can be changed to read in tenths of a nautical mile from 0.1 to 9.9NM.

While operating in T1, T2 or T3 modes:


Press . Read cross track error

| | | | | | |
|---------|----|---------|----|---------|----|
| 0.1: :. | to | 9.9: :. | NM | | |
| or | | .: 0.1 | to | .: :9.9 | NM |

Decimal points  indicate display is read in 1/10 mile.

NOTE


Exercise caution when using 01NM cross track conditions
Since 0.1NM = 600 feet, unforeseen obstacles could be encountered while traveling a course.

Press  to select display of Distance to Go or Time to Go.

| | | |
|----------------|-------------|---------------|
| Distance to Go | 0 0 0 0 0.0 | NM Minimum |
| | 0 0 9 9 9.0 | NM Maximum |
| Time to Go | 0 0 0 0 | Hours-Minutes |
| | 9 9 9 9 | Maximum |


When distance or time exceeds the maximum, it may be necessary to program a closer waypoint to get a time or distance display.

T2 - TRACK 2 DISPLAYS. See Paragraph "Compensation for Magnetic Variation."

Press . Set to T2 mode.



Cross Track Error is displayed the same as the T1 mode.

Vessels speed or vessels heading can be displayed in the lower display.

Press  to select display of speed or heading.


Vessel's Speed  0 0.0 to  4 0.0 KTS/HR.

Vessels speed computations require that the vessel be moving for 2 to 4 minutes. Changes in both speed and direction of vessel travel can cause erroneous readings.

Vessels Heading  0 0 0 0.1 to  0 3 5 9.9 degrees true.

Vessels heading computations require that the vessel be moving for a period of time. Changes in direction of the vessels travel will require additional time to average the vessels heading display.

T3 - TRACK 3 DISPLAYS. See Paragraph "Compensation for Magnetic Variation."

Press . Set to T3 mode.

Cross Track Error is displayed the same as the T1 mode.



Bearing to the waypoint and the Elapsed Time 24 hour clock can be displayed in the lower display.

Press  to select display of Bearing or Time.

Bearing to Waypoint  0 0 0.1 to  3 5 9.9 degrees true



Elapsed time/24 Hour Clock displays days, hours, minutes.

The timer begins counting when power is turned ON.

Press  to reset timer to  0 0:0 0:0 0
Day HR MIN

To set the timer to read days and 24 hour time:


Press six digits for the day, hours and minutes.

Read the display  0 0:0 0:0 0 to  3 1:2 3:5 9
Day HR MIN

APPROACH TO AND ARRIVAL AT WAYPOINT.


Read indications of distance, Cross Track Error and Time to Go.

Distance to go decreases toward  0 0 0 0 0.0

Time to go decreases toward  0 0 - 0 0 -

Some cross track error may be displayed.

Set to MCR or L/L mode to read actual position or select the next waypoint.

The Arrival Alarm will sound at a preset distance from the waypoint. When the first GRI is entered and when a new GRI is entered the preset distance is automatically set to 0.5NM. Use the procedure of WAYPOINT ARRIVAL ALARM to change limits. Press  to stop alarm.

RUN PAST WAYPOINT.

Some Cross Track Error may be displayed.
Distance to Go will continue to increase.

RESET POINT OF ORIGIN.

When Cross track error indicates that you are too far off-course, it may be desired to reset the Point of Origin to set a new course to the waypoint.

Press . Set to WP. Press  set to T1, T2 or T3.

The present position is reset as Point of Origin and the new course is computed. Distance, Time To Go and Bearing information are recalculated from this position.

NOTE

If reset of the Point of Origin is not desired,
DO NOT set to WP mode. To recall a waypoint for review, set to CNV mode and recall waypoint, then reset to desired mode of operation. Set to NOR or L/L position to read present position.

COMPENSATION FOR MAGNETIC VARIATION.

Both the Vessels Heading display (T2 display) and the Bearing to the waypoint display (T3 display) are displayed in degrees relative to True North. Compensation can be applied to correct the two displays for the local Magnetic Variations so the display corresponds to a magnetic heading and bearing. When Compensation is entered into the Ioran, it is automatically applied to both the Heading and the Bearing displays. All subsequent calculations have the compensation applied. Therefore, compensation should be checked frequently to determine the correct amount for the area of operation and should be cleared from the unit when not required.

To apply compensation to the Heading and Bearing Displays:

Press  then press . Set to CNV mode.

Press $\boxed{-/R}$ then press $\boxed{9}\boxed{8}$.

Read the Vessel's Heading in the lower display.

No correction applied $\boxed{00000.0}$
 $\boxed{0-121.0}$

The Bearing display can not be observed during this procedure.

Press three (3) digits for the amount of correction in your area:

Example: Press $\boxed{1}\boxed{4}\boxed{3}$ for 14.3 degrees of correction.

Read the upper display $\boxed{00014.3}$

Minimum correction is 00.1 degrees. Maximum is 30.0

Press $\boxed{+/M}$ to add the amount of correction.

Press $\boxed{-/R}$ to subtract the amount of correction.

Read upper display. - - - - - $\boxed{00014.3}$ or $\boxed{-0014.3}$

Leading "0" for positive correction. * *

Blank digit for negative correction.... Press \boxed{ENT} .

Read lower display of corrected Heading. $\boxed{0-135.3}$

Press \boxed{CL} key while set to this operating mode to clear the compensation from the Heading and Bearing displays.

Press $\boxed{\blacktriangleleft}$ key. Set to T3 mode to observe correction in the Bearing display.

3.4.9 CALCULATE LAT-LONG FOR TWO TD's.

Press $\boxed{\blacktriangleleft}$ then press $\boxed{\blacktriangleright}$. Set to CNV mode.

Read the present chain 7980 or other in display.

If calculation for a different chain is required, press the four digits for the chain, press \boxed{ENT} . Read chain number in the display.

Use the Keyboard, press six digits for each TD, a total of 12 digits. Read TD's in display.

Press \boxed{ENT} . Wait 5 seconds. Read the calculated Latitude-Longitude in the displays.

To store Lat-Long as a waypoint:

Press $\boxed{+/M}$, press two digits to designate memory number.

Press \boxed{CL} and repeat for additional calculations.

To enter as a waypoing use procedure 3.4.8.6.

Recall TD position from memory to calculate Latitude-Longitude position.

Press F/R, press two digits to recall memory.

Press ENT. Wait 5 seconds. Read the calculated Latitude-Longitude in the display. Store the Lat-Long position in any memory as described above.

3.4.10 Automatic Waypoint Sequencing In ComPuNav Operation.

Automatic waypoint sequencing, Figure 11, of preselected waypoints can be accomplished in the WP mode.

Waypoints can be programmed using either TD positions or Latitude-Longitude positions. Using this procedure, the user can prepare a ROUTE Plan of TEN waypoints before leaving the port. Once the Route Plan is established there is no need for the user to enter waypoints until the tenth WP is reached.

The preselected waypoints will be automatically recalled and entered when the vessel arrives within a preselected circle of proximity to the waypoint.

Depending on the navigation clearance around the waypoint, the user can preset the range of the circle of proximity where the automatic sequence to the next waypoint will occur. The range can be preset from 0.1NM to 9.9NM, using the procedures for setting the Waypoint Arrival Alarm. The next waypoint will automatically enter into ComPuNav operation and a new course is computed to the next waypoint. Read the next waypoint in the Memo display.


See section describing the waypoint proximity arrival alarm and cross track error OFF Course Alarm. Set up these two alarm conditions to satisfy the requirements of the prearranged course so that the waypoints will automatically sequence.

3.4.10.1 Programming and Set-Up of a Route Plan.

Program and store the desired waypoints in memories in accordance with procedures of 3.4.8.

Waypoints can be stored using Time Differences (TD's) positions or LAT/LONG positions.







See Figure 11. If the vessel does not enter the preset circle of proximity range setup by the Waypoint Arrival Alarm, the waypoint will not automatically sequence and the user must force the change. See 3.4.10.4 - Force Change of Waypoint.



Caution: The next waypoint is selected when the circle is entered. The vessel has not reached the true waypoint position. Read the distance and cross track error displays and/or the loran position in the NOR or L/L modes.


Figure 11. Route Plan for Automatic Waypoint Sequencing.

3.4.10.2 Entering the Route Plan.

1. Press  Key. Set Bar to WP mode.
2. Recall the waypoints from memories in the sequence of the desired Route Plan.
Press  key. Press two digit keys for the desired memory.
Read Waypoint number in Memo display.
3. Press  key.
4. Press  key. Press two digits for next desired memory.
Read Waypoint number in Memo display.
Press  key. The waypoint number entered first will appear in MEMO display.
Other waypoint numbers are not displayed after press of  key, until automatically recalled for the route.
5. Repeat procedure for up to TEN waypoints.

NOTE

The entire waypoint sequence cannot be displayed. The operator should keep a record of the entries for reference.

6. If it is necessary to change the waypoint sequence, the entire sequence must be re-entered using the above procedures.
Press  key and repeat procedure.

3.4.10.3 Using the Route Plan for ComPuNav Operation.


After the Route Plan is entered:

1. Set BAR indicator to WP position, then to T1, T2 or T3.
2. Read the waypoint number in the display.
3. When the first waypoint is reached within the circle of proximity the waypoint will automatically sequence to the next waypoint.
Read the waypoint number in the display.
The present position is entered as the new point of origin and the new course is computed from this position.
4. Read the displays of Cross Track Error XTE, Distance and Bearing to the next waypoint.
5. As each waypoint is reached the automatic sequencing will occur. However, the 10th waypoint remains entered until

another WP is entered.

7. Repeat the procedure to enter a new Route plan. The previous Route Plan is erased from memory during operation.

3.4.10.4 Force Change of Waypoint in Auto-Sequence Route

Press . Set to T1 position. Read waypoint number in memo display.

Press , then press .





The waypoint number will change to the next waypoint number in the sequence.

Repeat the procedure to force another waypoint. Distance and Bearing are automatically computed to the next waypoint.

If next waypoint is within the preset limits of the arrival alarm, the alarm will sound.



3.4.11 SETTING OF ALARM LIMITS FOR ON-OFF COURSE ALARM, WAYPOINT ARRIVAL ALARM AND ANCHOR WATCH ALARM.

1. To set the ON-OFF Course Alarm limits:





Press . Set to CNV Mode. Press  to call-up the display of cross track limit. Read limit in the display. Press two (2) digit keys to designate the new alarm limit.

 NM minimum,  NM maximum. Press .




Press  to clear and to reset the limit again.


Press  to inhibit and prevent the alarm from sounding.

2. To set the Arrival Alarm limit and Automatic Waypoint Sequencing limit:

Press . Set to CNV mode. Press  to call-up the display of Alarm limit. Read limit in the display.

Press two (2) digits to designate the new alarm limit.

 NM minimum,  NM maximum. Press .

Press  to clear and to reset the limit again.

Press . to inhibit and prevent the alarm from sounding.

NOTE


When the GRI is entered or changed
the Arrival Alarm limit is automatically
reset to 0.5 NM. Always reset to the
desired limit.

3. To set the Anchor Watch Alarm limit:
Press . Set to CNV Mode. Press to call-up
the display of alarm limit. Read limit in display.
Press two (2) digits to designate the new alarm limit.
 NM minimum, NM maximum. Press .
Press key to clear and to reset the limit again.
Press to inhibit and prevent the alarm from sounding.
4. To Activate the Anchor Watch Alarm:
Press . Set to WP Mode.
Press . Read 95 in the MEMO Display.
The vessel's present position Latitude-Longitude is automatically
entered. Read displays.
If the vessel drifts beyond the preset limit the alarm will sound
Press to stop alarm.

NOTE

The anchor watch position LAT-LONG
will remain in the WP display until
a new waypoint is entered.

3.5 TEST MODE OPERATION.

Before operating the unit in the Test Mode, press  key and set the Bar indicator to SEL position. Allow sufficient time for the unit to settle. The unit must be completely settled, CS alarm off on the desired Secondary stations, before the Test mode signal analysis can be performed.



3.5.1 Cancel Station BLINK Alarms.

Activating the unit into the Test mode will cancel all status alarm indications including CS, S/N, and Station Blinks. When the unit is reset to a different operating mode, if the alarm condition remains the unit will detect and display the alarm condition and/or Blink.

CAUTION

Do not set unit into Test mode during the settling process. When alarms are cancelled, it could indicate that the displayed TD's are correct.

3.5.2 To set the unit into the TEST mode:

Press  Set to SEL mode. Press  Key. All segments of the display are automatically displayed for approximately 3 seconds. All 8's and all decimal points/colons are displayed.


3.5.3 Signal Analysis.

1. After 3 seconds in the Test mode a computer analysis of the Loran signals will appear in both displays.
2. The displays may be sequencing through the Master and Secondary stations approximately every 3 seconds. Press S1 key or S2 key to stop the display sequencing on the desired stations, Master or Secondary.
3. Press S1 key or S2 key to start the sequencing to select a different station, Master or Secondary.

NOTE

See Figure 12 for a description of the displayed information.

4. Observe Digit 6 (right side) of the displays. Digit 6 will display the number 4 when the receiver is completely settled. If the number 4 is not displayed, set function to SEL position and allow the receiver to settle before proceeding.
5. Digits 1 and 2 identify the stations by displaying the first two digits of the Master station GRI or the first two digits of the secondary station TD's. Digit 2 will be flashing to indicate that the numbers displayed are not Time Differences (TD's).



81-207

Figure 12. Sample Digital Readouts

6. Digits 3,4 and 5 present an analysis of the Loran pulses. The loran pulses are measured at three different locations and each digit represents the analysis of the three locations. The analysis is presented on a scale of 0 to 9, where 0 is the lowest quality signal condition and 9 is the best quality signal condition.

In most portions of the loran coverage areas, Digit 3 will read 2 or less. Digit 4 is the most important indicator of signal quality since it represents the measurement at the tracking point of the loran signal pulse. During the analysis, the number indications presented in digits 3, 4, and 5 will fluctuate higher and lower about some average value. Note the average values. Indications of 025 or higher in digits 3, 4 and 5 are usually adequate for reliable loran reception.

Skywave Operation. Skywave operation of the Master and Secondary stations is possible. Skywave signals always arrive at the receiver later than the ground waves, because, unlike the ground wave which follows a path along the curvature of the earth, the skywaves travel paths at varying angles above the ground wave path. The most perpendicular (vertical) skywaves are absorbed into the ionospheric layers. The skywaves which strike the ionospheric layer at an angle bounce off the ionosphere and are reflected back to earth at approximately the same angle. The skywave path of the signals, thus, requires a longer period of time to arrive at the receiver. This characteristic is important for two reasons:

1. The skywave does not interfere with cycle select and matching of the Loran C signals, as long as the ground wave Loran C signals are strong enough to use.
2. The skywave signal can be stronger than the ground wave signal in fringe areas and therefore, can be used in fringe areas to determine approximate position.

Skywave operation is used to extend the range of operation in a GRI chain when the vessel is moving away from the chain transmitters. The Skywave position accuracy is always less accurate than the ground wave accuracy and will vary considerably, depending on the ionospheric conditions and signal conditions.

Skywave signals generally arrive at the receiver approximately 30 microseconds later, at a distance of 1000 miles from the stations, during the daytime hours. At night time, the time of arrival of the skywave can extend up to 60 or more microseconds later at the same distance, because at night time the ionospheric layer is at a higher altitude and the skywave delay is longer. Your receiver provides a means to activate cycle selection for skywave operation.

CAUTION

The operator must understand that this type of operation is not recommended, except in cases where an approximate loran position is better than no position. Caution must be observed when using skywave operation.



The standard point on the Loran C pulse, for cycle select and tracking of the signals, is 30 microseconds time after the beginning of the Loran pulse, and skywaves do not arrive before this point. They could arrive 35 or 40 microseconds or more later in time.

When cycle selection is activated, the receiver circuits can be manually activated to increase the cycle tracking point, of any or all stations, on the Loran C pulses, in increments of 10 microseconds. By increasing the cycle tracking point 30 or 40 microseconds, the receiver will attempt to synchronize on the skywave pulse, which arrives 30 to 40 microseconds later, instead of synchronizing on the ground wave pulse.


When synchronization occurs on a skywave signal from a secondary station, the TD reading indicated in the display will be 30 to 40 microseconds higher than the TD which would be indicated if the ground wave signal was used. And, depending on the distance from the station and the altitude of the ionosphere, the TD readings may stabilize at some point between 30 and 40 (perhaps 35) microseconds higher than the ground wave signal would indicate. Therefore, to determine a position using TD's derived from skywave operation on a secondary station, the operator must subtract 30 to 40 microseconds from the displayed TD, depending on how many increments of 10 microseconds the cycle tracking point was increased.

Consequently, the skywave operation will always be less accurate than the ground wave. The operator must estimate his distance from the Loran station and then increase the cycle tracking point 30 or 40 microseconds or more depending on the estimated distance. Then by observing the TD displayed, the operator can determine the difference in microseconds, between the 30 to 40 microsecond increase in the cycle tracking point and the TD reading, as they approach synchronization.

3.6.1 Skywave Operation - on Master and All Acquired Secondaries.

1. Press  . Set Bar to SEL position. This activates cycle selection for all stations. The cycle tracking point of the Master and Secondaries can be increased in increments of 10 microseconds.
2. Press  key 3 times to increase the cycle tracking points (of M, S1 and S2) 30 microseconds. All CS status/alarms will illuminate indicating both displays are in a non-tracking state.
3. Immediately set Function Bar to NOR and wait for tracking to occur. Several minutes may elapse before stabilization.
4. The TD readings in both displays will fluctuate somewhat, depending on the skywave distance from the stations, and will begin to stabilize on the skywave signals.
5. The CS status/alarms may or may not extinguish when the Loran is used in this manner.



If the TD readings in both displays do not begin to stabilize:

6. Reset Function Bar to SEL position.
7. Press  key 4, 5 or 6 times to increase the cycle tracking points 40, 50 or 60 microseconds, if required. All CS status/alarms will illuminate.
8. Immediately set Function Bar to NOR and wait for tracking to occur. The CS status/alarms may or may not extinguish.


NOTE

In this mode, although the cycle tracking points of all stations is increased, the TD's read in the displays will not necessarily increase in increments of 10 microseconds, because all of the station cycle tracking points have been increased simultaneously.

3.6.2 Skywave Operation - on Secondary S1 (Upper Display) only.

1. Press . Set Bar to S1 position. This activates cycle selection for S1 secondary. The cycle tracking point of S1 secondary can be increased in increments of 10 microseconds.
2. Press  key 3 times to increase the S1 cycle tracking point 30 microseconds. S1-CS and status/alarms will illuminate indicating the S1 display is in a non-tracking state.
3. Immediately set Function Bar to NOR and wait for tracking to occur. Several minutes may elapse before stabilization.
4. The TD readings in the S1 display will begin to stabilize at readings approximately 30 microseconds higher than would be observed using ground wave signals.
5. The S1-CS status/alarms may or may not extinguish when the Loran is used in this manner.

If the TD readings in S1 display do not begin to stabilize:

6. Reset Function Bar to S1 position.
7. Press  key 4, 5 or 6 times to increase the cycle tracking point 40, 50 or 60 microseconds if required. S1-CS status/alarms will illuminate.
8. Immediately set Function Bar to NOR and wait for tracking to occur. The S1 status/alarms may or may not extinguish.

9. Subtract 30 or 40 microseconds (or more) from the TD reading when using the TD for navigation, depending on how many microseconds the cycle tracking point was increased (i.e., how many times +/M key was pressed).

3.6.3 Reinitialize Secondary S1. When cycle selection is activated in the S1 position, the secondary in the upper display can be reinitialized by pressing the CL key. The S1-CS status/alarm will illuminate.

At the same time, the receiver will begin a search for additional secondaries to track. If another secondary cannot be found, the receiver will attempt to reacquire the secondary originally displayed. If another secondary is found, the receiver will acquire that secondary. In any case, when the secondary is reacquired, the receiver must settle before using it for navigation (S1-CS alarms extinguished).

3.6.4 Skywave Operation - on Secondary S2 (Lower Display) only.

1. Press ◀. Set BAR to S2 position.
This activates cycle selection for S2 secondary. The cycle tracking point of S2 secondary can be increased in increments of 10 microseconds.
2. Press +/M key 3 times to increase the S2 cycle tracking point 30 microseconds. S2-CS status/alarms will illuminate indicating the S2 display is in a non-tracking state.
3. Immediately set Function Bar to NOR and wait for tracking to occur. Several minutes may elapse before stabilization.
4. The TD readings in the S2 display will begin to stabilize at readings approximately 30 microseconds higher than would be observed using the ground wave signals.
5. The S2-Cs status/alarms may or may not extinguish when the loran is used in this manner.

If the TD readings in the S2 display do not begin to stabilize:

6. Reset Function Bar to S2 position.
7. Press key 4, 5 or 6 times to increase the cycle tracking point 40, 50 or 60 microseconds, if required. S2-Cs status/alarms will illuminate.
8. Immediately set Function Bar to NOR and wait for tracking to occur. The S2 status/alarms will illuminate.
9. Subtract 30 microseconds (or more) from the TD readings when using the TD readings for navigation, depending on how many microseconds the tracking point was increased (i.e., how many times key was pressed).

- 3.6.5. Reinitialize Secondary S2. When cycle selection is activated in the S2 position, the secondary in the lower display can be reinitialized by pressing the key. The S2-CS status/alarm will illuminate.

At the same time, the receiver will begin a search for additional secondaries to track. If another secondary cannot be found, the receiver will attempt to reacquire the secondary originally displayed. If another secondary is found, the receiver will acquire that secondary. In any case, when the secondary is acquired, the receiver must settle before using it for navigation (S2-CS alarm extinguished).

3.7 MANUALLY ASSISTED CYCLE SELECTION.

The operator can manually assist the receiver to acquire and cycle select the correct cycle tracking point. This may be required when operating in areas where the receiver has difficulty in identifying the correct point at which to track the loran signals.

In areas of high noise conditions, in areas of strong signal near the Loran station, in areas of weak signal (fringe areas) at the extreme limits of coverage areas, the receiver may display incorrect time difference for one or more TD's. Also, the operation of the Loran receiver may be severely impaired when it is used in areas where TV receivers are in operation. Never operate a TV receiver while using your Loran. The TD readings displayed may be 10 to 60 microseconds higher or lower than the correct readings. The indication would be that the TD's are incorrect for a known position, such as the vessel's berth or at a location where the TD's were previously measured and established. Where conditions such as this exist, the operator will observe that one or more of the Cycle Select (CS) status/alarm has not extinguished in a reasonable period of time and that the TD may be fluctuating higher or lower about some average reading, indicating that the receiver has not settled.

CAUTION

The operator must know the TD's of the location or know a very close approximate of the TD's before using these operations.

3.7.1 Manually Assisted Cycle Selection - S1 Secondary

1. Set Function Bar to SEL position.
2. Observe the S1-CS status/alarm. If it is illuminated, cycle selection has not occurred and can be assisted manually.
3. Observe the TD in the S1 display. Estimate the difference (in microseconds, higher or lower) between the TD displayed and the known TD.
4. Set Function Bar to S1 position. Use step 5 of step 6.
5. Press +/M key to increase the cycle tracking point +10 microseconds each time the key is pressed.
6. Press -/R key to decrease the cycle tracking point -10 microseconds each time the key is pressed.

7. Observe the TD in the S1 display. The TD should read approximately the same as the known TD within several microseconds. Allow several minutes for the TD's to stabilize. If stabilization does not occur, the operator should move the vessel away from the area and repeat paragraph 3.4.2

3.7.2 Manually Assisted Cycle Selection - S2 Secondary. Repeat the procedure of 3.4.1 using Function Bar in the S2 position and by observing the S2-CS status/alarm conditions.

3.7.3 Manually Assisted Cycle Selection - Master Station

1. Set Function Bar to SEL position.
2. Observe the M-CS status/alarm. If it is illuminated, Master cycle selection has not occurred and can be assisted manually.
3. Observe the TD's in S1 and S2 displays. Estimate the difference (in microseconds, higher or lower) between the TD's displayed and the known TD's.
4. Press +/M key to increase the cycle tracking point (Master +10 microseconds each time the key is pressed. The TD's in both displays will decrease -10 microseconds each time the +/M key is pressed.
5. Press -/R key to decrease the cycle tracking point (Master) -10 microseconds each time the key is pressed. The TD's in both displays will increase +10 microseconds each time the -/R key is pressed.
6. Observe the TD's in both displays. The TD's should read approximately the same as the known TD's within several microseconds.
7. The S1-CS and S2-CS status/alarms may or may not extinguish when Master Cycle Select occurs. If secondary cycle select does not occur in several minutes, it may be necessary to move the vessel away from the area and repeat the procedures of 3.4.2
8. Do not use the TD's for navigation unless the CS status/alarms extinguish.

3.8 SPECIAL TEST FUNCTIONS

Special test functions can be performed to determine the operational capabilities of the Loran receiver. These functions are normally used by test technicians and production personnel to check the receiver for proper operation and are not used for normal operation.

Internal Oscillator Stability. This is a display of the internal oscillator frequency deviation.


1. Set Function Bar to SEL. Press 0 key. Wait 3 seconds for the digit display segment test to finish.
2. Press +/M key to display the frequency deviation. Deviation is displayed 00000.0 min., 000020.0 max.
3. Press +/M key to restore display to Test mode operation.

- 3.9 Manual Change of Cycle Tracking Points. The receiver cycle tracking points for the Master and Secondaries can be changed manually .


To manually change the cycle tracking points of the Master and all acquired Secondaries:

1. Press ◀. Set to SEL mode.
2. Press +/M key to increase the cycle tracking point +10 microseconds each time the key is pressed, or, Press -/R key to decrease the cycle tracking point -10 microseconds each time the key is pressed.
3. In both conditions, all CS status/alarms illuminates.
4. If Function remains in the SEL position, a properly working receiver will reacquire the correct cycle tracking points and settle. All CS alarms will extinguish.

To manually change the cycle tracking point of S1 secondary:

1. Press . Set to S1 mode.
2. Press +/M key to increase the cycle tracking point +10 microseconds each time the key is pressed, or, press -/R key to decrease the cycle tracking point -10 microseconds each time the key is pressed.
3. In both conditions, the S1-CS status/alarm illuminates.
4. If Function remains in the S1 position, a properly working receiver will reacquire the correct cycle tracking point and settle. The S1-CS status/alarm will extinguish.

To manually change the cycle tracking point of S2 Secondary:

1. Press . Set to S2 mode.
2. Press +/M key to increase the cycle tracking point +10 microseconds each time the key is pressed, or, Press -/R key to decrease the cycle tracking point -10 microseconds each time the key is pressed.
3. In both conditions, the S2-CS status/alarm illuminates.
4. If Function remains in the S2 position, a properly working receiver will reacquire the correct cycle tracking point and settle. The S2-CS status/alarm will extinguish.

3.10 INTERFERENCE ANALYSIS

Test mode analysis of signal conditions to localize interference from on-board equipment can be performed using the Loran unit.

1. Perform a signal analysis in accordance with the Test Mode Operation, paragraph 3.5.
2. Note the average value of the digits, particularly digit 4.
3. Energize the on-board equipment, one item at a time. Operate each item to utilize its maximum capability.
4. When an item of equipment is generating or radiating noise interference, it will be indicated in digits 3, 4, 5 by displaying lower order numbers and large fluctuations in the average value of digits 3, 4 and 5. Noise interference from on-board equipment can cause the Loran to be completely unusable. In cases such as this the operator must eliminate the interference by isolating the item of equipment causing the interference.

Interference Reduction. In many cases the effects of interference can be reduced or eliminated by relocating the antenna coupler. The following recommendations should be accomplished prior to selecting the final location for mounting the Loran Unit and the Antenna Coupler:

- * Follow the recommendations listed in the Installation Section.

- * Connect the power cable directly to the battery terminals. Do not connect the power cable to intermediate distribution terminals which carry power for other equipment.
- * Perform the Interference Analysis in the Test mode as described.
- * In all cases, the ships alternator will require some form of interference suppression. It may require use of a combination of methods. Some recommendations are listed herein.
- * Install a 20,000 Microfarad, computer grade, vented electrolytic capacitor from the alternator output terminal to the engine block or the alternator housing. Testing may be required to determine the best ground. Relocate the system voltage regulator to within 12 inches of the alternator.
- * Install shielded wires from the Voltage-regulator to the alternator, grounding the shield to the engine block or the ships ground. Testing may be required to determine the best ground.
- * Reduce the length of the main battery cables, both positive and negative cables.
- * When alternators cannot be suppressed satisfactorily, it will be necessary to replace or rebuild the alternator to eliminate the source of interference.

CERTIFICATE OF LIMITED WARRANTY

Providing you present a valid proof of purchase, SI-TEX Marine Electronics Inc. warrants all parts of each new product against defect in material and workmanship under normal use and will repair or exchange any parts proven to be defective at no charge for a period of two years for parts and one year for labor from the date of purchase, except as provided below under Limited Warranty Exceptions.

Defects will be corrected during normal working hours by an authorized SI-TEX Marine Electronics Inc. dealer, service center, or at the SI-TEX office in St. Petersburg, Florida. There will be no charge for labor for a period of one year from the date of purchase, except as provided below under Limited Warranty Exceptions.

This Warranty and Proof of Purchase must be made available to the authorized SI-TEX Marine Electronics Inc. service location or dealer at the time of service.

LIMITED WARRANTY EXCEPTIONS

SI-TEX Marine Electronics Inc. will not be responsible for equipment which has been subjected to water or lightning damage, accident, abuse, or misuse nor any equipment on which the serial number label has been removed, altered or mutilated.

SI-TEX Marine Electronics Inc. assumes no responsibility for damage incurred during installation.

This Limited Warranty is effective only with respect to the original purchaser.

Any cost associated with transducer replacement, other than the cost of the transducer itself, is specifically excluded from this Limited Warranty.

Travel cost incurred will not be accepted for SI-TEX Marine Electronics Inc. products.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE FACE HEREOF.

SPECIFIC EXCLUSIONS

Charges for overtime, stand-by, holiday, and per diem are specifically excluded from the Limited Warranty.

Chart paper, stylus, stylus belt, lamps, and fuses are consumable items and are not covered by this Limited Warranty.

Installation workmanship or materials except as provided directly by SI-TEX Marine Electronics Inc. are not covered by this Limited Warranty.

SI-TEX Marine Electronics Inc. equipment or parts thereof which have been repaired or altered except by an authorized SI-TEX Marine Electronics Inc. dealer or service center are not warranted in any respect.

Transducer, software update, battery, microphone, magnetron, and microwave components and water damage on water resistant VHF radio are items excluded from the two-year warranty and are covered by warranty for a period of one year for both parts and labor.

SI-TEX Marine Electronics Inc. will not, at any time, assume any costs or labor charges for checkout or external line fuse replacement or problems not found to be at fault in equipment itself.

THERE ARE NO WARRANTIES OR GUARANTEES EXPRESSED OR IMPLIED WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY. SI-TEX MARINE ELECTRONICS INC. HAS NO OTHER LIABILITY TO PURCHASE FOR DIRECT OR CONSEQUENTIAL DAMAGE OR ANY THEORY INCLUDING ABSOLUTE LIABILITY, TORT, OR CONTRACT. THIS LIMITED WARRANTY CANNOT BE ALTERED OR MODIFIED IN ANY WAY AND SHALL BE INTERPRETED IN ACCORDANCE WITH THE LAWS OF THE STATE OF FLORIDA. THIS WARRANTY IS LIMITED TO THE CONTINENTAL U.S.A., ALASKA, HAWAII, AND CANADA.

HOW TO OBTAIN SERVICE UNDER THIS WARRANTY

To provide better flexibility, SI-TEX Marine Electronics Inc. gives you the option of obtaining service under this warranty by either:

a) Contacting an authorized SI-TEX Marine Electronics Inc. service station (The closest service station may be found by contacting your dealer of purchase.)

or

b) Shipping your equipment prepaid via UPS or truck with insurance prepaid to SI-TEX Marine Electronics Inc. at the address provided below.

SI-TEX Marine Electronics Inc. will, whenever possible, make all repairs covered by Limited Warranty within two weeks of receiving the equipment in Florida and return same to you, freight prepaid.

c) You must present a copy of your Purchase Sales Slip at the time you request warranty service.

Shipping/Mailing Address:

SI-TEX Marine Electronics Inc.
11001 Roosevelt Blvd., Suite 800
St. Petersburg, FL 33716
727-576-5734

SI-TEX Marine Electronics Inc. offers a complete line of quality marine electronics including fishfinders, electronic charting systems, radars, autopilots, GPS/WAAS/Loran receivers, SSB receivers, direction finders, VHF radios, VHF marine & TV antennas, and integrated systems. For more information, contact your SI-TEX dealer or the main office, located in St. Petersburg, Florida.