


OPERATION MANUAL

Differential Ready Convertible Hand Held GPS

HG-7



931112411 01
SI-TEX


Switching between time to go and total time	22
NAV1 screen during route navigation	23
NAV2 screen during route navigation	23
Canceling the route navigation	23
Alarms	24
Setting and Canceling an Anchor Watch Alarm	25
What is an anchor watch alarm?	25
Setting an anchor watch alarm range	25
Setting the anchor watch alarm	25
Canceling the anchor watch alarm	25
Setting and Canceling a Proximity Alarm	26
What is a proximity alarm?	26
Setting a proximity alarm range	26
Canceling the proximity alarm	26
Setting and Canceling a XTE Alarm	27
What is an XTE alarm (course deviation)?	27
Setting an XTE alarm range	27
Canceling the XTE alarm	27
Setup Procedure	28
Menu options	28
Selecting a Menu option	28
Monitoring GPS satellite signal reception	29
Changing the distance, speed or altitude unit	29
Selecting a geodetic datum	29
Displaying position data in LAT/LONG mode	30
Displaying position data in Loran C LOP mode	30
Changing Loran C chain	30
Changing the least significant digit of LAT/LONG position	30
Correcting your position	31
Selecting a measuring system mode	33
Compensation of compass	34
Setting antenna height (above sea level)	35
Setting average constants (measuring position, speed and course) ..	35
Setting off timer (Power saving)	35
Accumulated OP. (operation) time	36
Displaying local time	36
Displaying differential GPS (DGPS)	37
DGPS measurement	37
Setting a DGPS alarm	37
Setting a DGPS timeout	38
Monitoring DGPS measurement	38
Selecting and editing an output format	39
Calculating Loran C LOPs based on LAT/LONG data	40
Calculating the distance and bearing between two points	41
Troubleshooting Guide	42
Nothing appears when you press PWR/DIM key	42
No information appears on the screen (during initial setup) ..	42
Error message appears as you power on (Self-test function) ..	42
Nothing appears but buzzer sounds during power-on	43
Unstable signal reception	43
Fuse replacement	43
Specifications	44
Major Specifications	44
Standard equipment list	45
Options	45
Outline and Dimensions	46
Interconnecting Diagram	46
Installing	47
Installing batteries	47
Installing carrying strap	48
Installing shoulder belt	48
Installing mounting bracket	48
Installing the antenna at remote position	49
Using a GA-06 as external antenna	51
Local Geodetic systems	52

For Proper Operation


GPS signal reception (HDOP or PDOP)

The accuracy of position determination with GPS is affected by the geometrical position of satellites and the accuracy of the ranging to the satellite.

- The satellite geometrical position in comparison to the user is expressed in the Geometrical Dilution of Precision, GDOP (or DOP). Roughly speaking, the more "spread out" the satellites are, the better accuracy of the position. When the satellites are bunched together, the position may not be as accurate as normal.
- GPS receiver usually employs an algorithm which selects satellites based on the lowest DOP in accordance with satellites moving.
- Horizontal DOP (HDOP) is for the horizontal (lat/long) aspect of the error: 2-dimensional navigation.
- Position DOP (PDOP) is for both horizontal (lat/long) and vertical (altitude) aspect of error: 3-dimensional navigation.



HDOP vs Range Error



Note:

- The value of DOP changes with time because all satellites move in orbit. As a result, even if the GPS receiver is fixed to a certain point, the value measured by the geometrical position is not fixed at all times.
- When satellites are positioned near the horizon (lower elevation), you cannot receive the GPS signal because of the interruption by mountains, buildings, etc.
- The GPS signal reception is not possible in a room. Please make sure to put the antenna in open site, away from any obstacles.
- The bearing data obtained from the GPS navigation system is a reference from the true north.

Time to fix position

It takes more time to fix position in the following cases.

- When you use your GPS receiver for the first time.
- When the stored orbital data is not suitable for the available satellite, or purged due to lengthy storage.
- When you use it after moving a long distance.

NAVIGATOR shortens position calculating time by storing the orbital data sent from the available satellites. When you first switch on the receiver, it may take about 15 minutes before the first fix is made. From the second operation, the receiver can fix your position within a minute because of stored satellite data from the previous operation.

When it takes more than 30 minutes, carry out the following operations:

- (1) Press the **OFF** key to turn off the power.
- (2) Press and hold the **POWER/DIM** key to turn on the power again.
- (3) Press the **ENT** key while "Checking" is displayed.
- (4) Move the cursor to "1. INITIALIZE" and press **ENT** key.

Tips for mounting GPS Receiver

Avoid following locations or situations:

- A place exposed to direct sun or near a heating device.
- A place adjacent to Magnetic Compass.
- A place exposed to strong vibration or shock.


Special note for LCD (Liquid Crystal Display)

Avoid following conditions to insure good LCD visibility.

- Long-time exposure to direct sun rays or UV.
- Extremely hot (surrounding temperature more than 50°C, 120°F) or cold (less than 0°C, 32°F) environment.

Getting Started

When you first use NAVIGATOR, it must receive new orbital data from the satellites and it may take approximately 15 minutes to display your position (**COLD START**). Once this step is completed, your position is displayed immediately any time you wish. To make NAVIGATOR operational (to store orbital data of GPS satellites in system memory), use the following steps.



Lift and keep the antenna plane horizontal for position fixing.



Press for 3 seconds to power on. This is to avoid unnecessary battery consumption by accidental power on.

On-screen messages change in the following sequence when NAVIGATOR receives satellite signals.

Dim/bright the display:



Press to dim/bright the screen.

GPS
ROM No. KM=A46
checking

Initial message.
Self checking function in process.

Change the contrast:



Press to change display contrast (intensity) in 4 levels.

GPS
ROM No. KM=A46
check OK

Second message.
Self checking function completed.

Power off:



Press for 2 seconds to turn NAVIGATOR off. All data before power-off is kept in memory for later use.

GPS
Flip up ANTENNA
before operating

Flip up the antenna on the back side of the unit to horizontal position so that reception of satellite signals will not be impaired.

What is failure of positioning?

If signals from three or more satellites are not received, your position cannot be fixed.

Blinking
NAVI 27°54.008N
82°41.613W
SPEED 15.0kt
COURSE 359.9°

Blinks while GPS satellites are being searched or interrupted.

OP. TIMER of MENU 8-4 should be cleared when batteries are replaced.

No blinking
NAVI 27°54.008N
82°41.613W
SPEED 15.0kt
COURSE 359.9°

When signals from 3 or more satellites are received, present latitude and longitude position with solid N (or S) and W (or E) is displayed.


Remove internal batteries when the unit is in storage to avoid damage by corroded batteries.

NAVI
SPEED 15.0kt
COURSE 359.9°

If position is not obtained:
The data from previous operation is displayed. However, if you initialize, again the memory data is erased and no data is shown.

Operation by built-in simulator

The built-in simulator helps you practice operation before you use it in the field. Only a power source is required to turn on the unit. You enter the starting position of the simulated navigation at point number 150 in lat/long referring to "Storing Waypoints" (page 11). Then, turn the unit off. Turn the unit on again by pressing **PWR/DIM** key and press "4" key while **"CHECK OK"** is displayed on the screen. Your position draws a circle from the position in point number 150 at 10.0 kt speed with 0.1 nm radius. It takes about 3 min. 40 seconds for each circle. You can try every function of the unit as if in practical operation. Simply turn the power off to get back to normal operation.



Start position entered at point number 150.

How to Find Out Your Position

You can find your position by simply reading the present latitude and longitude on the screen.

MODE

Press this key to recall NAV1
(Navigation 1) screen.

NAV1 screen

NAV1	27°54.005N	Present position
	82°44.824W	North or South latitude
		East or West longitude
SPEED	15.0kt	Speed in knots
COURSE	359.9°	Bearing in degrees

Blinks if positioning is interrupted.

Note: Positioning interruption

If NAVIGATOR has failed to receive signals from GPS satellites, it shows speed of zero (0) but keeps the last LAT/LONG and course data.

- Present position can also be shown as Loran C LOPs (see Page 30 for Loran C LOPs display).
- Speed can be shown in different units (see Page 29).

Storing present position (EVENT)

Event key stores position automatically.

EVT

CLR


Returns to previous
display screen.

Press this key to store the present position. You can store up to 20 points. The oldest data will be replaced with new data when you've used 20.

You can also store the present position (memory number 000) using **MOB** key.

I'm storing
present
position...

Present position
Track



Last event point
number is shown.

EVT	27°38.145N
	82°43.280W
001	27°54.008N
	82°41.613W

The position data of
event point number 001.

Recalling event or MOB position

MENU

1

Enter an event number (one of point number 000 to 020) you wish to recall. Point number 000 contains the position data when you have pressed **MOB** key.

Select 1: **WAYPOINT**.

Press until Menu options 1 to 4 appear.

Specified event point
number is shown.

Event or MOB position
is recalled.

WP1-001=	
	27°38.145N
	82°43.280W

CLR


Use this key if you have entered
an incorrect number. You can
reenter an event point number.

How to Get Distance and Bearing to WPT

You can obtain the following navigation information to the waypoint (WPT)

- Distance and bearing from present position to a WPT or the final destination
- Ship's speed and time to go

You can store up to 130 points (numbers 021 to 150).



Navigation to WPT

Use the following steps (see Page 11 for operation details).

1. Determine your waypoints and/or final destination from sea charts or other sources.
2. Store latitude and longitude data of waypoints.
3. Create a route by combining waypoints and events.
4. Start navigation.

Waypoint navigation

"Prepare to sail.
Power On! Everything OK!"

See Page 6 for operation.

Setup
"We'll sail to point 107 to-
day. Set it as waypoint."

See Page 17 for setup.

"Check bearing and distance.
Now, let's go!"

Store event
"A buoy! Store this position."

See Page 8 for storage.

Waypoint
107

Course line

Route navigation

Waypoint advance range during
route navigation

Route navigation See Page 20 to select route navigation.

See Page 15 to store a route.

See Page 26 to set proximity alarm.

When you enter the proximity range,
the course is set to the next point
automatically.


091

083

137


132

Skiping name entry




Changing position data


You can not edit a waypoint position data when the point number is used as a waypoint or in a route navigation. **NO EDITING** message will be displayed.



Erasing a single route




Erasing entire data from memory




Note: All waypoints and routes are permanently lost after performing this step.

Reentering the point of origin in waypoint navigation


Once reset, the present position is used as the new point of origin for waypoint navigation.



NAV1 screen during waypoint navigation




NAV2 screen during waypoint navigation




Canceling waypoint navigation

To cancel waypoint navigation, turn WPT to OFF on NAV2 screen.





Route Setup

Following procedure shows how to set up a new navigation route using previously entered route number and route point number. Recall the first waypoint in NAV2 screen, by entering the route and route point number respectively. If you want to trace back the route, the direction of navigation can be reversed.



Selecting route navigation

You navigate on a route, following the course line, which is automatically updated as you enter each point. You can also reverse the navigation route to return to the start point.



What is the route point number?


ROUTE: 01→005/014
053→102→105→
110→33→091→
083→137→025→

Order on the route:
001→002→003→
004→005→006→
007→008→009→

Example: Waypoint 32 is the 5th waypoint in this route.

Point number
Press ▼ or ▲ key to scroll the screen.

Switching between distance to WPT and total distance



To switch the display between the distance (DIST) to the next waypoint and the total distance (T. DIST) to the final destination:


When "DIST (Distance)" is shown:
The distance to the next waypoint is shown.
When "T.DIST (Total Distance)" is shown:
The total distance required to arrive at final destination is shown (9999 nm, sm, km maximum).

9999 Positioning has failed or the required distance has exceeded 9999 nm, sm, or km.

NAV1 screen


NAV1 27°54.008N
7083 82°41.613W

Display field 1
Display field 2



DIST 27.3nm Press key. T. DIST 627.3nm
Press key.

Switching between time to go and total time



To switch the display between the time to go (TTG) to the next waypoint and the total time (T.TTG) required to the final destination:


When "TTG (Time to Go)" is shown:
The time to go to the next waypoint is shown.
When "T.TTG (Total Time)" is shown:
The total time required to arrive at final destination is shown (99 hours 59 minutes maximum).

99h99m Positioning has failed or the in route time has exceeded 99 hours 59 minutes.

NAV1 screen


NAV1 27°54.008N
7083 82°41.613W

Display field 1
Display field 2



TTG 02h21m Press key. T. TTG 32h21m
Press key.


Alarms




Setting and Canceling a Proximity Alarm

What is a proximity alarm?


The buzzer sounds when you have arrived at the waypoint during waypoint or route navigation. This alarm is set automatically when you have selected the waypoint or route navigation. However, the proximity alarm does not operate if its alarm range is set to 0.00 or if an anchor watch alarm has been set. (Initial set :0.00)



Setting a proximity alarm range




Canceling the proximity alarm



Setup Procedure

Menu options




1. **Waypoints**
Store, edit, copy, and erase waypoints.
(see pages 11 to 19).
2. **Differential GPS (DGPS)** See page 37.
Select DGPS mode.
Set DGPS timeout.
Monitor DGPS data.
3. **GPS**
Display GPS satellite status.
Switch (2- and 3-dimensional) positioning modes.
Set antenna height (above sea level).
Select datum.
4. **Select or remove corrections.**
Position correction (LAT/LONG or Loran C LOPs)
Compass correction
Set the time difference.
5. **Route**
Store, set, cancel, and erase a route
(see pages 11 to 16 and 20 to 23).
6. **Alarm**
Enter alarm range and disarm alarms
XTE alarm
Proximity alarm
Anchor watch alarm
DGPS alarm See page 37.
7. **Calculation**
Distance and bearing between two points
LAT/LONG into LOPs data conversion
8. **Initial value setup**
Set average constants.
Select distance, speed, and altitude units.
Select and edit the output format.
Set off timer.
9. **Display**
Select the position indication (LAT/LONG or Loran C LOPs).
Select 1/1000 or 1/100 minute in LAT/LONG position.
Accumulated operation time.


Selecting a Menu option

You can select an option on the Menu screen in two ways: by direct numeric number entry and by selection using cursor. This manual explains numeric key entry for easy understanding, but you can also use the cursor for option selection. The following compares these two methods when you check the GPS satellite signal monitor status (page 29) as an example:

Numeric number entry




cursor selection




Displaying position data in LAT/LONG mode

You can select the LAT/LONG or Loran C LOPs mode for position display.




Displaying position data in Loran C LOP mode

You can convert both your present position given by GPS and stored position data (waypoints and event data) from LAT/LONG into Loran C LOPs.




Changing Loran C chain

You can convert both your present position given by GPS and stored position data (waypoint and event data) from LAT/LONG into Loran C LOPs.




Changing the resolution in LAT/LONG position

You can select the resolution of LAT/LONG position between 1/1000 minute and 1/100 minute.



When your present position is indicated in Loran C LOPs mode, you can correct it by entering the Loran C LOPs correction amount.




Secondary 2 station correction amount
Secondary 1 station correction amount

CLR Press to clear incorrect input.
You can reenter numeric data

Check the correction amount


You can check the correction amount as follows:



Your position has been corrected by
1.5 microseconds to the secondary.
Your position has been corrected by
1.1 microseconds to the other secondary.

Compensation of compass


The course and bearing to waypoint are shown in true bearing. You can adjust the GPS true bearing to the magnetic compass bearing.



Automatic compensation


(Initial setup: Auto)

In the Auto mode, the magnetic compass is compensated based on the built-in global magnetic variation maps. However, avoid using this mode if you are higher than 75 degrees North or South latitude. Also, the compass may have a small error as the system contains world maps. Correction manually is recommended.



Manual compensation

(Initial setup: 0°)
(Setup range: -180.0° to +180.0°)




Accumulated OP. (operation) time

(Initial setup: 00:00)

This function displays the accumulated operation time with batteries. Typical alkaline battery's op. time is about 10 hours, and standard battery's op. time is about 4 hours, when the backlight of the display is off.

9 : 1 : DISP L / L
2 : GRI 7980-1-4
3 : L / L UNIT.001
4 : OP. TIME 00b00

— cursor



Press to display Menu option 9.


Press until Menu options 1 to 4 appear.

The unit will automatically shut off when battery voltage becomes lower than minimum operating voltage.

Displaying local time

(Initial setup: 00:00)

You can display your local time by entering a time difference from the Greenwich Mean Time (GMT). See the following chart to determine zone time difference.



Press until Menu options 1 to 4 appear.

CLR Press to clear incorrect input. You can reenter numeric data.

Correction of input error

Move — cursor onto incorrect number and enter correct one.


MENU 1 : WAYPOINT
2 : DGPS
3 : GPS
4 : COMP

4-4 : TIME

+00:00

4-4 : TIME


-05:00



Setting a DGPS timeout

(Initial time: 100 sec)

If the correction data from a beacon receiver is interrupted or with errors, NAVIGATOR holds the last differential correction for the duration of the time out. You can set TIMEOUT to 10 to 180 seconds. However position accuracy degrades as TIMEOUT becomes longer.




Note: Timeout can be set from 010 to 180 seconds.

Correction of input error

Move cursor onto incorrect number and enter correct one.

Monitoring DGPS measurement

You can monitor RTCM SC-104 format data sent from beacon receiver. If the communication fails due to baud rate matching error or others, an Error message appears.



HEALTH indicates health status of reference station.


0 is best. Reliability degrades as the number increases up to 5.

6 indicates reference station not monitored.

7 means reference station not working.

Calculating Loran C LOPs based on LAT/LONG data

When you enter a Loran C chain number and the first digit of two secondary stations, NAVIGATOR calculates the Loran C LOPs based on the specified LAT/LONG data and displays the LOP values.



Note : You must have a real-time GPS position to use this feature.

Troubleshooting Guide


If NAVIGATOR does not function properly, check the following items. If the problem continues, call for service.

Nothing appears when you press PWR/DIM key

Check the following points:

- Blown fuse
- Low battery voltage
- Poor contact of external power cable to display unit
- Poor contact of external power cable to battery socket


WARNING! Always turn Off the power supply before replacing the fuse.



No information appears on the screen (during initial setup)

Check the following points.

- The antenna cable may not be connected securely between the antenna and receiver.
- If signals not received, or key operation not effective, try the following steps.



When the above procedure is carried out:

- The stored position data is NOT lost even when you perform these steps.
- The present positioning data is erased and NAVIGATOR returns to the initial setup.
- All setup parameters are initialized and you need to set them again.

Error message appears as you power on (Self-test function)

<p>GPS ROM No. KM=A46 checking</p>	<p>Error message list</p> <table> <tr> <td>BACKUP ERROR</td><td>An error has occurred in backup RAM.</td></tr> <tr> <td>ROM changed</td><td>A checksum error has occurred.</td></tr> <tr> <td>RAM ERROR</td><td>A RAM error has occurred.</td></tr> <tr> <td>ERR RAM adrs</td><td>An error has occurred in backup RAM.</td></tr> <tr> <td>ERR RAM data</td><td>Mismatching between write and read data has occurred.</td></tr> <tr> <td>ERR LSI</td><td>An KCD-57 internal error has occurred.</td></tr> <tr> <td>RTC ERROR</td><td>An RTC operation error has occurred.</td></tr> </table>	BACKUP ERROR	An error has occurred in backup RAM.	ROM changed	A checksum error has occurred.	RAM ERROR	A RAM error has occurred.	ERR RAM adrs	An error has occurred in backup RAM.	ERR RAM data	Mismatching between write and read data has occurred.	ERR LSI	An KCD-57 internal error has occurred.	RTC ERROR	An RTC operation error has occurred.
BACKUP ERROR	An error has occurred in backup RAM.														
ROM changed	A checksum error has occurred.														
RAM ERROR	A RAM error has occurred.														
ERR RAM adrs	An error has occurred in backup RAM.														
ERR RAM data	Mismatching between write and read data has occurred.														
ERR LSI	An KCD-57 internal error has occurred.														
RTC ERROR	An RTC operation error has occurred.														

Error message display area

- If you have replaced the ROM chip, the **ROM changed** message may appear. In this case, turn on the power switch again.
- If display of **ERROR** message is in the above table, **CHECK START** and **END checksum** is sequentially repeated, call for service.

Specifications


Major Specifications

GPS receiver section	
Receiving frequency	1575.42 MHz \pm 1 MHz
Receiving channel	Digital 11-channel parallel/sequential
Receiving code	C/A code
Sensitivity	Better than -130 dBm (elevation angle: 5° or over)
Tracking speed	200 knots maximum
Accuracy	15 meters RMS (without SA), 100 meters 2DRMS (with SA)
(PDOP \leq 3)	0.1 knot RMS (without SA)
Note: Accuracy is subject to change in accordance with DoD civil GPS user policy.	
GPS display section	
Display	LCD with backlight (16 x 4 characters, usual picture area: 56.9 x 27.2 mm)
Display mode	NAV1, NAV2, NAV3, MOB (Man Over Board), MENU
Position data display	Latitude/longitude in increments of 1/1000 minute or converted Loran C LOPs
Differential	ON, OFF, AUTO
Navigational display	Speed, course, velocity made good/course made good/elapsed time, altitude, distance/bearing/cross track error/course deviation/time to go to waypoint, total time to go and distance on route, DOP value, present time (UTC or LTC), satellite status, distance/bearing between two points, MOB display, operation time, off timer
Instant (event) memory	20 points
Waypoint memory	130 points (usable as waypoint)
Route memory	10 routes (Max. 130 waypoints) with reverse trail
Alarm	Proximity, cross track error, anchor watch, DGPS
Position compensation	latitude/longitude, Loran C LOPs, Datum
Magnetic compensation	Auto or manual
Parameters	LOP conversion, memory of waypoints and name (up to 8 letters), selection of measuring unit (nm,sm,km), antenna height, averaging (smooth) factor, position mode (2D or 3D automatic selection)
Input data format	RTCM SC-104 (for DGPS: 4800 baud rate)
Output data format	NMEA-0183 (AAM, APB, BOD, BWC, GGA, GLL, GSA, GSV, GTD, RMB, RMC, SGR, VTG, WDC, WPL, XTE, and ZDA), NMEA 1, NMEA 2, CIF, SHIPMATE 0183
Data output interval	1 second (CIF, SHIP, and NMEA 1), 3 seconds (NMEA 2), and 1 to 99 seconds selectable (NMEA-0183)
Data level	RS-232C
Memory protection	By built-in battery
Power supply	4AA alkaline/mangan batteries or 9 to 35 VDC
Power consumption	2 W or less (9 to 35 VDC)
Environmental condition	Display unit: -10° to +60°C (14° to 140°F) Antenna unit: -30° to +70°C (-22° to 158°F)


* Specifications subject to change without notice.

Outline and Dimensions

Scale differs among drawings.





Interconnecting Diagram




Installing carrying strap



Attach the wrist strap as shown for hand carry convenience.




Installing shoulder belt




- (1) Pass the belt end through the ring at side of carrying soft case.
- (2) Pass the belt end through the ring on the belt.

Installing the mounting bracket

Optional – Not included



- (1) Install the base with screws supplied at desired installation site.
- (2) Set the bracket at desired angle and set it using the knob.
- (3) Slide unit to the bottom with the guide rail fitting into the groove.
- (4) Secure the unit to the mounting bracket with the fixing screw.



Local geodetic systems

In alphabetical order				In numerical order			
Name	No.	Name	No.	No.	Name	No.	Name
ALASKA/CANADA	04	LIBERIA 64	57	00	WGS-84	43	CHATHAM
ARC 50	29	MAHA 71	58	01	WGS-72	44	PARAGUAY
ARC 60	30	MALAYSIA	23	02	TOKYO	45	BRAZIL
ARGENTINA	39	MALDIVE	48	03	NAD-27	46	NEW GEORGIA
ASCENSION	31	MARCUS	35	04	ALASKA/CANADA	47	EASTER
AUSTRALIAN 84	06	MARSHALL	82	05	EUROPEAN 50	48	MALDIVE
BAHRAIN	27	MASCARENE	73	06	AUSTRALIAN 84	49	GUAM 63
BERMUDA	37	MIDWAY 61	62	07	SOUTH ASIA	50	GUADAL CANAL
BRAZIL	45	MOROCCO	61	08	SOUTH AMERICA	51	HONG KONG 63
CANARY	68	NAD-27	03	09	GREENLAND	52	DIEGO GARCIA
CAYMAN BRAC	56	NAD-83	10	10	NAD-83	53	JOHNSTON
CHATHAM	43	NEW GEORGIA	46	11	ICELAND 55	54	SRI LANKA
COCOS	28	NEW ZEALAND	13	12	IRELAND 65	55	KELGUELEN
COLOMBIA	38	NIGERIA	63	13	NEW ZEALAND	56	CAYMAN BRAC
CORVO/FLORES	65	OMAN	67	14	EUROPEAN 79	57	LIBERIA 64
DIEGO GARCIA	52	PARAGUAY	44	15	ROME 40	58	MAHA 71
DJAKARTA	22	PHILLIPPINES	19	16	SOUTH AFRICA	59	SALVAGE
EAST FALKLAND	76	PHOENIX	40	17	SAUDI ARABIA	60	ERITREA
EAST MALAYSIA	79	PITCAIRN	69	18	INDIAN/NEPAL	61	MOROCCO
EASTER	47	PORTO SANTO	77	19	PHILLIPPINES	62	MIDWAY 61
EFATE	36	PUERTO RICO	71	20	ENGLAND	63	NIGERIA
EGYPT	66	QATAR	72	21	HAWAII	64	TRINIDAD
ENGLAND	20	ROME 40	15	22	DJAKARTA	65	CORVO/FLORES
ERITREA	60	SALVAGE	59	23	MALAYSIA	66	EGYPT
ETHIOPIA	25	SANTA MARIA	75	24	JAPAN	67	OMAN
EUROPEAN 50	05	SANTO	74	25	ETHIOPIA	68	CANARY
EUROPEAN 79	14	SAUDI ARABIA	17	26	SOMALIA	69	PITCAIRN
FAIAL	78	SOMALIA	26	27	BAHRAIN	70	SOUTH CHILE
FIJI	81	SOUTH AFRICA	16	28	COCOS	71	PUERTO RICO
FINLAND	84	SOUTH AMERICA	08	29	ARC 50	72	QATAR
FLORIDA	41	SOUTH ASIA	07	30	ARC 60	73	MASCARENE
GREENLAND	09	SOUTH CHILE	70	31	ASCENSION	74	SANTO
GUADAL CANAL	50	SRI LANKA	54	32	IWO JIMA	75	SANTA MARIA
GUAM 63	49	ST. HELENA	34	33	TERN	76	EAST FALKLAND
HAWAII	21	SURINAM	83	34	ST. HELENA	77	PORTO SANTO
HONG KONG 63	51	SWEDEN	85	35	MARCUS	78	FAIAL
ICELAND 55	11	TERN	33	36	EFATE	79	EAST MALAYSIA
IRELAND 65	12	TOKYO	02	37	BERMUDA	80	TRISTAN
INDIAN/NEPAL	18	TRINIDAD	64	38	COLOMBIA	81	FIJI
IWO JIMA	32	TRISTAN	80	39	ARGENTINA	82	MARSHALL
JAPAN	24	TUNISIA	42	40	PHOENIX	83	SURINAM
JOHNSTON	53	WGS-72	01	41	FLORIDA	84	FINLAND
KELGUELEN	55	WGS-84	00	42	TUNISIA	85	SWEDEN

NOTES PAGE