

SP120C Autopilot

User Manual (v3)



SI-TEX Main Office Address:
25 Enterprise Zone Drive, Ste 2
Riverhead, NY 11901
Tel: +1-631-996-2690
Email: service@si-tex.com
Web: www.si-tex.com

IMPORTANT: PLEASE RETAIN ON BOARD

(This page intentionally left blank)

Contents

Warnings	2
Important Installation Notes	3
Installation Tools Required	3
Overview	4
Standard Equipment	4
Additional Equipment Required	4
System Block Diagram	5
System Components / Installation Guides	5
SP120C Control Display Unit	5
Installation Dimensions and Guide	6
Electronic Compass	6-7
Rudder Feedback Unit	8-10
Installation and Wiring	11-13
System Operation	13-14
Steering Modes	13-14
Display Screens	15
System Settings	16
Pilot Settings	16-19
Advanced Menus	20-21
Initial Setup (Installers Instructions)	22
Calibration	22
GPS Settings	25
Other Menu Items	26
Setting Up And Configuring Your GPS System	26
Initial Inspection And Testing	28
Dockside Tests	28
Error Messages	29
Alarms	29
Trouble Shooting	30-31
Warranty	32
Additional Information	33
Contact Information	34

Warnings

- The autopilot is a navigational aid; an adequate watch must be maintained at all times when autopilot is in use.
- The autopilot must be placed in manual mode when the vessel is stationary as the system may continue to drive the rudder to the end of its travel and damage to the system may result.
- It is strongly recommended that the autopilot not be used while navigating in restricted waterways as water currents, wind changes or radio transmitter interference can endanger your own or other vessels.
- It is recommended to install a rudder feedback unit for best performance; otherwise the system will not operate in auto / gps mode unless the vessel is moving at a configurable minimum speed.

Important Installation Notes

- Access for wiring must be provided. cables will possibly need to be run or extended if required, to the vessels switchboard, SP120C display, e-compass, rudder feedback (if fitted) and drive unit.
- SP120C cables and equipment must be located as far as possible from transmitting equipment and cables (e.g. radio aerials and aerial cables, radars, inverters, ect) to prevent electro-magnetic-interference.
- The e-compass must be mounted a minimum distance of 1 meter from other magnetic compasses, radios, speakers, transmitting equipment or other products with magnetic properties, to avoid interference.
- The SP120C must have a direct connection to power supply via a 15 amp circuit breaker or a 15 amp fused circuit and an isolating switch.

Installation Tools Required

- Screwdrivers – flat blade and phillips head
- Side cutting pliers
- Wire strippers
- Spanners (various) or adjustable spanner
- 75mm hole saw
- Power drill + assortment of drill bits
- Multi meter (dvm)
- Ancillaries such as tape, terminal block, screws, cable ties, etc.

Overview

Standard Equipment

- SP120C CDU 'Control Display Unit'
- ELECOM - electronic compass / e-compass
- RFUS - rudder feedback unit (optional)

Additional Equipment Required (not standard supply)

- 1. Drive motor** – to allow the SP120C to control the vessels steering system.
 - Hydraulic steering systems with a helm pump and ram will require one of the following;
 - Reversing hydraulic motor/pump-set, tapped into the existing hydraulic steering system or;
 - A constant running hydraulic pump with direction control solenoids.


A mechanical steering system will require;

- a reversing mechanical drive, connected to the existing steering ram mechanism.

2. Termination hardware;


- Terminal blocks (suitable for 0.75mm² and 2.5mm² cables)
- Circuit breaker / switch (15A rated)
- Wiring extension cables / ferrules / crimp lugs & related crimp tools
- 2c x 2.5mm² for extending motor and power cables (larger for long cable runs)
- 1 pair 0.75mm² for each nmea interface cable

System Block Diagram




System Components / Installation Guides

SP120C - Control Display Unit

- Steering control system for 4.0m - 16m vessels;
 - 'Virtual Rudder Feedback' feature, where no RFU requires to be installed.
 - 3 Control Modes – Manual Mode, Auto Mode and GPS mode
 - Live indication for 'Steering mode', 'Position & Waypoint Info', 'Heading', 'Course to Steer', 'Rudder angle', 'System Voltage' and 'Drive Current'
 - Supports all current NMEA-0183 interface standards;
 - Heading: HDG, HDT, THS, HDM/ ROT & COG
 - GPS: APA, APB, XTE, BOD, BWC & RTR *for GPS steering mode
 - GLL, RMC, SOG, VTG *for visual indication and assisting AUTOPILOT control
 - 30cm fly-lead for drive motor and power connections
 - 6 pin LTW connectors for Compass and Rudder/NMEA-0183 interfaces
 - Power: 12-24 Volts DC (Up to 29V During Charging)
 - Drive output up to 35A. *If current exceeds 35A, the drive output is inhibited.
 - Software controlled rudder limits, inhibits drive control at each mechanical limit.
- 
- Additional auto switching fail safes, in case of failure of RFU or E-compass;
 - If RFU fails, the system will revert to Non-RFU mode automatically.
 - If a GPS system is connected and the standard supplied E-Compass fails, the SP120C system will automatically revert to GPS 'COG' mode for heading reference.

Installation

SP120C CDU Installation Dimensions



SP120C CDU Installation Guide

- The SP120C Head unit should be mounted in a position accessible to the steering position and protected from direct rain or salt water.
- For in dash mounting cut a 75mm (3.0") hole
- An optional mounting bracket is available and may be used for desktop mounting - see your supplier
- Drill mounting screw holes
- Mount the display using screws supplied (304 SS – 6G)

NOTE: Use the protection cover when the system is not in use, to protect the screen and casing from UV and other physical damage

ELECOM Electronic Compass (E-Compass V.3)

Take care when handling the compass as it is a sensitive piece of equipment.

The compass position is the most important item in the installation of the autopilot. Good course holding is dependent on the compass being free from magnetic interference and excessive rolling or pitching.

E-Compass Specifications:


- Output based on NMEA 0183 standards
- Protocol Settings: 4800–8–N–1
- Output Sentences: HDM & ROT
- Power supply: 12-24 VDC <1Watt
- No moving parts to prevent mechanical wear-out, small size and high reliability.

- Solid state electronics with tilt and roll compensation up to 35degrees.

E-Compass Installation Guide:

- **IMPORTANT!** The compass must be fitted in an area at least 1 meter away from steel objects.
- Avoid positions near radios, speakers, aerials, antenna cables or any other current carrying cables.
- Select a dry position free from magnetic interference.
- If system is fitted to a steel hull vessel, the compass must be mounted at least 1m above the steel structure on a non-magnetic post or bracket (aluminium and wood are good options in this case)
- A lower / aft mounted position along the centre of the hull is preferred, to reduce the influence of vessel roll and pitch.
- Check other side of bulkheads and deck heads for magnetic interfering type objects before mounting.
- Mount the compass horizontally with the arrow (bow) pointing to the front of the vessel, preferably on a stainless steel, wooden or plastic bracket.
- Use non-magnetic screws to mount the compass unit (316 grade stainless steel)
- The unit must be mounted on a flat horizontal surface.
- Before selecting the E-compass installation position, it is good to test the installation position is free from interference by checking the location with a portable magnetic compass.

E-Compass Dimensions



Rudder Feedback Unit


Rudder Feedback Unit (RFUS)

The RFU is optional, although recommended for the best possible performance on some types of vessels.

For example: A RFU must be installed on vessels with high sides that are sensitive to winds turning the boat, or high powered 5-6m Deep V (22-25 deg dead rise / 175HP+) type vessels used in rough seas and high winds. Or any other vessels that are overly sensitive and very responsive to small amounts of 'rudder' at high speeds.

When the RFU is installed, the configuration settings are simplified. Non-RFU mode is slightly more complicated.

NOTE: *The RFUS is factory aligned. The arm should not be removed or loosened. It is also water resistant, however, if mounted in a wet position some protection should be provided to prevent water damage or physical damage.*




RFU Installation Guide


1. Refer to installation diagram and installation template supplied with the unit
2. Mount rudder feedback adjacent to the tiller (**NOTE:** *rudder feedback movement must copy the angular movement of the tiller like a pendulum*)
3. Use a mounting bracket if required.
4. Note the markings on the rudder feedback unit. 'P & S' (Port and Starboard) to check ruder moves in the correct direction, manually, before testing on the water.
5. Check installation is suitable by slowly moving the steering manually, to ensure:
 - a. The direction indicated on the top of the RFU is correct
 - b. No undue mechanical strain is placed on the feedback or linkage. (Also check for strain when the tiller is tilted upright (for outboard engine installations)
6. To complete the install, use the SP120C advanced menu to calibrate the rudder limits and centre point of the RFU.

Rudder Feedback Unit


Installation Diagram



Example RFUS installations for outboard engines:




Rudder Feedback Unit




Installation & Wiring

Reversing pump or linear drive systems



Solenoid Controlled Systems




Wiring Information

Solenoid Valves - Important Information

If an emergency jog lever is fitted then the motor outputs must be isolated! to prevent damage to the drivers. To isolate, a 2 pole change over relay must be installed between the SP120C and the Solenoids, as per diagram below;

Also as a preventative measure to ensure voltage spikes do not interfere with the AUTOPILOT or other equipment, spike suppression diodes should be fitted on solenoid valves.




Rudder Connector

Pin connections from rear of plug, solder connection side.

NOTE: Pin 1 has dot adjacent.

- Pin 1 5V RFU Supply
- Pin 2 RFU Wiper
- Pin 3 0V RFU Supply / TX- RS-232 GND
- Pin 4 TX+ RS-232 Data + (heading information)
- Pin 5 + GPS Input (Positive)
- Pin 6 - GPS Input (Negative)



Supplied GPS Cable (for NON-RFU models)

The standard system is supplied with a short 4 core 30cm fly-lead, for wiring direct to a GPS unit. See below for the color codes used for external connections;

NMEA input from GPS:

- Pin 5 +GPS Input (Positive) White wire
- Pin 6 - GPS Input (Return) Green wire


NMEA output for Heading data to external systems:

- Pin 4 + Heading Data Out (Positive) - Red wire
- Pin 3 - Heading Data Out (Negative) - Blue wire (0 volt line)

NOTE: For further interfacing information, refer to the installation manual supplied with your GPS unit.

Wiring Information - continued

Rudder Feedback Unit Wiring



System Operation

Steering Modes


After initially powering on the system the SP120C will always return to MANUAL mode

If AUTO or GPS mode is active, press once to return.

To control the rudder manually in this mode, press;

To drive the rudder to PORT

To drive the rudder to STBD




AUTO MODE

To enter AUTO mode, press the button

To change / set the desired course to steer, press or to increase or decrease the desired heading value to steer to.

To disengage AUTO mode, press to return to Manual Mode.



Continued next page

System Operation


Steering Modes - Continued

GPS MODE


To enter GPS mode, press both **MODE** & **AUTO** simultaneously. Before enabling this mode, ensure the GPS system has an activated waypoint, cursor or route, for the SP120C to follow. The boat will change course to steer at the maximum rate of turn, so it is recommended to ensure the vessel is heading towards the first GPS target at a suitable speed before enabling.


To disengage GPS mode, press **AUTO** to return to Manual Mode.

In this mode, the AUTOPILOT must be interfaced to a GPS generating NMEA 0183 data output. The GPS will also require configuration to ensure correct sentences and settings are suitable.




To **DODGE** an obstacle while in GPS Mode Press;


 To dodge by steering the vessel to PORT

 To dodge by steering the vessel to STBD


Display Screens



Manual Mode



Auto Mode




GPS Mode

NOTE: Rudder Angle indication will not be displayed in Non-RFU mode.

Motor Drive Concept

During AUTO or GPS modes, the system will pulse the drive motor when it is close to the desired target heading. This allows the system to make minor adjustments to the rudder to stay on course. Also note the dead band (relating to the rudder sense setting) this accounts for excessive play in the rudder and reduces the rudder 'hunting' effect.



System Settings

Pilot Settings

To access the SP120C Settings menu

Press the **MODE** button.

NOTE: *SP120C Settings can be modified at any time, while using any of the modes.*

To increase or decrease any SP120C settings press **◀** or **▶**

Continuously press **MODE** to scroll between each of the SP120C Settings, or to return to main screen (or wait 5 seconds).

NOTE: *Any modified setting will be automatically saved and stored in memory.*

Pilot Settings Explained (RFU Mode)

Pilot Settings	
Mode Next Opt.	<> Change Val.
> RUDDER RATIO	9
RUDDER SENSE	1
RATE OF TURN	700°/min
BACKLIGHT BRIGHT	15

Rudder applied for Course Error


RUDDER RATIO (Gain) Range: 1-40 Default: 15

Controls the amount of drive / rudder applied for a given off-course angle.

In general, a vessel with fast turning rate will require a lower value.

This may be adjusted according to vessel speed. I.e. Low speeds may require a higher value, as the vessel will respond slower to larger rudder movements at lower speeds.

NOTE: If the vessel is understeering and taking a long time to get back on track, increase this value. If the vessel is over-steering or overshooting and making hard turns to stay on track, decrease this value.



RUDDER SENSE (Sensitivity)


Range: 1-10 Default: 1

The acceptable amount of off-course error allowed for minor rudder corrections.

Increasing this value reduces the amount of pulses used to keep the vessel on course.

If the vessels rudder is continuously hunting, always increase this value to avoid damaging the drive unit.

This value should also be increased in poor weather conditions. For example, when going up a wave the vessels course may move +6 degrees, on the way down the vessel corrects itself -6 degrees naturally, therefore Rudder Sense value should be increased. Otherwise, the SP120C will correct the course change and drive the rudder on the way up the wave, in turn causing the vessel to oversteer when moving down the wave, therefore resulting in excessive unnecessary rudder corrections.



RATE OF TURN

Range: 10-720 (degrees/min) Default: 700

Limits the rudder drive when the SP120C detects the vessel is turning too fast.

I.e. if the rate of change in heading exceeds this value, the SP120C system limits the rudder drive to limit high speed turns. If this setting is too low, the vessel may understeer when changing course.


Backlight Bright

Controls the brightness and display mode of the LCD display.

To switch between Day/Night modes;

Select the BACKLIGHT BRIGHT setting using the **MODE** button;

To switch to Night mode or dim the LCD screen, press and/or hold 

To switch to DAY mode and increase brightness, press and/or hold 

Pilot Settings (Non-RFU Mode)

Pilot Settings	
Mode Next Opt.	<> Change Val.
> RUDDER RATIO	9
RATE TOLERANCE	15
RATE OF TURN	700°/min
MINIMUM SPEED	10KN
MOTOR PULSE TIME	15
BACKLIGHT BRIGHT	15

**Rudder applied
for Course Error**

RUDDER RATIO (Gain)

Range: 1-40 Default: 15

See item 1 on previous page

RATE TOLERANCE

Range: 1-99 Default: 1

Determines the minimum 'Rate of Turn' value before applying counter rudder.

When using non-RFU mode, the SP120C uses ROT to determine how much rudder must be applied to keep the vessel on course. Increasing this value will limit the amount the SP120C pulses the rudder drive when making minor course corrections. i.e.

RATE OF TURN (Maximum - °/min)

Range: 10-720 Default: 700

See item 3 on previous page

MINIMUM SPEED

Range: 3-99kts Default: 10KN

This sets the minimum operating speed of the vessel when switching over to AUTO or GPS mode. If the vessel does not exceed this speed when switching over to AUTO or GPS mode, the SP120C will Alarm and revert back to Manual Mode. Since the system in Non-RFU mode requires ROT for determining the amount of rudder driver required, the vessel must be moving at speed for obtaining an accurate ROT.

MOTOR PULSE TIME

Range: 1-100 Default: 15

Non-RFU mode only uses pulses of current in order to drive the motor. This adjustment sets the size of the pulse.

The more responsive the vessel is to the rudder movement, the lower this setting should be. Usually, for larger boats with slow rudder speed, a longer pulse is required to drive the motor.

Backlight Bright

See item 4 on previous page

Advanced Menus (Install Options)

NOTE: You must be in Manual Mode to access these menus.

Non-RFU mode – Install Options Menu

RFU mode – Primary Menu



To Access 'Install Options' menu

Press **MODE** button once while in Manual Steer mode.

Then from the Pilot Settings screen, simultaneously press both **MODE** & **AUTO**

To navigate the 'Install Option' menu

Press **◀** or to **▶** select a desired menu, then;

Press **AUTO** to enter the desired menu.

To modify any option or value in any of these menus

Press **AUTO** on the item you wish to change;

Press **◀** or **▶** to change a value or option of the selected item.

Press **AUTO** again to save.

Press **MODE** to return to the previous menu (or wait 5 seconds)

Advanced Menus (Pilot Setup Explained)

USE RFU

Values: YES / NO Default: YES

Enable only if a RFU is connected.

Note that if the RFU is enabled and the RFU fails, the system will automatically revert to NON-RFU mode. Therefore it is recommended to test and sea trial both modes with this setting off and on.

SWAP DRIVE OUTPUT

Values: YES / NO Default: NO

A handy function to reverse the motor drive output in case the motor is driving in the wrong direction.

SOLENOID

Values: NEGATIVE / POSITIVE

Default: NEGATIVE

For setting the drive output polarity for solenoid drive systems.

Set to Negative if solenoids have a common positive connection to battery

Set to Positive if solenoids have a common negative connection to battery

DEAD BAND

Range: 1 – 20 (degrees) Default: 10

Adjusts the amount the rudder is allowed to “wander” before the autopilot reacts to correct any change. This value has a similar effect to the ‘Sensitivity’ setting in the primary PILOT Settings.

REVERSE DELAY

Range: 1 to 99 Default: 5

Pilot Setup	
> USE RFU	NO
SWAP DRIVE OUTPUT	NO
SOLENOID NEGATIVE	
DEAD BAND	10
REVERSE DELAY	5
PULSE SIZE	15
OFFCOURSE ALARM	45
Enable Rudder Feedback	

Sets the time delay when the SP120C changes the motor direction (i.e. Port to Starboard or Starboard to Port changes) this setting can prevent shock load and over current on the drive output, since reversing motors and solenoids need time to discharge before driving in the opposite direction.

PULSE SIZE:

Range: 1 to 50 Default: 15

When the vessel is near to the desired position/course, the drive motor will be pulsed to make minor adjustments. A larger pulse size may be required for less responsive vessels with slower steering pumps. (E.g. larger boats with high rudder inertia require larger pulse size values.)

OFFCOURSE ALARM

Range: 1 to 180 (degrees) Default: 45

The SP120C system will alarm when the difference between the vessels heading and desired course to steer, is greater than this value.

Initial Setup

Installer's Instructions

NOTE: Before powering the system for the first time follow the initial inspection & testing procedures.

Advanced Menu - Install Options > Pilot Setup

If a RFU is installed, change USE RFU to YES.

Return to Manual MODE and drive the motor Port and Stbd. If the drive motor is moving the rudder in the wrong direction, change SWAP DRIVE OUTPUT to YES.

If using a constant running motor, check the solenoid common terminals are wired as per the installation wiring Diagram (to Battery +VE) In this case, ensure that the Solenoid Negative setting is used.

Pilot Setup	
> USE RFU	NO
SWAP DRIVE OUTPUT	NO
SOLENOID NEGATIVE	
DEAD BAND	10
REVERSE DELAY	5
PULSE SIZE	15
OFFCOURSE ALARM	45

[Enable Rudder Feedback](#)

Calibration

Rudder Feedback Calibration

Advanced Menu - Install Options > Rudder Setup

Setup and calibrate the rudder feedback positions in this order:

End Port limit > End STBD limit > Set RFU Center


To set each limit, manually steer the vessel using the helm wheel or by pressing the < or > button. Be careful not to overdrive the rudder past the limit as the software limits are disabled in this mode.

During Calibration also check the rudder drive direction is correct.

Rudder Limits		
> RESET LIMITS		
END LIMIT PORT		
END LIMIT STBD		
SET RFU CENTER		

Reset Rudder Limits to default

PORT	LIVE RAW	STBD
640	448	340



Rudder Limits		

PRESS AUTO TO SAVE		
PRESS MODE TO ABORT		


PORT	LIVE RAW	STBD
640	447	340

Compass Calibration

Advanced Menu - Install Options > Compass Setup


If necessary, the E-Compass can be calibrated to compensate for local magnetic influences of the vessel. To carry out this procedure the boat must be in calm open waters and be able to safely turn around a 360° round track at a consistent low speed.

NOTE: *The standard E-compass is factory calibrated and only offset settings should need to be changed if the installation position is ideal as per the previous instructions*



To Calibrate the E-COMPASS:

- Go to the CALIBRATE ELECOM screen in the Install Options > Compass Setup menu
- Start turning the boat at low speed, holding the turn at a constant rate, then press **AUTO**
- A **GREEN** progress bar will be displayed.
- Continue turning the vessel slowly until the message 'CALIBRATION PASSED' is displayed




(Above) If you are turning too fast or too slow, a 'CALIBRATION FAIL' message will appear and you will be required to start the process again.

Compass Calibration

Adjusting Compass Offsets

After the E-compass is calibrated, find the bearing from the boat position to a known visible object. Use a chart or a chart plotter. Steer the boat so that the centre line of the boat is aligned with the bearing line pointing towards the object.

Change the correction offset parameter so that the bearing to the object and the compass readout becomes equal.



NOTE: *Make sure that both the compass heading and the bearing to the object have the same unit (°M or °T).*

NOTE: *If a GPS system is connected, it is recommended to enable the 'USE GPS COG' setting. If the E-compass fails the GPS 'COG' heading' will be used in this case, although will not be as accurate since the update rate will be much lower and COG does not work well until the vessel is moving.*

GPS Settings

GPS Settings

Advanced Menu - Install Options >
GPS Settings

GPS Settings	
> BOD CORRECTION	30
DODGE TIMER	15
SHOW WAYPOINT INFO	ON
MAG VARIATION USE	NMEA
MAG VARIATION	0.0

Angle of Attack to Course

BOD CORRECTION

Values: 1-50 Default: 30

This value increases or decreases the angle of attack from a GPS / PC supplied XTE (cross track error) when in GPS mode.

DODGE TIMER

Values: 1-100 Default: 15

The amount of time the SP120C drives the rudder (using pulses) to dodge an obstacle when in GPS mode.

SHOW WAYPOINT INFO

Values: ON/OFF Default: ON

Displays the GPS target waypoint information received when in GPS mode.

MAG VARIATION USE

Values: NMEA/MANUAL

Default: NMEA

Sets which source controls MAG Variation. I.e. Data supplied via GPS NMEA or set manually (see below)

MAG VARIATION

Values: 30.0E - 30.0W Default: AUTO

Magnetic compass variation offset value for the area of operation. It represents the angle on the horizontal plane between magnetic north (the direction the north end of a compass needle points, corresponding to the direction of the Earth's magnetic field lines) and true north (the direction along a meridian towards the geographic North Pole). This angle varies depending on your position on the Earth's surface and changes over time.

Other Menu Items

Setting up and configuring your GPS system

- * Refer to your GPS systems installation manual for this section;
- Set GPS NMEA port to output 4800 baud
- Enable at least one of the following sentences on the GPS NMEA port connected to the SP120C:
 1. APA
 2. APB or;
 3. BOD and XTE
- Set GPS Arrival zone limit to at least 0.05nm (lower for smaller / slower vessels)
- Set GPS XTE limits to 0.01nm (higher for larger vessels)
- Enable “auto sequence” if applicable - for automatically confirming the next waypoint when following a route.
- Enable the sentences GLL, RMC, SOG, & VTG for the SP120C to indicate GPS position and for Speed over Ground information. Otherwise the SP120C will not function in ‘Non-RFU’ AUTO or GPS modes.

NOTE: *** If only XTE information is available from your GPS unit then your vessel must be heading towards the desired target/course before engaging the GPS mode. The “Auto Sequence” feature will not be available in this situation.*

Factory Reset

Install Options

- > **PILOT SETUP**
- RUDDER SETUP**
- COMS DIAGNOSTICS**
- COMPASS SETUP**
- GPS ADJUSTMENT**
- FACTORY DEFAULTS**
- DISPLAY SETTINGS**
- ABOUT**


General Pilot Settings


This will reset all systems settings to default values

Enter the advanced menu – Install Options. Select **FACTORY DEFAULTS**. Press **AUTO** to enter and follow the instructions on the screen. The unit will ‘Beep’ once completed and all settings will be restored to defaults.

Communications Diagnostics

The check if NMEA messages are received correctly, use the advanced menu – Install Options – **COMS DIAGNOSTICS** page. If a NMEA sentence is correctly received, the sentence turns **GREEN**

To check the incoming data on PORT 1 (i.e. the 6-pin LTW - NMEA I/O port labeled **RUDDER**) press 

To check the data messages on PORT 2 (i.e. the 6-pin LTW - NMEA I/O port labeled **COMPASS**) press 

Other Menu Items

Display Settings

To enable or disable any of the extra information indicated on the LCD, use the DISPLAY SETTINGS menu found on the Advanced menu – Install Options page:



About Page

This page is used to check hardware version and firmware build dates, for each core.

If this manual does not match your system, please contact SI-TEX for a firmware update.

Initial Inspection and Testing

- Confirm power to be connected is the required DC voltage.
- Power Supply 12V-24V DC is available.
- Ensure polarity of the voltage supply is correct.
- All electrical connections are correct.
- Loose cables are clipped or tied up.
- Any un-used connections are isolated and/or sealed.

Your system should now be ready to power on.

Dockside Tests

- Turn steering wheel fully clockwise.
- Visually check moving (mechanical) parts do not foul;
- Repeat 1st step for anti-clockwise direction.
- Return Steering to centre.
- Switch on SP120C AUTOPILOT system
- Press arrow button to operate steering in that direction
- Check that rudder moves in correct direction does not drive past limits
- Check RFU calibration is set if limits are not set
- Check Course change provides sufficient Rudder movement. (Auto mode)
- Check compass heading display on SP120C is available.
- Return steering to centre.
- Check GPS settings are correct as per section

IMPORTANT: *Always initially test system at low speeds first in open water during calm conditions.*

Error Messages

There are a number of possible error messages that can be displayed on screen

MOTOR SHORT

Over current detected on motor wires

CLUTCH SHORT

Over current detected on clutch wire

OFF COURSE

Vessel is more than the set off course ° from Target Heading.

RUDDER AT LIMIT

Rudder has reached the set end stop

RFU DISCONNECTED

Cannot detect the rudder feedback unit

GPS – NO GPS DATA

No NMEA XTE and no BOD received

GPS – NO GPS XTE

No NMEA XTE or APB XTE or RMB XTE received

GPS – NO GPS BOD

No NMEA BOD or APB BOD received

NO XTE – SET DEST

User needs to set a destination waypoint in GPS / PC

VESSEL TOO SLOW

Vessel is too slow to maintain steering without rudder feedback.

NO COMPASS

Compass/Heading data missing * the compass bar will disappear.

Alarms

A number of conditions will cause the SP120C to sound and flash the alarm message on the display.

Off Course Alarm

In AUTO mode an audible alarm of 3 “beeps” per second will sound when boat heading is greater than 45° from the desired course. A red message will also be displayed on the screen

GPS Alarm

In GPS steering mode an audible alarm of 1 “beep” per second will sound when no GPS data is received by the SP120C. A red message will also be displayed on the screen.

Compass Alarm

If there is no reading from a compass, or no HDM / HDT data incoming, an audible alarm of 1 “beep” per half-second will sound. A red message will also be displayed on the screen.

Low Speed Alarm

When used without a rudder feedback (RFU), if the vessel speed goes below the low speed threshold set in the settings, an audible alarm of 1 “beep” per second will sound. A red message will also be displayed on the screen.

Troubleshooting

SP120C Display is completely Black

- Check power is available: 12V-24VDC
- Check boat master switch for AUTOPILOT
- Check circuit breaker (if applicable)
- Check in-line fuse of SP120C red wire
- Check all wiring connections SP120C
- Check Backlight setting

SP120C does not move rudder when AUTO is selected

- Confirm SP120C display is showing compass heading information & No alarm situation.
- Check voltage is present at the SP120C motor connections (Yellow and yellow with black stripe) when AUTO is selected and a course change is applied.
- Confirm that the supply voltage is 12V-24VDC (Red and Black).
- Check all motor and clutch wiring
- Check motor is functioning in manual mode, then check motor brushes
- Check the hydraulic system is operational:
 1. Ensure there is sufficient hydraulic fluid.
 2. Purge the system of possible air locks / contamination.
 3. Ensure that any flow restricting valves are not completely closed.
 4. Check all hydraulic connections for leaks.

Troubleshooting - continued

SP120C Display will not change from MANUAL STEER mode.

- Vessel speed may be below the set threshold, if USE RFU is set to NO.
- Check speed setting in the SP120C settings
- Vessel must be moving forward at or higher than that set speed.

SP120C does not follow a waypoint or route

- Check GPS plotter waypoint or route is set to 'go-to' or activated.
- Check GPS mode is selected on SP120C
- Check alarm status of SP120C
- Ensure that the GPS unit has the correct magnetic correction factor.
- Check SP120C compass alignment and possible magnetic interference

No GPS Data Alarm

- Check wiring of the GPS to the SP120C unit.
- Check sentence in GPS unit for correct data output (APA/APB/BOD & XTE)
- Check route is set up or selected in the GPS unit
- Check location fix at the GPS unit.

Warranty

SI-TEX products are thoroughly inspected and tested before shipment from the factory and are warranted to be free of defects in workmanship and materials for a period of one year from the date of shipment from the factory.

This warranty is extended to and is solely for the benefit of the original consumer purchaser.

All units in need of repair will be repaired without charge to the purchaser during the above mentioned period in accordance with the following terms and conditions:

1. The defective unit is returned "freight prepaid" to Si-Tex Marine Electronics : 25 Enterprise Zone Drive, Suite #2 Riverhead, NY 11901
2. Proof of purchase is supplied and original Serial Numbers on equipment have not been changed.
3. Information is provided regarding the nature of the failure or problem occurring.
4. A return address is supplied to enable the equipment to be returned by road freight. Any other means of transport will be charged to the customer's account and must be paid in advance.

This warranty does not cover defects or damages caused by unauthorised service or damage through accident, misuse or abuse. The owner is also responsible for providing reasonable maintenance and weather protection of the equipment.

SI-TEX shall not be liable for damage or loss incurred resulting from the use and operation of this product.

SI-TEX reserves the right to make changes or improvements to later models without incurring the obligation to install similar changes to equipment already supplied.

Some states do not allow the exclusion or limitation of incidental or consequential damages; therefore the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Additional Information

Si-Tex Marine Electronics

Please refer to the Si-Tex website for more information

Web: www.si-tex.com



SI-TEX Main Office Address:
25 Enterprise Zone Drive, Ste 2
Riverhead, NY 11901
Tel: +1-631-996-2690
Email: service@si-tex.com
Web: www.si-tex.com