

KODEN

SERVICE MANUAL

MARINE RADAR

MDC-5000/5200/5500

SERIES

MDC-7000/7900

SERIES

This product is specifically designed to be installed on boats and other means of maritime transport. If your country forms part to the EU, please contact your dealer for advice before attempting to install elsewhere.

MDC-5000/5200/5500/7000(P)/7900(P) Series Service Manual**Doc No: 0093855002****Document Revision History**

No.	Doc. No./Rev. No.	Revised Date (Y/M/D)	Revised content
0	0093855002-00	2018/05/31	First edition
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

Document No. Revised Version Norm

When part of the document needs to be revised, the document has advanced revision number.

The document No. is indicated at the lower right side on the cover and at the left or right side of the footer region of each page.

© 2018 Kodens Electronics Co., Ltd. All rights reserved.

No part of this publication may be reproduced, transmitted, translated in any form by any means without the written permission of Kodens Electronics Co., Ltd. The technical descriptions contained in this publication are subject to change without notice. Kodens assumes no responsibility for any errors, incidentals or consequential damages caused by misinterpretation of the descriptions contained in this publication.






Important Notice

- For copy and transcription of this Service Manual (hereinafter referred to as this manual), permission from Koden is needed. Koden prohibits the un-authorized copy and transcription of this manual.
- If this manual is lost or damaged, consult a dealer of Koden or Koden.
- The specification of the products and the contents in this manual are subject to change without notice.
- The contents displayed on the menu of product may be different from the expression of this manual. The fonts and shapes of the keys and menus in the illustration may differ from the actual ones, and some parts may be omitted.
- Koden is not liable for damages and troubles arisen from misunderstanding of the contents in this manual.
- Koden is not liable for any damages caused by earthquake, lightning, wind and flood damage and fire for which Koden is not responsible, and actions by third parties, other accidents, customer's unintended error/abuse and the use under other abnormal conditions.
- Koden is not liable for damages of accompaniment (change/loss of memorized content, loss of business profit, stop of business) arisen from use or failure of our products.
- If the stored data are changed or lost, irrespective of causes of troubles and damages, Koden is not liable for them.
- Koden is not liable for any damages arisen from malfunction caused by combination of software and connected equipment in which Koden is not engaged.







For Your Safe Operation

Symbols used in this Service Manual


This manual uses the following symbols. Understand the meaning of each symbol and implement the maintenance and inspection.


Symbol	Meaning
 Warning	Mark for warning This symbol denotes that there is a risk of death or serious injury when not dealing with it correctly.
	Mark for danger high voltage This symbol denotes that there is a risk of death or serious injury caused by electric shock when not dealing with it correctly.
 Caution	Mark for caution This symbol denotes that there is a risk of slight injury or damage of device when not dealing with it correctly.
	Mark for prohibition This symbol denotes prohibition of the specified conduct. Description of the prohibition is displayed near the mark.
IMPORTANT	Mark for important matters This mark denotes that there is a possibility that data loss may interfere the operation or that the expected result may not be obtained when the radar is not dealt correctly.
	Mark for reference This mark shows the part to be referred to concerning this description.






Caution Item on Equipment

	<p>Caution on a high voltage inside. A high voltage, which may risk your life, is used. This high voltage remains in the circuit after you have powered off switch. To prevent touching the high voltage circuit inadvertently, the protective cover is provided to the high voltage circuit and the high voltage caution label is affixed. Ensure to power off switch for your safety and discharge the electricity remaining in the capacitor before starting to check. An engineer authorized by our company should inspect and maintain the circuit.</p>
 <p>Warning</p>	<p>Be sure to switch off the power in the boat. If the power switch is inadvertently powered on during work, you will be electrified. To prevent such accident from occurring, ensure to switch off the power in the boat and the power of equipment. Furthermore, it is safer to hang the caution tag with description of [Under Work] near the power switch of equipment.</p>
 <p>Warning</p>	<p>Caution on dust Inhaling dust may cause respiratory disease. When cleaning the inside of equipment, be careful not to inhale dust. Wearing a safety mask is recommended.</p>
 <p>Caution</p>	<p>Caution on location of equipment Do not install the equipment where it is excessively damp and suffers from excessive water drops.</p>
 <p>Caution</p>	<p>Caution on static electricity The static electricity may be generated from the carpet on the floor in the cabin or clothes made of synthetic fiber. The static electricity may destroy the electronic parts on the circuit board. Handle the circuit board, taking the suitable anti-static measures.</p>
	<p>Prohibited matter Any Display and Scanner unit combination other than specified in the manual is prohibited and will void manufacturer's warranty.</p>

Caution Items on Handling

 Caution	<p>Caution on the rotating aerial</p> <p>The radar antenna may start to rotate without notice. Please stand clear from the antenna for your safety.</p>
--	--

 Caution	<p>Caution on electromagnetic disturbance</p> <p>The operating Antenna & Scanner unit radiates high-energy electromagnetic wave. It may cause harmful effect for human body due to its continuous radiation. As International regulation says, electromagnetic waves less than 100 watt/m² does not have a harmful effect on human bodies, but some kind of medical devices such as heart pacemakers are sensitive even under the low energy electromagnetic wave. Any personnel with such a device should keep away from the electromagnetic wave generating position at all times.</p> <p>Specified power density and distance from the radar (in accordance with the provision as specified in IEC 60945)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Model name</th> <th style="text-align: left;">Transmission power / Antenna length</th> <th style="text-align: center;">100W/m²</th> <th style="text-align: center;">50W/m²</th> <th style="text-align: center;">10W/m²</th> </tr> </thead> <tbody> <tr> <td>MDC-5004</td> <td>4kW / 3 feet Antenna</td> <td style="text-align: center;">0.9 m</td> <td style="text-align: center;">1.3 m</td> <td style="text-align: center;">2.8 m</td> </tr> <tr> <td>MDC-5204/5240</td> <td>4kW / 4 feet Antenna</td> <td style="text-align: center;">1.0 m</td> <td style="text-align: center;">1.4 m</td> <td style="text-align: center;">3.1 m</td> </tr> <tr> <td>MDC-5504/5540</td> <td>4kW / 6 feet Antenna</td> <td style="text-align: center;">1.2 m</td> <td style="text-align: center;">1.7 m</td> <td style="text-align: center;">3.7 m</td> </tr> <tr> <td>MDC-5006/5060</td> <td rowspan="2">6kW / 4 feet Antenna</td> <td rowspan="2" style="text-align: center;">1.5 m</td> <td rowspan="2" style="text-align: center;">2.1 m</td> <td rowspan="2" style="text-align: center;">4.5 m</td> </tr> <tr> <td>MDC-5206/5260</td> </tr> <tr> <td>MDC-5506/5560</td> <td rowspan="3">6kW / 6 feet Antenna</td> <td rowspan="3" style="text-align: center;">1.7 m</td> <td rowspan="3" style="text-align: center;">2.4 m</td> <td rowspan="3" style="text-align: center;">5.4 m</td> </tr> <tr> <td>MDC-7006/7060</td> </tr> <tr> <td>MDC-7906/7960</td> </tr> <tr> <td>MDC-5012/5010</td> <td rowspan="3">12kW / 4 feet Antenna</td> <td rowspan="3" style="text-align: center;">2.1 m</td> <td rowspan="3" style="text-align: center;">2.9 m</td> <td rowspan="3" style="text-align: center;">6.4 m</td> </tr> <tr> <td>MDC-5212/5210</td> </tr> <tr> <td>MDC-5512/5510</td> </tr> <tr> <td>MDC-7012/7010</td> <td rowspan="2">12kW / 6 feet Antenna</td> <td rowspan="2" style="text-align: center;">2.4 m</td> <td rowspan="2" style="text-align: center;">3.4 m</td> <td rowspan="2" style="text-align: center;">7.6 m</td> </tr> <tr> <td>MDC-7912/7910</td> </tr> <tr> <td>MDC-7012P</td> <td rowspan="2">12kW / 9 feet Antenna</td> <td rowspan="2" style="text-align: center;">2.9 m</td> <td rowspan="2" style="text-align: center;">4.1 m</td> <td rowspan="2" style="text-align: center;">9.0 m</td> </tr> <tr> <td>MDC-7912P</td> </tr> <tr> <td>MDC-5025/5020</td> <td rowspan="2">25kW / 4 feet Antenna</td> <td rowspan="2" style="text-align: center;">2.9 m</td> <td rowspan="2" style="text-align: center;">4.1 m</td> <td rowspan="2" style="text-align: center;">9.2 m</td> </tr> <tr> <td>MDC-5225/5220</td> </tr> <tr> <td>MDC-5525/5520</td> <td rowspan="2">25kW / 6 feet Antenna</td> <td rowspan="2" style="text-align: center;">3.5 m</td> <td rowspan="2" style="text-align: center;">4.9 m</td> <td rowspan="2" style="text-align: center;">10.9 m</td> </tr> <tr> <td>MDC-7025/7020</td> </tr> <tr> <td>MDC-7925/7920</td> <td rowspan="3">25kW / 9 feet Antenna</td> <td rowspan="3" style="text-align: center;">4.1 m</td> <td rowspan="3" style="text-align: center;">5.8 m</td> <td rowspan="3" style="text-align: center;">13.0 m</td> </tr> <tr> <td>MDC-7025P</td> </tr> <tr> <td>MDC-7925P</td> </tr> </tbody> </table>	Model name	Transmission power / Antenna length	100W/m ²	50W/m ²	10W/m ²	MDC-5004	4kW / 3 feet Antenna	0.9 m	1.3 m	2.8 m	MDC-5204/5240	4kW / 4 feet Antenna	1.0 m	1.4 m	3.1 m	MDC-5504/5540	4kW / 6 feet Antenna	1.2 m	1.7 m	3.7 m	MDC-5006/5060	6kW / 4 feet Antenna	1.5 m	2.1 m	4.5 m	MDC-5206/5260	MDC-5506/5560	6kW / 6 feet Antenna	1.7 m	2.4 m	5.4 m	MDC-7006/7060	MDC-7906/7960	MDC-5012/5010	12kW / 4 feet Antenna	2.1 m	2.9 m	6.4 m	MDC-5212/5210	MDC-5512/5510	MDC-7012/7010	12kW / 6 feet Antenna	2.4 m	3.4 m	7.6 m	MDC-7912/7910	MDC-7012P	12kW / 9 feet Antenna	2.9 m	4.1 m	9.0 m	MDC-7912P	MDC-5025/5020	25kW / 4 feet Antenna	2.9 m	4.1 m	9.2 m	MDC-5225/5220	MDC-5525/5520	25kW / 6 feet Antenna	3.5 m	4.9 m	10.9 m	MDC-7025/7020	MDC-7925/7920	25kW / 9 feet Antenna	4.1 m	5.8 m	13.0 m	MDC-7025P	MDC-7925P
Model name	Transmission power / Antenna length	100W/m ²	50W/m ²	10W/m ²																																																																				
MDC-5004	4kW / 3 feet Antenna	0.9 m	1.3 m	2.8 m																																																																				
MDC-5204/5240	4kW / 4 feet Antenna	1.0 m	1.4 m	3.1 m																																																																				
MDC-5504/5540	4kW / 6 feet Antenna	1.2 m	1.7 m	3.7 m																																																																				
MDC-5006/5060	6kW / 4 feet Antenna	1.5 m	2.1 m	4.5 m																																																																				
MDC-5206/5260																																																																								
MDC-5506/5560	6kW / 6 feet Antenna	1.7 m	2.4 m	5.4 m																																																																				
MDC-7006/7060																																																																								
MDC-7906/7960																																																																								
MDC-5012/5010	12kW / 4 feet Antenna	2.1 m	2.9 m	6.4 m																																																																				
MDC-5212/5210																																																																								
MDC-5512/5510																																																																								
MDC-7012/7010	12kW / 6 feet Antenna	2.4 m	3.4 m	7.6 m																																																																				
MDC-7912/7910																																																																								
MDC-7012P	12kW / 9 feet Antenna	2.9 m	4.1 m	9.0 m																																																																				
MDC-7912P																																																																								
MDC-5025/5020	25kW / 4 feet Antenna	2.9 m	4.1 m	9.2 m																																																																				
MDC-5225/5220																																																																								
MDC-5525/5520	25kW / 6 feet Antenna	3.5 m	4.9 m	10.9 m																																																																				
MDC-7025/7020																																																																								
MDC-7925/7920	25kW / 9 feet Antenna	4.1 m	5.8 m	13.0 m																																																																				
MDC-7025P																																																																								
MDC-7925P																																																																								

 Warning	<p>Do not disassemble or modify. It may lead to trouble, fire, smoking or electric shock. In case of trouble, contact our dealer or our company.</p>
 Warning	<p>In case of smoke or fire, switch off the power in the boat and the power of equipment. It may cause fire, electric shock or damage.</p>
	<p>Caution on the remaining high voltage. A high voltage may remain in the capacitor for several minutes after you have powered off. Before inspecting inside, wait at least 5 minutes after powering off or discharging the remaining electricity in an appropriate manner. Then, start the work.</p>
 Caution	<p>The information displayed in this unit is not provided directly for your navigation. For your navigation, be sure to see the specified material.</p>
 Caution	<p>Use the specified fuse. If un-specified fuse is used, it may cause a fire, smoke or damage.</p>

Break in procedure of stored radar



Caution


Following procedure is recommended for “Break In” of the stored radar.

Otherwise the radar sometimes exhibits unstable transmitting operation such as arcing at its initial operation after long period of storage and make the operation more difficult.

1. Extend preheat time as long as possible (preferably 20 to 30 minutes).
2. Set the pulse width to the shortest one and start the operation.

When the operation in the shortest pulse is stable then go to operation in longer pulse and repeat the similar step until the operation reaches to the final pulse condition.

Disposal of used cells and this radar

 Warning	A high-energy density lithium ion battery cell is built in this radar. Improper disposal of the lithium ion battery cell is discouraged as the cell has possibility of short-circuiting. If it gets wet, generation of heat, explosion or ignition may occur resulting in injury or fire.
--	---

Treatment of the used lithium ion cells

To dispose built-in lithium ion battery cells (CR2032) in this radar, insulate each terminal with scotch tape, etc. and wrap in a plastic bag, etc.

The disposal and collection rules may be different depending on each municipal district. Obey the directions of each district.

Disposal of this radar

This radar shall be disposed according to the municipal regulations or rules.

Contents

Document Revision History.....	i
Important Notice.....	ii
For Your Safe Operation	iii
Break in procedure of stored radar	vii
Disposal of used cells and this radar	viii
Contents	ix
Chapter 1 Fault diagnosis	1-1
1.1 About alarms.....	1-1
1.2 Malfunction detection step	1-2
1.3 Malfunction diagnosis flowchart.....	1-3
1.3.1 Initial malfunction diagnosis 1	1-3
1.3.2 Initial malfunction diagnosis 2	1-4
1.3.3 Other faults (Display unit).....	1-5
1.3.4 Abnormal display	1-6
1.3.5 No response from the Antenna Scanner unit	1-7
1.3.6 Sensitivity failure.....	1-8
1.3.7 No display of ship's bearing, speed and latitude/longitude	1-9
1.3.8 Operation unit abnormality	1-10
1.3.9 Antenna Scanner unit abnormality	1-11
1.3.10 Synchronization of screen abnormality	1-12
1.3.11 High voltage abnormality	1-12
1.3.12 Pulse length control failure	1-13
1.3.13 Rotary abnormality	1-14
1.3.14 Heading line and Azimuth abnormality	1-15
1.3.15 TT (ATA) abnormality.....	1-16
1.3.16 Chart display abnormality.....	1-17
1.3.17 No display of AIS	1-18
1.3.18 Other faults (Antenna Scanner unit).....	1-20
1.4 Failure criterion of microwave components	1-24
1.4.1 Magnetron	1-24
1.4.2 Front-end module	1-24
1.4.3 Limiter.....	1-24

Chapter 2 MAINTENANCE MENU.....	2-1
2.1 BITE.....	2-1
2.1.1 PANEL TEST	2-1
2.1.2 DIAGNOSE TT.....	2-1
2.1.3 DIAGNOSE AIS	2-2
2.1.4 SERIAL MONITOR	2-3
2.1.5 ANT MONITOR.....	2-4
2.1.6 SD CARD.....	2-4
2.2 ECHO	2-5
2.2.1 GAIN OFFSET	2-5
2.2.2 SEA CURVE	2-5
Chapter 3 How to exchange components	3-1
3.1 Display unit.....	3-1
3.1.1 Replacement of fuse.....	3-1
3.1.2 Dismantling of bracket and rear case (MRD-108 / MRD-108P)	3-2
3.1.3 Dismantling of bracket and rear case (MRD-109)	3-3
3.1.4 Dismantling of bracket and rear case (MRD-111).....	3-4
3.1.5 Exchange of Logic PCB (MRD-108/108P/109/111/MRM-108/108P/110).....	3-5
3.1.6 Exchange of power supply PCB (MRD-108/108P/109/111, MRM-108/108P/110)	3-6
3.1.7 Exchange of LCD unit (MRD-108/108P)	3-9
3.1.8 Exchange of LCD unit (MRD-109)	3-11
3.1.9 Exchange of LCD unit (MRD-111)	3-13
3.1.10 Exchange of backlight power PCB (MRD-108/108P).....	3-15
3.1.11 Exchange of Rear card connector PCB (MRD-108/108P/MRM-108/108P/110)	3-17
3.1.12 Exchange of Connector PCB (MRD-109).....	3-18
3.1.13 Exchange of Connector PCB (MRD-111)	3-19
3.2 Operation unit.....	3-20
3.2.1 Exchange of Panel PCB (MRO-108/108P).....	3-20
3.2.2 Exchange of Panel PCB (MRD-111).....	3-23
3.2.3 Exchange of track ball (MRO-108/108P).....	3-24
3.2.4 Exchange of Silicon key (MRD-111)	3-26
3.3 Antenna Scanner unit.....	3-27

3.3.1	Dismantling of antenna and antenna cover	3-27
3.3.2	Exchange of Azimuth Pulse unit and Drive unit motor (RB806 / 807 / 717A / 718A / 719A)	3-29
3.3.3	Exchange of V ring	3-31
3.3.4	Exchange of Modulator PCB	3-36
3.3.5	Exchange of Fan (RB809 only)	3-39
3.3.6	Exchange of Fan (RB719A only).....	3-40
3.3.7	Exchange of Magnetron (RB806).....	3-41
3.3.8	Exchange of Magnetron (RB807, RB808/808P)	3-43
3.3.9	Exchange of Magnetron (RB809/809P)	3-45
3.3.10	Exchange of Magnetron (RB717A, RB718A)	3-47
3.3.11	Exchange of Magnetron (RB719A).....	3-49
3.3.12	Exchange of Transformer (RB809/809P)	3-51
3.3.13	Exchange of Transformer (RB717A, RB718A)	3-53
3.3.14	Exchange of Transformer (RB719A)	3-54
3.3.15	Exchange of MIC (RB806)	3-56
3.3.16	Exchange of IF MODULE (RB807/808/808P/809/809P)	3-57
3.3.17	Exchange of IF PCB, MIC and limiter device.....	3-58
Chapter 4 Spare parts and Circuit diagram		4-1
4.1	Spare parts.....	4-1
4.2	Circuit diagram.....	4-34
4.2.1	Interconnection diagam of 4kW Scanner Unit (RB806)	4-35
4.2.2	Interconnection diagam of 4 kW Scanner Unit (RB716A).....	4-36
4.2.3	Interconnection diagam of 6 kW Scanner Unit (RB807)	4-37
4.2.4	Interconnection diagam of 6 kW/12 kW Scanner Unit (RB717A/718A)	4-38
4.2.5	Interconnection diagam of 12 kW Scanner Unit (RB808)	4-39
4.2.6	Interconnection diagam of 12 kW Scanner Unit (RB808P).....	4-40
4.2.7	Interconnection diagam of 25 kW Scanner Unit (RB809)	4-41
4.2.8	Interconnection diagam of 25 kW Scanner Unit (RB809P).....	4-42
4.2.9	Interconnection diagram of 25 kW Scanner Unit (RB719A).....	4-43
4.2.10	Inter connection diagram MRD-108/MRD-108P	4-44
4.2.11	Inter connection diagram MRM-108/MRM-108P.....	4-45
4.2.12	Inter connection diagram MRD-111	4-46
4.2.13	Inter connection diagram MRD-109	4-47

4.2.14	Inter connection diagram MRM-110.....	4-48
4.2.15	Circuit diagram Power supply PCB	4-49
4.2.16	Circuit diagram of BACK LIGHT POWER PCB	4-51
4.2.17	Circuit diagram of PANEL BOARD (E63-900*).....	4-52
4.2.18	Circuit diagram of PANEL BOARD (E68-900*).....	4-53
4.2.19	Circuit diagram of PANEL BOARD (E73-900*).....	4-54
4.2.20	Circuit diagram of CONNECTOR PCB (E63-911*).....	4-55
4.2.21	Circuit diagram of CONNECTOR PCB (E68-910*)	4-56
Annex	A-1
A.1	Clean up the trackball	A-1
A.2	Interface	A-3
1.	Relation between functions and input signal	A-3
2.	Kind of input/output ports	A-4
3.	Setup Interface	A-5
4.	Confirmation of input signal.....	A-11
5.	Connection of gyro convertor S2N	A-12
6.	Gyro/Log interface: Connection of ADPC-101 unit (non-IMO)	A-14
7.	Connection of LOG pulse NMEA converter L1N (200 pulse/nautical mile only)	A-16
8.	Connection of AIS.....	A-17
A.3	System Program	A-19
	Version confirmation.....	A-19
	How to update the system program	A-20

Chapter 1 Fault diagnosis


1.1 About alarms

Alarm and warning display may appear at the lower right of the radar screen as shown in the following figure, when a malfunction or operation error has been detected in the device.

In case of occurrence of multiple numbers of alarms, it is possible to confirm all of them in [LIST].

Alarms occurred since Power ON can be confirmed by [HISTORY LIST]. (MDC-7000/7900 series only)

☞ Refer to “Chapter 3 Alarm” in the Operation manual for the [LIST] and [HISTORY LIST].



☞ Refer to “Chapter 1 Display and Operation 1.1 Radar Display [Alarm display area]” in the Operation manual.

1.2 Malfunction detection step

As a first step of on-board repair, refer to the following tables describing outlines of malfunction diagnostics procedure.

Table 1.1 basic malfunctions


Failure status	Possible cause	Measure
No power.	<ol style="list-style-type: none"> 1. Power cable is disconnected. 2. Operation unit cable is disconnected. 3. Supply voltage is out of range. 4. Main power fuse is blown. 	<ol style="list-style-type: none"> 1. Connect power cable firmly and secure connector. 2. Connect operation cable firmly and secure connector. 3. Use proper power source. 4. Change fuse with new one.
Power is applied but no display	<ol style="list-style-type: none"> 1. Display brilliance is adjusted to the minimum. 2. Connector of internal cable is disconnected. 3. Failure of LCD unit or Backlight power PCB 	<ol style="list-style-type: none"> 1. Adjust properly. 2. Confirm by a serviceman. 3. Request repair.

Table 1.2 possible malfunctions


Error status	Possible cause	Measure
Display brilliance is dark.	<ol style="list-style-type: none"> 1. Adjustment of display brilliance is incorrect. 2. Failure of LCD driver circuit 3. Failure of Backlight power PCB 	<ol style="list-style-type: none"> 1. Adjust properly. 2. Request repair 3. Request repair
No radar echo is displayed.	<ol style="list-style-type: none"> 1. Receiver is detuned. 2. Video contrast adjustment error 3. Failure of transceiver 	<ol style="list-style-type: none"> 1. Readjust by referring to "Tune adjustment of Installation manual". 2. Readjust by GAIN, SEA or RAIN knobs, or readjust by referring to "Tune adjustment of Installation manual". 3. Request repair
Radar echo is too weak.	<ol style="list-style-type: none"> 1. Receiver is detuned. 2. Failure of Magnetron or MIC (front-end) 	<ol style="list-style-type: none"> 1. Readjust by referring to "Tune adjustment of Installation manual". 2. Request repair
Error message "Head line signal abnormal." is displayed.	<ol style="list-style-type: none"> 1. No heading line signal input. 	<ol style="list-style-type: none"> 1. Check [BP/HG] signal between an Antenna Scanner unit and a Display unit.
Antenna does not rotate.	<ol style="list-style-type: none"> 1. Motor fuse is blown. 2. Motor power is not supplied. 3. Inter-switch mode is difference. 	<ol style="list-style-type: none"> 1. Replace fuse with a new one. 2. Check motor power connection. 3. Set inter-switch mode to master mode.

1.3 Malfunction diagnosis flowchart


1.3.1 Initial malfunction diagnosis 1




1.3.2 Initial malfunction diagnosis 2




1.3.3 Other faults (Display unit)




1.3.4 Abnormal display




1.3.5 No response from the Antenna Scanner unit




1.3.6 Sensitivity failure




1.3.7 No display of ship's bearing, speed and latitude/longitude




1.3.8 Operation unit abnormality




1.3.9 Antenna Scanner unit abnormality




1.3.10 Synchronization of screen abnormality




1.3.11 High voltage abnormality




1.3.12 Pulse length control failure




1.3.13 Rotary abnormality




1.3.14 Heading line and Azimuth abnormality




1.3.15 TT (ATA) abnormality



1.3.16 Chart display abnormality



1.3.17 No display of AIS




Confirmation of AIS connection

How to confirm the AIS signals:


1. Select monitor function

MENU > MAINTENANCE > BITE > SERIAL MONITOR > AIS

As shown in the right side picture, the serial sentence of VDM will be displayed.



Example of screen when the format of serial signal does not match



Example of monitoring serial signals of AIS on the screen

2. Result of monitoring


- When the format of serial sentence does not match, change the I/O baud rate of the port connected to the radar in AIS device to IEC 61162-2 or 38400 bps at AIS device side.
- When nothing is displayed on the screen, interchange the blue wire with the white wire of Blue/White twisted cable (CW-387) connected to Tx-A and Tx-B of AIS device respectively.




If the screen is improved with this interchange, carry out the same interchange at CW-387 and connect to J2-AIS again.


If the screen is no improvement with this interchange, investigate the connecting port of AIS device and AIS device itself.

- When AIS symbol is not displayed even with display of a VDM sentence, confirm "No display of AIS" in accordance with the faults diagnosis flow. [Go to 1.3.17 No display of AIS in page 1-18.]


1.3.18 Other faults (Antenna Scanner unit)







*Subject to version change



*Subject to version change

1.4 Failure criterion of microwave components

1.4.1 Magnetron

The following phenomenon listed below may arise at the initial stage of magnetron's lifetime and can not finally transmit at all.

- a. Images may drop out from the center in broken lines and straight lines.
- b. A target may be split into two in the direction of distance or may be thin down like images applied with RAIN Rejection.
- c. When pulse width is changed manually from LP to SP, detuning may be caused.
- d. Desensitization may be caused.
- e. Current value of magnetron may fall outside of the specified values.
- f. When lead wires of a magnetron are disconnected from the pulse transformer, the resistance between lead wires may be 15 Ω or more.

1.4.2 Front-end module

- a. There would be no best point in manual tuning or automatic tuning.
- b. There would be no images except strong signals from land.

1.4.3 Limiter

- a. Sensitivity would become extremely worse (Buoys up to 3 miles displayed could fade out and buoys within only 1 mile could be displayed).


Chapter 2 MAINTENANCE MENU

2.1 BITE

Other items except the card item are the same items of BITE in MAINTENANCE MENU.

This is the function to find out faults easily.

There are items of ALARM TEST, PANEL TEST, DIAGNOSE TT, DIAGNOSE AIS, SERIAL MONITOR, ANT MONITOR and SD CARD as shown in the right picture.



2.1.1 PANEL TEST

It can check whether there is any fault in the function of Operation unit (MRO-108, MRO-110 and MRD-111).


How to operate:

1. Push "MENU" key, then the menu will be displayed.
2. "MAINTENANCE" => "BITE" => "PANEL TEST" =>
3. The panel layout as shown in the right picture will be displayed.

When any key is pushed, "●" mark will be indicated at the left side of the key if the key is normal. If nothing is indicated, the key is faulty.

When a knob is turned, the indicating line will be turned in proportion to the turning of the knob if the key is normal. If the line will not turn, the corresponding volume or encoder may be faulty.

The "o" mark of the track ball or joystick shown at the bottom will move to the direction of turning if the function is normal. If the mark will not move, the track ball or joystick may be faulty.



2.1.2 DIAGNOSE TT


This is the function to check TT (ATA) function.

How to operate:

1. Push "MENU" key to display the menu.
2. "MAINTENANCE" => "BITE" => "DIAGNOSE TT" =>
3. When the function is normal, "O" mark will be displayed at the left side of each item as shown in the right picture.

When there is any fault, mark "x" will be displayed. TT (ATA) will not function if there is even one "x" mark.

- In the case of "x HDG", no HDT sentence has been input into J3, J5, J6 or gyro port at the rear side of the Display unit. Check the input.




2.1.3 DIAGNOSE AIS

This is the function to check whether AIS function has any fault or not.

How to operate:

1. Push "MENU" key to display the menu.
2. "MAINTENANCE" => "BITE" => "DIAGNOSE AIS" =>
3. When the function is normal, "O" mark will be displayed at the left side of each item as shown in the right picture.



When there is any fault, mark "x" will be displayed. AIS will not function if there is even one "x" mark.


- In the case of "x AIS DATA", VDM sentence is not input into the connector J2 (AIS) at the rear side of the Display unit.
- In the case of "x HDG", HDT sentence is not input into J3, J5, J6 or gyro port at the rear side of the Display unit. Check the input.
- In the case of "x SPD", VBW or VHW sentence is not input in J3, J5, J6 at the rear side of the Display unit. Check the input.
- In the case of "x LAT/LON", GNS or GGA, GLL or RMC sentence is not input in J3, J5, J6 at the rear side of the Display unit. Check the input.
- In the case of "x COG/SOG", VTG sentence is not input in J3, J5, J6 at the rear side of the Display unit. Check the input.

2.1.4 SERIAL MONITOR

How to operate:

1. Push "MENU" key to display the menu.
2. "MAINTENANCE" => "BITE" => "SERIAL MONITOR" =>
The content of the input will be displayed as shown in the right picture, and the display will scroll when the screen is fully occupied.
3. When "ENT" key is pushed, the scrolling will stop. Then, push "ENT" key to start the scrolling again.

The bottom line of the screen is the latest data.
Comparing the details of data input contained at the end of the instruction manual with the sentence monitored, confirm the correctness.



Note: When ship's bearing, speed and positioning sentence data is invalid, display of data, TT (ATA) function and AIS function will be unavailable.

- Ship's bearing (HDG) : Required
MDC-7X00P:THS>HDT
Others :THS>HDT>HDG>HDM>VTG(T)[COG]>VTG(M)[COG]>RMC[COG]>RMA[COG]
- Speed (STW,COG/SOG) : Required
VBW>VTG(D)(Track/Speed against ground)>VHW(Speed against water)
- Own Ship Latitude/Longitude (LAT/LON) : Required
MDC-7X00P:GLL>GGA>GNS>RMC
Others :GLL>GGA>GNS>RMC>RMA
- Geodetic system (DATUM) : Required
DTM
- Date, Time : Required
MDC-7X00P:ZDA(Present Date, Time)
Others :ZDA(Present Date, Time)>RMC(Positioning Time)>GGA(Positioning Time)
- Destination LAT/LON, ID
RMB>BWC>RTE/WPL
- Destination Bearing/Distance
RMB>BWC
- Cross Track Distance
RMB>XTE
- Route
RTE/WPL
- Depth
DPT>DBT
- Water Temperature
MTW
- Own Ship LOP value
GLC
- Wind Direction, Speed
MWD

2.1.5 ANT MONITOR

This is the function to check the status of Antenna Scanner unit.

How to operate:

1. Push “MENU” key to display the menu.
2. Follow “MAINTENANCE” => “BITE” => “ANT MONITOR” =>
3. The status of Antenna Scanner unit as shown at right will be displayed.

```

10 >MAINTENANCE
06 >BITE
06 >ANT MONITOR

STATUS
RB808 12kW OPEN 08
HIGH VOLTAGE 318V
MAG CURRENT MONI 113
MAG HEATER 2.5V
MOTOR MONI 175
TUNE VOLTAGE 12.1V
TUNE METER ██████████
RATE OF ROTATION
HTM 24.7RPM
MUM 246.7V
PM RX MONI ---
PM TX MONI ---
    
```

The normal range is as shown in the table below. However, even if values are within the ranges, there may be cases where enough performance cannot be obtained and vice versa. This is just a guideline.

RB807/RB808/RB809

Scanner Item	RB807	RB808/RB809
HIGH VOLTAGE	200 – 320	300 – 420
MAG CURRENT	20 - 220	
MAG HEATER	1 - 12	
TUNE VOLTAGE	Difference between tuned voltage of each pulse range is ± 10	
RATE OF ROTATION	When antenna is set at low rotation: 20 - 28 rpm	

RB806/RB717A/718A/719A

Scanner Item	RB806/RB717A/718A/719A
HIGH VOLTAGE	100 - 300
MAG CURRENT	2 - 45
MAG HEATER	10 - 124
TUNE VOLTAGE	Difference between tuned voltage of each pulse range is ± 10
RATE OF ROTATION	When antenna is set at low rotation: 20 - 28 rpm

2.1.6 SD CARD

MDC-5200/5500 series

When C-MAP SD card is inserted, “C-MAP” will be displayed. If not, “NONE” will be displayed.

```

06 >BITE
01 ALARM TEST OFF
02 PANEL TEST
03 DIAGNOSE TT
04 DIAGNOSE AIS
05 SERIAL MONITOR
06 ANT MONITOR
07 >SD CARD
    SD CARD
    USED 0.117GB
    FREE 0.847GB
    C-MAP
    
```

C-MAP SD card is inserted

```

06 >BITE
01 ALARM TEST OFF
02 PANEL TEST
03 DIAGNOSE TT
04 DIAGNOSE AIS
05 SERIAL MONITOR
06 ANT MONITOR
07 >SD CARD
    SD CARD
    NONE
    
```

C-MAP SD card is not inserted

MDC-5000/7000/7900 series

When SD card is inserted, "C-MAP" and/or "USED/FREE size" will be displayed. If not, "NONE" will be displayed.

**CAUTION: Backup SD-card must be inserted in the upper card reader [SD Card (1)].
C-MAP SD-card must be inserted in the lower card reader [SD Card (2)].**



C-MAP/backup SD card is inserted



C-MAP/backup SD card is not inserted

2.2 ECHO

2.2.1 GAIN OFFSET

This is the function to adjust noise amount that varies per range.


In order to use the maximum gain performance, at scale 8 of gain knob, the background noise (thin small spots) in images will be displayed over the screen at the level where it will not interfere with detection of targets as shown in the right picture. When this displayed background noise will not vary even with changes of ranges without adjustment of gain knob, the setting will be the best.

If the background noise will change with changes of ranges, set "GAIN OFFSET".

Note:

Background noise will change in inverse ratio to IF bandwidth, and IF bandwidth will work with pulse width.

For the purpose, there is MAINTENANCE > PRESET > GAIN OFFSET in order to set the background noise amount per pulse width separately. Therefore, set the gain offset bandwidth first. Then, set the gain offset range. Otherwise, when pulse width is switched over by "SP/LP" key, the amount of background noise may become different.



2.2.2 SEA CURVE

This is the function to set the gradient of STC curves.

The range is 1 to 8. As the numerical figure becomes small, STC curves will become steeper (nearer images will disappear).

The default value is 4

- This page intentionally left blank.-

Chapter 3 How to exchange components

Turn off all power supply before start of works and disconnect all cables from connectors.

Searching for corresponding pages for an exchange of a component (From chapter 3 "How to exchange components" in index, open the corresponding pages and follow the procedures in them.)

3.1 Display unit


3.1.1 Replacement of fuse

The locations of the fuses are on the back panel of Display unit.

Fuse type and rating

Application	Type, dimension (mm)	Fuse characteristic	Rating
Main power	Tubular ($\Phi 6.4 \times 30$)	Normal blow	15 A
Modulator high voltage	Tubular ($\Phi 5.2 \times 20$)	Normal blow	0.8 A
Antenna drive motor (For MDC-5000/5200/5500 series)	Tubular ($\Phi 5.2 \times 20$)	Normal blow	5 A
Antenna drive motor (For MDC-7000(P)/7900(P) series)	Tubular ($\Phi 5.2 \times 20$)	Normal blow	10 A

Fuse locations:



3.1.2 Dismantling of bracket and rear case (MRD-108 / MRD-108P)


1. Loosen four (4) knob bolts and dismantle the Display unit from the mounting bracket.



2. Open the unit by removing ten (10) screws.



3. Disconnect connectors J704, J726 and J729. Cut one (1) wire binding bands. Removing one (1) screws.



3.1.3 Dismantling of bracket and rear case (MRD-109)

1. Loosen four (4) knob bolts and dismantle the Display unit from the mounting bracket.




* (These are necessary works for replacement of components in Display unit)

2. Open the unit by removing ten (10) screws.



3. Disconnect connectors J704, J726 and J729. Cut one (1) wire binding bands.



Go to page 3-5 for 3.1.5 Exchange of Logic PCB
Go to page 3-6 for 3.1.6 Exchange of power supply PCB
Go to page 3-11 for 3.1.8 Exchange of LCD unit.

3.1.4 Dismantling of bracket and rear case (MRD-111)

1. Loosen two (2) knob bolts and dismantle the Display unit from the mounting bracket




* (These are necessary works for replacement of components in Display unit)

2. Open the unit by removing ten (10) screws



3. Disconnect connectors J704, J726 and J729. Cut one (1) wire binding bands.



Go to page 3-5 for 3.1.5 Exchange of Logic PCB
Go to page 3-6 for 3.1.6 Exchange of power supply PCB
Go to page 3-13 for 3.1.9 Exchange of LCD unit.

3.1.5 Exchange of Logic PCB (MRD-108/108P/109/111/MRM-108/108P/110)

1. After dismantling the bracket and rear case as shown in page 3-2 to 3-4, perform as follows:
2. Overturn the unit and remove four (4) screws.



3. Remove eight (8) connector nuts.



4. Remove seven (7) washers and cap for connectors.



5. Overturn the unit and remove thirteen (13) PCB fixing screws.



6. Disconnect connectors J720, J701 and J722.
7. Disconnect connector J709, J710 on the back side of the Logic PCB.




8. Remove the logic PCB (E63-700*)
9. Exchange the logic PCB (E63-700*) with a new one.
10. Reassemble in reversed steps and dismantle the bracket and rear case as shown in page 3-2 to 3-4.


*Subject to version change

3.1.6 Exchange of power supply PCB (MRD-108/108P/109/111, MRM-108/108P/110)


1. After exchange of the logic PCB (page 3-5), perform as follows:
2. Remove five (5) screws and remove angle plate.



3. Disconnect connectors J601, J602, J603 and J604.



4. Remove ten (10) screws.




5. Exchange power supply PCB (E63-600*) with a new one.
6. Reassemble in reversed steps, follow the exchange of the logic PCB (page 3-5) and dismantle the bracket and rear case as shown in page 3-2 to 3-4.


*Subject to version change

3.1.7 Exchange of LCD unit (MRD-108/108P)


1. After dismantling the bracket and rear case as shown in page 3-2, perform as follows:
2. Disconnect connector J613, and remove the two (2) screws fixing the ferrite core.




3. Remove the ferrite core fasteners.



4. Remove twenty-two (22) screws and LCD chassis.



5. Cut one (1) wire binding bands and disconnecter connector CN1.



6. Remove four (4) fasteners on the LCD unit.




3.1.8 Exchange of LCD unit (MRD-109)


1. Remove twelve (12) screws.




2. Disconnect connectors J704, J726 and J729. Cut one (1) wire binding bands.



3. Remove sixteen (16) screws.



4. Cut one (1) wire binding bands.



5. Remove chassis (E69MB1201*).
6. Exchange LCD unit (LQ150X1LX9K) with a new one.
7. Reassemble in reverse steps, the exchange of logic PCB (page 3-5) and dismantle the bracket and rear case (page 3-3).

*Subject to version change

3.1.9 Exchange of LCD unit (MRD-111)


1. After dismantling the bracket and rear case (MRD-111) as shown in page 3-4, perform as follows:
2. Remove one (1) big flat caps and three (3) small flat caps.




3. Remove one (1) big knobs and three (3) small knobs after loosening knob tightening screws.




4. Overturn the display unit and remove eight (8) screws to take out the PCB.



5. Remove twenty (20) screws and key board chassis (E54MB1305*).




6. Remove twelve (12) screws.



*Subject to version change

7. Cut two (2) wire binding bands, remove edge holder (EHP-6).



8. Disconnect connectors J802 (E68-600*).



9. Remove LCD chassis (E54MB1304*).


10. Exchange LCD unit (NL10276BC24-37UC) with a new one.

11. Reassemble in reversed steps and dismantle the bracket and rear case as shown in page 3-4.

*Subject to version change

3.1.10 Exchange of backlight power PCB (MRD-108/108P)

1. After dismantling the bracket and rear case as shown in page 3-2, perform as follows:
2. Disconnect connector J613 and remove seven (7) screws.




3. Exchange for backlight power PCB with a new one.
4. Reassemble in reversed steps and dismantle the bracket and rear case as shown in page 3-2.

3.1.11 Exchange of Rear card connector PCB (MRD-108/108P/MRM-108/108P/110)

1. Remove four (4) screws.



2. Remove the two harness and four spacers.



3. Raise up the board and remove three (3) screws on the back.




Caution:
Please make sure not to drop the removed screws in the cabinet.

Please do not give too much force when raising up the board. The flat cable will be pulled out.

4. Exchange for Rear card connector PCB with a new one.
5. Reassemble in reversed steps and dismantle the bracket and rear case as shown in page 3-2.

3.1.12 Exchange of Connector PCB (MRD-109)

1. After dismantling the step 5 to 3.1.8 Exchange of LCD unit (MRD-109) perform as follows:
2. Remove three (3) screws.



3. Remove two (2) screws.



4. Exchange for Connector PCB with a new one.
5. Reassemble in reversed steps and dismantle the bracket and rear case as shown in page 3-3.

3.1.13 Exchange of Connector PCB (MRD-111)

1. After dismantling the bracket and rear case (MRD-111) as shown in page 3-4, perform as follows:
2. Remove two (2) screws.



3. Exchange for Connector PCB with a new one.
4. Reassemble in reversed steps and dismantle the bracket and rear case as shown in page 3-4.

3.2 Operation unit

3.2.1 Exchange of Panel PCB (MRO-108/108P)

1. Remove four (4) corner caps by sliding up.



2. Remove the bracket by removing four (4) screws.



3. Remove two (2) big flat caps and three (3) flat caps.




4. Remove two (2) big knobs and three (3) small knobs after loosening knob tightening screws.



5. Overturn the Operation unit and remove twelve (12) screws.



6. Open the unit and disconnect two (2) connectors.



7. Remove eleven (11) screws to take out the PCB.



8. Exchange panel PCB (E63-900*) with a new one.
9. Reassemble in reverse steps.

*Subject to version change

3.2.2 Exchange of Panel PCB (MRD-111)


1. After dismantling the bracket and rear case (MRD-111) as shown in page 3-4, perform as follows:
2. Remove one (1) big flat caps and three (3) small flat caps.



3. Remove one (1) big knobs and three (3) small knobs after loosening knob tightening screws.



4. Overturn the display unit and remove eight (8) screws to take out the PCB.



5. Exchange panel PCB (E68-900*) with a new one.
6. Reassemble in reverse steps.

*Subject to version change

3.2.3 Exchange of track ball (MRO-108/108P)

1. Remove four (4) corner caps by sliding up.



2. Remove the bracket by removing four (4) screws.



3. Overturn the Operation unit and remove twelve (12) screws.



4. Open the unit and disconnect the connector on the trackball.




5. Exchange the track ball (TRD-101S (FB) K) with a new one.
As the V-ring on the new track ball is not yet fixed, fix it first.



6. Reassemble in reverse steps.

3.2.4 Exchange of Silicon key (MRD-111)

1. After dismantling the Exchange of Panel PCB (MRD-111) up to step 4 as shown in page 3-23, perform as follows:
2. Remove nineteen (19) screws and key board chassis (E68MB3302*).



3. Exchange silicon key (E54MC1202*).
4. Reassemble in reverse steps.

*Subject to version change

3.3 Antenna Scanner unit

3.3.1 Dismantling of antenna and antenna cover

1. Remove the antenna from the pedestal plate by removing four (4) screws.



2. Remove the cover of stern side by removing four (4) screws.



3. Go to page 3-29 for exchange of Azimuth Pulse unit and Drive unit motor and go to page 3-31 for exchange of V ring.
4. Remove the TR unit by removing two (2) screws and disconnect connectors J1, J2, J3, J4 and J502.



Go to page 3-36 for exchange of Modulator PCB
Go to page 3-39 for exchange of Fan (RB809, RB719A)
Go to page 3-43 for exchange of Magnetron (RB807, RB808/808P)
Go to page 3-45 for exchange of Magnetron (RB809/809P)
Go to page 3-47 for exchange of Magnetron (RB717A, RB718A)
Go to page 3-49 for exchange of Magnetron (RB719A)
Go to page 3-51 for exchange of Transformer (RB809/809P)
Go to page 3-53 for exchange of Transformer (RB717A, RB718A)
Go to page 3-54 for exchange of Transformer (RB719A)
Go to page 3-58 for exchange of IF PCB, MIC and limiter device

3.3.2 Exchange of Azimuth Pulse unit and Drive unit motor (RB806 / 807 / 717A / 718A / 719A)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the bow side cover by removing four (4) screws.



3. Remove the four (4) screws holding Drive unit motor ASSY and disconnect connector J4.



4. Remove the Drive unit motor ASSY.



5. Go to page 3-31 for exchange of V ring.
6. Remove Azimuth Pulse unit (249U155426-03B) by removing two (2) screws.




7. Exchange Drive unit motor (239H53917B)

Note:

In order to provide appropriate gap between gears, insert paper tape with 0.1mm thickness between the main gear and pinion gear, and push Drive unit motor ASSY toward main gear and tighten screws lightly.

Adjust location of Drive unit motor ASSY so that rotation of the main shaft can remove the paper tape by moving out.

Then tighten the screws firmly.



8. Reassemble in reverse steps, and follow the dismantling of antenna and antenna cover (page 3-27).

3.3.3 Exchange of V ring

* As exchange of V ring is rather complicated, it is recommended not to perform the work at site but to ask to KODEN.

1. After the exchange of Azimuth Pulse unit and Drive unit motor (page 3-29), perform as follows:
2. Remove the TR unit by removing two (2) screws and disconnect connectors J3, J4 and J502.



3. Remove the heading pulse detector by removing two (2) screws.



4. Remove the bearing holding parts by removing four (4) screws.



5. Remove six (6) screws.




6. Remove the bearing case by sliding down.



7. Remove the bearing fixing plate by removing six (6) screws.



8. Remove the bearing #6912ZZ and the bearing holder downward.




9. Remove the main gear downward.



10. Remove the key from the main shaft.



11. Remove the main shaft by lifting up.



12. Remove the V ring after wiping off dirty grease.



13. Remove dirty object to clean.



14. Install a new V ring.




15. Put enough grease to seal side evenly without air bubbles.




16. Reassemble in reverse steps, refer to “Exchange of Azimuth Pulse unit and Drive unit motor (page 3-29)” and “Dismantling of antenna and antenna cover (page 3-27)”.

3.3.4 Exchange of Modulator PCB

1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. RB806
Remove the fourteen (14) screws, disconnect connector J13 and unsolder two wires.
Exchange modulator PCB with a new one.
(Modulator PCB: E38-130* for RB806)




- RB807, RB808
Remove the twenty-two (22) screws, disconnect connector J4 and unsolder two wires.
Exchange modulator PCB with a new one.
(Modulator PCB: E71-110* for RB807)
(Modulator PCB: E61-110* for RB808/808P)



*Subject to version change


RB809

Remove the twenty-six (26) screws and disconnect connector J4, J5, J6, J7 and J10.
Exchange modulator PCB with a new one.
(Modulator PCB: E62-110* for RB809/809P)



RB717A, RB718A

Remove the fourteen (14) screws and disconnect connector J5 and J6.
Exchange modulator PCB with a new one.
(Modulator PCB: E41-100* for RB717A)
(Modulator PCB: E41-101* for RB718A)




*Subject to version change

RB719A

Remove the seventeen (17) screws and disconnect connector J5, J6 and J7.

Exchange modulator PCB with a new one.

(Modulator PCB: E48-100* for RB719A)




3. Reassemble in reverse steps and dismantle the antenna and antenna cover (page 3-27).


*Subject to version change

3.3.5 Exchange of Fan (RB809 only)

1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Disconnect connector J10



3. Cut one (1) wire binding bands.




4. Remove four (4) screws fixing the fan.



5. Exchange the fan (FBA06T12H).
6. Reassemble in reverse steps order and dismantle the antenna and antenna cover (page 3-27).

3.3.6 Exchange of Fan (RB719A only)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Disconnect connector J5



3. Remove two (2) screws fixing the fan.



4. Exchange the fan (FBA06T12H).




5. Reassemble in reverse steps order and dismantle the antenna and antenna cover (page 3-27).

3.3.7 Exchange of Magnetron (RB806)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Unsolder two wires.



3. Pull out to wire through hole for wire, remove the corrugated tube.




4. Remove four screws by non-magnetic screwdriver.




Caution:

Use a non-magnetic screwdriver, because the contact of the metal tool with the magnetron will cause deterioration of its performance.

5. Following above picture cut the excess wires from magnetron.



6. Exchange magnetron (MAF1421BY).




7. Reassemble in reverse steps and dismantle the antenna and antenna cover (page3-27).

3.3.8 Exchange of Magnetron (RB807, RB808/808P)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the shielding case by removing eight (8) screws.



3. Remove the magnetron lead two (2) wires from the terminal with a soldering iron and four (4) screws.




4. Cut the excess wires from magnetron and exchange the magnetron MAF1565N or MAF1562R.




5. Reassemble in reverse steps and dismantle the antenna and antenna cover (page 3-27).

3.3.9 Exchange of Magnetron (RB809/809P)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the shielding case by removing eight (8) screws.



3. Remove the magnetron lead two (2) wires from the terminal with a soldering iron and four (4) screws.




4. Cut the excess wires from magnetron and exchange the magnetron M1568BS



5. Reassemble in reverse steps and dismantle the antenna and antenna cover (page 3-27).

3.3.10 Exchange of Magnetron (RB717A, RB718A)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the shielding case by removing three (3) screws.




3. Remove the magnetron lead wires (green and yellow) by cutting three (3) wire binding bands.



4. Remove the magnetron lead wires from the terminal with a soldering iron.



5. Remove four (4) fixing screws with a screw driver of non magnetic material.




6. Exchange magnetron (MSF1425B).




7. Reassemble in reverse steps and dismantle the antenna and antenna cover (page 3-27).

3.3.11 Exchange of Magnetron (RB719A)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the shielding case by removing four (4) screws.




3. Remove the insulating tube from the magnetron lead wires (green and yellow) by cutting two wire binding bands.



4. Remove the magnetron lead wires from the terminal with a soldering iron.




5. Remove four (4) fixing screws with a screw driver of non magnetic material and exchange the magnetron (M1458A).



6. Reassemble in reverse steps and dismantle the antenna and antenna cover (page 3-27).

3.3.12 Exchange of Transformer (RB809/809P)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the twenty-six (26) screws and disconnect connector J4, J5, J6, J7 and J10.



3. Remove magnetron lead wires, capacitor and diode from the transformer terminal with soldering iron.



4. Remove four (4) screws and a nut. Exchange the transformer (KCT-374*).



*Subject to version change


5. Mounting a capacitor (ECQE1104KF) on transformer terminal.




6. Reassemble by reversed step order and dismantle the antenna and antenna cover (page 3-27).

3.3.13 Exchange of Transformer (RB717A, RB718A)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the shield case by removing three (3) screws.



3. Remove magnetron lead wires, capacitor and diode from the transformer terminal with soldering iron.



4. Overturn the TR unit.
5. Remove six (6) screws and a nut.
Exchange the transformer (KCT-330* for RB717A/KCT-331* for RB718A).




*Subject to version change

6. Reassemble by reversed step order and dismantle the antenna and antenna cover (page 3-27).

3.3.14 Exchange of Transformer (RB719A)


1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the modulator PCB by removing seventeen (17) screws and disconnect connectors J5, J6 and J7.



3. Remove the shield case by removing three (3) screws.




4. Overturn the TR unit.
5. Remove the E41-500* by removing four (4) screws.




*Subject to version change


6. Remove the shield case by removing three (3) screws.



7. Remove magnetron lead wires, capacitor and diode from the transformer terminals with a soldering iron.



8. Remove four screws and exchange the transformer (KCT-341*).



9. Reassemble in reversed steps and dismantle the antenna and antenna cover (page 3-27).


*Subject to version change

3.3.15 Exchange of MIC (RB806)

1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove four (4) screws and shield case.



3. Disconnect connector J13.



4. Remove five (5) screws.



5. Exchange MIC UNIT a new one.
6. Reassemble by reversed step order and dismantle the antenna and antenna cover (page 3-27).

3.3.16 Exchange of IF MODULE (RB807/808/808P/809/809P)

1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the module by removing two (2) screws.
RB807, RB808(P), RB809(P)




3. Remove four (4) screws.




4. Reassemble in reverse steps, and dismantle the antenna and antenna cover (page 3-27).

3.3.17 Exchange of IF PCB, MIC and limiter device

1. After dismantling the antenna and antenna cover (page 3-27), perform as follows:
2. Remove the shield case by removing three (3) screws.
RB717A, RB718A




RB719A




3. Remove four (4) magnetron fixing screws with a screw driver of non magnetic material.




4. Remove the magnetron.
RB717A, RB718A



RB719A




5. Remove the filter.




6. Remove two (2) screws.




7. Overturn the TR unit.
RB717A, RB718A




RB719A




8. Remove three (3) screws.



9. Remove the circulator device by removing four (4) screws.




10. Remove four (4) screws.




Note: At the time of assembling, cover the gap between MIC and the limiter with electric conductive tape for shielding. Solder the end tips to prevent self peeling.


11. Peel off the copper shielding tape.




12. Overturn the Transceiver unit and remove four (4) screws.




13. Disconnect connector J1 and remove shield case.




14. Remove four (4) hexagonal posts with a wrench.



15. Remove IF PCB (E41-200*) by removing two (2) screws.



16. Remove the connector and exchange MIC (NJT1973) and limiter device.



17. Reassemble in reverse steps, and dismantle the antenna and antenna cover (page 3-27).

Note: At the time of assembling, cover the gap between MIC and the limiter with electric conductive tape for shielding. Solder the end tips to prevent self peeling.

*Subject to version change

- This page intentionally left blank.-

Chapter 4 Spare parts and Circuit diagram

4.1 Spare parts

Unit	Parts Code	Name	Type	Page No.
Display unit / Processor unit				
MRD-108 MRD-108P	0060772230	LOGIC PCB	E63-700*	4-4 23
	0060772410	POWER SUPPLY PCB	E63-600*	4-4 44
	0060772260	Rear Card connector PCB	E63-910*	4-4 55
	0060772450	Rear Card connector PCB	E63-911*	4-4 55
	0050281049	LCD	G190EG03 V1	4-4 2
MRM-108 MRM-108P	0060772060	Backlight Power PCB	E63-610*	4-4 19
	0060772230	LOGIC PCB	E63-700*	4-5 5
	0060772410	POWER SUPPLY PCB	E63-600*	4-5 8
	0060772260	Rear Card connector PCB	E63-910*	4-5 28
	0060772450	Rear Card connector PCB	E63-911*	4-5 28
MRD-109	0060772230	LOGIC PCB	E63-700*	4-6 34
	0060772410	POWER SUPPLY PCB	E63-600*	4-6 39
	0060772250	Connector PCB	E68-910*	4-6 8
	0059543094	LCD module	LQ150X1LX9K	4-6 20
MRD-111	0060772230	LOGIC PCB	E63-700*	4-8 35
	0060772280	LOGIC PCB	E68-700*	4-7 35
	0060772410	POWER SUPPLY PCB	E63-600*	4-7/8 40
	0060772250	Connector PCB	E68-910*	4-7/8 30
	0060772240	Panel PCB	E68-900*	4-7/8 26
	0060771760	INV.PCB	E54-850*	4-7 33
	0060772400	LED Driver PCB	E68-800*	4-8 33
	0059543065	LCD module	NL10276BC24-13C	4-7 6
MRM-110	0050281059	LCD module	NL10276BC24-37UC	4-8 5
	0060772235	LOGIC PCB	E73-700*	4-9 5
	0060772410	POWER SUPPLY PCB	E63-600*	4-9 8
	0060772260	PCB assembly	E63-910*	4-9 28
Operation unit				
MRO-108	0060772100	PANEL PCB	E63-900*	4-10 6
MRO-108P	0059502052	TRACKBALL	TRD-101S(FB)K	4-10 14
MRO-110	0060772430	PANEL PCB	E73-900*	4-11 13
Scanner (RB806, RB807)				
RB806 (4 kW)	0062706021	TR UNIT [4 kW]	RB806-TR unit	4-12 A0005
	0060771540	MODULATOR PCB[4kW]	E38-130*	4-14 A1
	0059111002	FRONT END MODULE	NJT1949A	4-14 A2
	0058670014	MAGNETRON	MAF1421BY	4-14 V1
	0050351107	LIMITER DIODE	NJS6930	4-14 U2
	0058330333	CIRCULATOR	NJC3901D	4-14 W1
	0063703175	15W MOTOR	239H53917B	4-15 1
	0056280012	MOTOR BRUSH	24Z125209	4-15 1-8
	0030050034	AZI.PULSE UNIT	249U155426-04	4-15 3
RB807 (6 kW)	0030050033	TR UNIT [6 kW]	RB807-TR unit	4-16 13
	0065103241	HARNESS	E62ELA040B	4-17 30
	0060772270	MODULATOR PCB [6kW]	E71-110*	4-18 31
	0030050031	RFM-10*	RFM-10*	4-18 15
	0058670016	MAGNETRON	MAF1562R	4-18 23
	0060772160	PCB ASSY	E61-120*	4-18 3
	0050351107	DIORD LIMITER	NJS6930	4-18 13
	0058330331	CIRCULATOR	FCX68R	4-18 11
	0071803361	SPURIOUS FILTER	NJC9952	4-18 21
	0063703175	15W MOTOR	239H53917B	4-15 1
0056280012	MOTOR BRUSH	24Z125209	4-15 1-8	
	0030050034	AZI.PULSE UNIT	249U155426-04	4-15 3

*Subject to version change


Unit	Parts Code	Name	Type	Page No.
Scanner (RB808, RB808P, RB809, RB809P)				
RB808 RB808P (12 kW)	0030050031	RFM-10*	RFM-10*	4-22 7
	0058330331	CIRCULATOR	FCX68R	4-22 10
	0050351107	DIORD LIMITER	NJS6930	4-22 8
	0060772160	PCB ASSY	E61-120*	4-22 3
	0071803361	SPURIOUS FILTER	NJC9952	4-22 11
	0030050030	TR UNIT [12IW]	RB808-TR UNIT	4-19/20 13
	0060772110	PCB ASSY	E61-110*	4-22 2
	0058670036	MAGNETRON	MAF1565N	4-22 14
	0060772140	PCB ASSY	E61-500*	4-23 4
	0056210034	BLUSHLESS MOTOR	VGKC12-25N50L2T6	4-23 1
	0035103241	HARNESS	E62ELA040B	4-21 30
RB808P (12 kW)	0030050032	PERFORMANCE MONITOR	KPM-20(C) **	4-20 20
RB809 RB809P (25 kW)	0030050027	TR UNIT	RB809-TR	4-24/25 13
	0060772150	PCB ASSY	E62-110*	4-26 2
	0030050031	RFM-10*	RFM-10*	4-26 7
	0058670037	MAGNETRON	M1568BS	4-26 14
	0056401376	PLUSE TRANSFORMER	KCT-374*	4-26 4
	0056210034	BLUSHLESS MOTOR	VGKC12-25N50L2T6	4-23 1
	0058330331	CIRCULATOR	FCX68R	4-26 10
	0060772160	PCB ASSY	E61-120*	4-26 3
	0060772140	PCB ASSY	E61-500*	4-23 4
	0050351107	DIORD LIMITER	NJS6930	4-26 8
	0071803361	SPURIOUS FILTER	NJC9952	4-26 11
	0065103241	HARNESS	E62ELA040B	4-21 30
RB809P (25 kW)	0030050032	PERFORMANCE MONITOR	KPM-20(C) **	4-25 20

**The exchange of performance monitor kit will be performed at KODEN.


*Subject to version change

Unit	Parts Code	Name	Type	Page No.
Scanner (RB806, RB717A, RB718A, RB719A)				
RB806 RB717A RB718A RB719A Common	0062703175	DRIVE UNIT MOTOR	239H53917B	4-30 1
	0035830007	AZI PULSE UNIT	249U155426-03B	4-30 3
	0056280012	MOTOR BRUSH	24Z125209	4-30 1-8
	0059111005	MIC	NJT1973	4-33 11 / 4-29 C0012
	0050351107	Limiter	NJS6930	4-33 7 / 4-29 C0011
	0060720130	IF PCB	E41-200*	4-33 18 / 4-29 C0018
	0082202190	V ring	24E112007	4-32 13 / 4-28 B1001
RB717A (6 kW)	0030050002	TR UNIT [6 kW]	RB717A-TR	4-27 A0005
	0060710380	MODULATOR PCB [6 kW]	E41-100*	4-29 C0002
	0056401330	TRANSFORMER	KCT-330*	4-29 C0004
	0058670015	MAGNETRON	MSF1422B[J]	4-29 C0023
RB718A (12 kW)	0030050023	TR UNIT [12kW]	RB718A-TR	4-27 A0005
	0060710490	MODULATOR PCB [12 kW]	E41-101*	4-29 C0002
	0056401331	TRANSFORMER	KCT-331*	4-29 C0004
	0058670034	MAGNETRON	MSF1425B[J]	4-29 C0023
RB719A (25 kW)	0030050024	TR UNIT [25kW]	RB719A-TR	4-31 13
	0060710480	MODULATOR PCB [25 kW]	E48-100*	4-33 2
	0056401341	TRANSFORMER	KCT-341*	4-33 4
	0058670033	MAGNETRON	MSF1458A	4-33 22


*Subject to version change




APPROVED		CHECKED	DRAWN	TYPE	TITLE
Max. 2,2016		Max. 2,2016	Feb. 26, 2016	MRD-108 MRD-108P	EXPLODED VIEW OF DISPLAY UNIT 指示機分解図
Mr. Shinya Yamanaka		Mr. Shinya Yamanaka		KODEN ELECTRONICS	DWG.No. E63BG13000
UNIT		mm / Inch	SCALE	KODEN ELECTRONICS SOLU.TS.	
SYMBOL		DESCRIPTION OF REVISIONS	DATE	DRAWN	CHD.




APPROVED	CHECKED	DRAWN	TYPE	TITLE	
Mar.3,2016	Mar.6,2016	Mar.10,2016	MRM-108 MRM-108P	EXPLODED VIEW OF DISPLAY UNIT	
Mr. Shigeaki Yamamoto			制御部分解図		
UNIT	mm / inch	KODEN ELECTRONICS CO.,LTD.		DWG.No.	E63BG33030
DESCRIPTION OF REVISIONS		DATE	DRAWN	CHKD.	APPRD.




SYMBOL	DESCRIPTION OF REVISIONS		DATE	DRAWN	CHKD.	APPROV.	SCALE
	Add No.43-2, 43-3.						
APPROVED		CHECKED	DRAWN	TYPE		TITLE	
Apr. 8 '16		Apr. 8 '16	Apr. 8 '16	MRD-109		Exploded view of display unit	
Mr. Oguchi / Shimizu		Mr. Yamamoto				指示機分解図	
UNIT		mm / inch	KODEN		Koden Electronics Co., Ltd.		DWG.No.
							E69BG13021




APPROVED		CHECKED	DRAWN	TYPE	TITLE
Date: 8/18		Date: 8/18	Date: 8/18	MRD-111	Exploded view of display unit
976. Ogakiyama, Shimizu 51, Shizuoka					指示機分解図
UNIT	mm	inch	DWG.No. E68BG13021		
DATE			DRAWN	CHKD.	APPD.
DESCRIPTION OF REVISIONS			SCALE		
△	Add No.4-2-44-3.				
SYM.					




SYMBOL	DESCRIPTION OF REVISIONS	DATE	DRAWN	CHKD.	APPROD.	SCALE	UNIT	mm / inch	KODEN Kodan Electronics Co., Ltd.	DWG. No. E68BG33020
TITLE: Exploded view of display unit 指示機分解図 TYPE: MRD-111(DB) DRAWN: Jan. 28 '15 CHECKED: Jan. 28 '15 DRAWN BY: S. Yamashiro CHECKED BY: S. Yamashiro										






SYMBOL	DESCRIPTION OF REVISIONS	DATE	DRAWN	CHEK.	APPRO.	SCALE	→
APPROVED CHECKED DRAWN TYPE Jan. 28 '16 Jan. 28 '16 Jan. 28 '16 M. Ogata M. Ogata Y. Shimizu M. Ogata M. Ogata Y. Shimizu							
TITLE				EXPLODED VIEW OF OPERATION UNIT			
UNIT				MRO-108			
MFG. No.				E63BG20020			
KODEN				Koden Electronics Co., Ltd.			




APPROVED	CHECKED	DRAWN	TYPE	TITLE
May 2011	May 19 11	May 19 11	MRO-110	Exploded view of Operation unit
S. Maeda			操作部分解図	
KODEN			E73BG23020	
UNIT mm / inch			DWG.No.	
SCALE			E73BG23020	


SYM.	DESCRIPTION OF REVISIONS	DATE	DRAWN CHD.	APPR.	SCALE




APPROVED	CHECKED	DRAWN	TYPE	TITLE
May30,2003	May30,2003	May29,2003	RE716A	ANTENNA-SCANNER UNIT EXPLODED VIEW
M.OZAKI	H.SATO	T.KOJIMA	RB8.06	
UNIT	mm / inch	SCALE	DWG.No. 23W73461 Version 03	

DATE	DRAWN	CHD.	APPD.	SCALE	DESCRIPTION OF REVISIONS
Feb.8,2005					A RB8.06 addition
Mar. 4,2009					A File change.
					A For the reason for processing or old drawing incorrectly, the new drawing was made.
					SYM.








APPROVED	CHECKED	DRAWN	TYPE	TITLE
Mar.22.2003	Mar.22.2003	Mar.9.2003	RB718A/RB717A /RB718A/RB718BP /RB719A/RB719BP /RB806/RB807	DRIVE UNIT EXPLODED VIEW
M. OZ OKI	M. OZ OKI	T. Kodaguchi		
DATE	DRAWN	CHKD.	APPRD.	SCALE
Jun. 5.2008				
DESCRIPTION OF REVISIONS				
SYM.				
Δ	Type RB806, RB807 addition.			
Δ	Indication number change.			
Δ	TYPE RB718BP, RB719BP addition.			
				DWG.No. E48BG10133




APPROVED	CHECKED	DRAWN	TYPE	TITLE
May/12/2016	May/12/2016	May/11/2016	RB807	ANTENNA-SCANNER UNIT EXPLODED VIEW
S. Muramatsu Mr. Oguchi Mr. Saito				DWG.No. E71BG10100
UNIT	mm / Inch	SCALE	KODEN Koden Electronics Co., Ltd.	
DATE	DRAWN	CHD.	APPR.	
SYM. DESCRIPTION OF REVISIONS				










APPROVED	CHECKED	DRAWN	TYPE	TITLE
Mar.19.2014	Mar.19.2014	Mar.19.2014	RB808P	ANTENNA-SCANNER UNIT EXPLODED VIEW
<i>Mr. Yoshiki Morioka</i> for Signature				
UNIT mm / Inch			DWG.No. E61BG10100	
SCALE →			KODEN Kodan Electronics Co.,Ltd.	
SYMBOL	DESCRIPTION OF REVISIONS	DATE	DRAWN	CHD.






APPROVED		CHECKED	DRAWN	TYPE	TITLE
04/30/2015		04/30/2015	04/30/2015	RB808 RB808P	TR PART EXPLODED VIEW
M. Ogata		KODEN		KODEN Electronics Co., Ltd.	
UNIT	mm / Inch	SCALE	DWG. No. E61BG10130		
SYN.	DESCRIPTION OF REVISIONS	DATE	DRAWN	CHD.	APPD.






APPROVED	CHECKED	DRAWN	TYPE	TITLE
May/3,2016	May/13,2016	May/11,2016	RB809	ANTENNA-SCANNER UNIT EXPLODED VIEW
Y. Yamashita Mr. Ogata Mr. Saito				スキャナーユニット分解図
UNIT	mm / Inch	KODEN Kodan Electronics Co.,Ltd.		DWG.No. E62BG10140
DATE	DRAWN	CHD.	APPD.	SCALE
SYM.	DESCRIPTION OF REVISIONS			





APPROVED Mar.18,2014	CHECKED Mar.18,2014	DRAWN Mar.18,2014	TYPE RB809P	TITLE ANTENNA-SCANNER UNIT EXPLODED VIEW
Mr. Osamu Yamamoto for Signature KODEN Koden Electronics Co.,Ltd.				スキャナーユニット分解図 DWG.No. E62BG10100
UNIT	mm / inch	SCALE		

SYM.	DESCRIPTION OF REVISIONS	DATE	DRAWN	CHKD.	APPR.	SCALE




APPROVED		CHECKED	DRAWN	TYPE	TITLE
04/28/2015		04/28/2015	04/26/2015	RB809 RB809P	TR PART EXPLODED VIEW
Mr. Osamu Yamamoto		KODEN		KODEN Electronics Co., Ltd.	
UNIT	mm / Inch	SCALE	DWG. No. E62BG10130		
SYMBOL	DESCRIPTION OF REVISIONS	DATE	DRAWN	CHD.	APPRD.






Type RB806, RB807 addition, delete 1-5 Indication number change. TYPE RB718BP, RB719BP addition. SYM. DESCRIPTION OF REVISIONS	Date: 12/11/2009 Drawn: M. OZ Checked: M. OZ Approved: M. OZ Date: Feb. 2, 2009 Date: Mar. 5, 2008	APPROVED M. OZ Mar. 22, 2009 M. OZ Mar. 22, 2009 T. Kodaira	CHECKED M. OZ Mar. 22, 2009 T. Kodaira	DRAWN M. OZ Mar. 19, 2009 T. Kodaira	TYPE RB718A/77A RB718A/RB719BP RB719A/RB719BP RB806/RB807	TITLE DRIVE UNIT EXPLODED VIEW
KODEN Koden Electronics Co., Ltd.						
					DWG.No.	E48BG10133



APPROVED		CHECKED	DRAWN	TYPE	TITLE
Feb.16.2003		Feb.16.2003	Aug. 5.2002	RB719.A	ANTENNA-SCANNER UNIT EXPLODED VIEW
M. Ozaki		A. Miyazaki	T. Kasahara		
DATE		DATE	DATE	UNIT	DWG.No.
Sep.13.2010			mm / inch	ELECTRONICS	E48BG20101
DESCRIPTION OF REVISIONS		CHD.	APPD.	SCALE	
Title change					
SYM.					



APPROVED		CHECKED	DRAWN	TYPE	TITLE	TR PART	EXPLODED VIEW
2012.5.14	2012.5.14	2012.5.14	2012.5.14	RE719A			
2012.5.14	2012.5.14	2012.5.14	2012.5.14				
2008.5.11	2008.5.11	2008.5.11	2008.5.11				
DATE	DATE	DATE	DATE				
SYN.	SYN.	SYN.	SYN.				
DESCRIPTION OF REVISIONS							
No.5 changed.							
No.27 and No.29 are added.							
Figure Change							
KODEN Koden Electronics Co., Ltd.							
DWG.No. E48BG20127							

4.2 Circuit diagram

Inter connection diagram of Scanner unit

Model	Scanner Unit	Drawing No.	page
MDC-5004/5204/5504	RB806 (4 kW)	E38CGB010*	4-35
MDC-5006/5206/5506/7006/7906	RB807 (6 kW)	E71CFA110*	4-37
MDC-5012/5212/5512/7012/7912	RB808 (12 kW)	E61CGB004*	4-39
MDC-7012P/7912P	RB808P (12 kW)	E61CGB003*	4-40
MDC-5025/5225/5525/7025/7925	RB809 (25 kW)	E62CGB004*	4-41
MDC-7025P/7925P	RB809P (25 kW)	E62CGB003*	4-42
MDC-5240/5540	RB716A (4 kW)	E38CGB010*	4-36
MDC-5060/5260/5560/7060/7960	RB717A (6 kW)	E41CGB011*	4-38
MDC-5010/5210/5510/7010/7910	RB718A (12 kW)	E41CGB011*	4-38
MDC-5020/5220/5520/7020/7920	RB719A (25 kW)	E48CGB004*	4-43

Inter connection diagram

Model	Unit	Drawing No.	page
MDC-7906/7912(P)/7925(P)/7960/7910/7920	MRD-108(P)	E63CGB002*	4-44
MDC-7006/7012(P)/7025(P)/7060/7010/7020	MRM-108(P)	E63CGB003*	4-45
MDC-5204/5206/5212/5225/5240/5260/5210/5220	MRD-111	E68CGB003*	4-46
MDC-5504/5506/5512/5525/5540/5560/5510/5520	MRD-109	E69CGB002*	4-47
MDC-5004/5006/5012/5025/5060/5010/5020	MRM-110	E73CGB002*	4-48

*Subject to version change

Circuit diagram

(MDC-7000(P)/7900(P))

Name	PCB ASSY	Drawing No.	page
Power PCB	E63-600*	E63-600*	4-49,50
BACK LIGHT POWER PCB	E63-610* (MRD-108(P))	E63-610*	4-51
CONNECTOR PCB	E63-911*	E63CGB911*	4-55
PANEL BOARD	E63-900*	E63CGB900*	4-52

Circuit diagram

(MDC-5000)

Name	PCB ASSY	Drawing No.	page
Power PCB	E63-600*	E63-600*	4-49,50
CONNECTOR PCB	E63-911*	E63CGB911*	4-55
PANEL BOARD	E73-900*	E73CGB900*	4-54


Circuit diagram

(MDC-5200/5500)

Name	PCB ASSY	Drawing No.	page
Power PCB	E63-600*	E63-600*	4-49,50
CONNECTOR PCB	E68-910*	E68CGB910*	4-56
PANEL BOARD	E63-900* (MRO-108)	E63CGB900*	4-52
	E68-900* (MRD-111)	E68CGB900*	4-53


*Subject to version change

4.2.1 Interconnection diagram of 4kW Scanner Unit (RB806)




△	Add the circuit components on PCB E38-130*	2015.06.11	Ito	Kushizma	Umemiya	APPROVED	CHECKED	DRAM	DESIGNED	MOEL	RB806	TITLE Inter Connection Diagram of 4kw Open Scanner Unit	PAGE 1/1
△	Change the type of Magnetron.	2015.06.11	Ito	KUSHIZMA	Umemiya	Y. UMEMIYA	K. KUSHIZMA	H. ITO	H. ITO			ENG. NO. E38CG8010A	
NO	CONTENTS	DATE	REVISED	CHECKED	APPROVED	2015.06.11	2015.06.10	2015.06.10	2015.06.10	KODEN	Koden Electronics Co., Ltd.		

4.2.2 Interconnection diagram of 4 kW Scanner Unit (RB716A)




4.2.3 Interconnection diagram of 6 kW Scanner Unit (RB807)




NO.	CONTENTS	DATE	REVISED	CHECKED	APPROVED	APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	TITLE	DWG. NO.	PAGE
						H. ITO		M. SATO	M. SATO	RB807	INTER CONNECTION DIAGRAM (6kW SCANNER UNIT)	E71CFA1100	1/1

APPROVED: H. ITO (15.03.01)
 CHECKED: H. KUBOYAMA (15.03.01)
 DRAWN: M. SATO (15.07.30)
 DESIGNED: M. SATO (15.07.30)
 MODEL: RB807
 TITLE: INTER CONNECTION DIAGRAM (6kW SCANNER UNIT)
 DWG. NO.: E71CFA1100
 KODEN Koden Electronics Co., Ltd.

4.2.4 Interconnection diagram of 6 kW/12 kW Scanner Unit (RB717A/718A)




4.2.5 Interconnection diagram of 12 kW Scanner Unit (RB808)




APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	RBB08	TITLE	INTER CONNECTION DIAGRAM (12KW SCANNER UNIT)
H. ITO	T. GOMI	K. KUSHIMA	K. KUSHIMA	DATE	*14-09-18	DRW. NO.	E61CGB0040
NO.	CONTENTS	DATE	REVISED	CHECKED	APPROVED	PAGE 1/1	

4.2.6 Interconnection diagram of 12 kW Scanner Unit (RB808P)




REV	CONTENTS	DATE	REVISED	CHECKED	APPROVED	APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	TITLE	DWG. NO.	PAGE
						H. ITO	T. GOMI	K. KUSHIMA	K. KUSHIMA	RB808P	INTER CONNECTION DIAGRAM [12kW SCANNER UNIT]	E61CGB0030	1/1

4.2.7 Interconnection diagram of 25 kW Scanner Unit (RB809)




NO	CONTENTS	DATE	REVISEE	CHECKED	APPROVED	APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	TITLE	DWG. NO.	PAGE
						H. ITO	T. GOMI	K. KUSHIHA	K. KUSHIHA	RB809	INTER CONNECTION DIAGRAM (25kW SCANNER UNIT)	E62CGB0040	1/1
						14.09.18	14.09.18	14.09.18	14.09.18	KODEN	Koden Electronics Co., Ltd.		

4.2.8 Interconnection diagram of 25 kW Scanner Unit (RB809P)




NO.	DATE	REVISION	CHECKED	APPROVED	NOCEL	TITLE	DWG. NO.	PAGE
H. ITO	14.09.18		T. GOMI		RB809P	INTER CONNECTION DIAGRAM (25kW SCANNER UNIT)	E62CGB0030	1/1
K. KUSHIMA	14.05.18		K. KUSHIMA		KODEN	Koden Electronics Co., Ltd.		

4.2.9 Interconnection diagram of 25 kW Scanner Unit (RB719A)




△×4	仕様ミス修正、フェルダール追加 (変更指示No. B719-022)	2013.12.10	S. Yanaka	T. Aski	S. Yamada														
△×2	コナアンサ 1200P/10kV1 C102, C103 追加	2009.05.15	Ito	Kuhtama	Uemura														
△×4	MODULATOR BOARD、IF AMP BOARD、Pulse Transformer 規格変更/ダイオード規格追加	2006.8.21	K. Ono	H. Ito	Uemura														
△×2	部品名の名称、スペル修正 PACKING GLAND/CABLE GLAND/CONNECTION CONNECTION	2004.1.26	H. Ito	Y. Aso	H. Iida														
NO.8	CONTENTS	DATE	REVISED	CHECKED	APPROVED														
										APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	TITLE		PAGE		
										H. Iida	Y. Aso	H. ITO	H. ITO	RB719A	INTER CONNECTION DIAGRAM OF 25kW SCANNER UNIT		1/1		
										03.3.25	03.3.25	03.3.25.	03.3.25.	KODEN	Koden Electronics Co., Ltd.		E48CGB004D		

4.2.10 Inter connection diagram MRD-108/MRD-108P




APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	TITLE
H. MAEDA	Y. UMEZAKI	T. GOMI	T. GOMI	MRD-108(P)/MRD-108(P)	Inter Connection Diagram
MD	CONTENTS	DATE	REVISED	DATE	APPROVED
		2017.06.02		2017.06.01	
				2017.06.01	
				2017.06.01	
KODEN Kodon Electronics Co., Ltd.					FIG. NO. E63CGB002B
					PAGE 1/1

4.2.11 Inter connection diagram MRM-108/MRM-108P




NO.	CONTENTS	DATE	REVISED	CHECKED	APPROVED
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					
46					
47					
48					
49					
50					
51					
52					
53					
54					
55					
56					
57					
58					
59					
60					
61					
62					
63					
64					
65					
66					
67					
68					
69					
70					
71					
72					
73					
74					
75					
76					
77					
78					
79					
80					
81					
82					
83					
84					
85					
86					
87					
88					
89					
90					
91					
92					
93					
94					
95					
96					
97					
98					
99					
100					

4.2.12 Inter connection diagram MRD-111




* This diagram is applied to the Direct bonding type.


4.2.14 Inter connection diagram MRM-110



4.2.15 Circuit diagram Power supply PCB





Date	DESCRIPTION	Revision	Date	DESCRIPTION	Revision	Title
2016.9.29	C81 : 100uF R130 : 10k R78 : 33k Q9,Q10 : 2SC2712 C31 : 1000pF -> 0.1uF J605 : Delete	R131 : 3.3k R126 : 0 C82 : NM	2016.6.13	R20 : 330k -> 4.7k	△	<E63-600A>
		△	2015.10.19	R21 : 10k -> 1k	△	Size A3 Document Number <E63-600A> Rev <Rev
						Date: Monday, October 03, 2016 Sheet 1 of 2




File	<E3-420A>	Rev	
Site	<E3-420A>	Rev	
Date	Monday, October 03, 2015	Sheet	2 of 2

4.2.16 Circuit diagram of BACK LIGHT POWER PCB




Doc	CE83-6100	Rev	
Doc	Document Number	Rev	
Doc	CE83-6100 Circuit	Rev	
Doc	Thursday, March 06, 2014	Sheet	1 of 1

4.2.18 Circuit diagram of PANEL BOARD (E68-900*)




REV	U7: KM-F49B=KM-F49C	99	2017.05.31	T. GOMI	UJEMUYA	NAEDA	APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	MRD-111	TITLE	PANEL BOARD	PAGE	1/1
	U7: KM-F49A=KM-F49B	99	2016.10.18	T. GOMI	UJEMUYA	H-ITO	H-ITO	K-ENDO	T. GOMI	T. GOMI				E68CGB900B		
NO2	CONTENTS			DATE	REVISED	CHECKED	APPROVED	2016.03.01	2016.03.01	2016.06.09	2016.06.04	KODEN	Koden Electronics Co., Ltd.			

4.2.19 Circuit diagram of PANEL BOARD (E73-900*)




APPROVED	CHECKED	DRAWN	DESIGNED	MODEL	TITLE
H. ITO	T. SENO	T. GOMI	T. WENO	MRO-110	操作部回路図 (E73-900)
2017.12.20	2017.12.26	2017.12.19	2006.09.22	KODEN Koden Electronics Co., Ltd.	E73CGB900A
R44, R46: 1k → 2.2k CONTENTS DATE REVISED CHECKED APPROVED					PCB ASSY: E73-9000 PCB BARE: E53-900A 緑 (SML012MT) 青 (SML010VT) PCB ASSY: E73-9000 PCB BARE: E53-900A DWG. NO. E73CGB900A PAGE 1/1

4.2.20 Circuit diagram of CONNECTOR PCB (E63-911*)



APPROVED	CHECKED								
H. NAEDA 2017.04.11	Y. UMEMIYA 2017.04.11								
MOD	CONTENTS								
DRAWN	DESIGNED	MODEL	TITLE						
T. GOMI 2017.02.03	T. GOMI 2017.01.19	MRD-108/MRM-108/110	REAR CARD CONNECTOR PCB						
		KODEN Koden Electronics Co., Ltd.	DWG. NO. E63CGB9110	PAGE	1/1				


4.2.21 Circuit diagram of CONNECTOR PCB (E68-910*)



Annex

A.1 Clean up the trackball

1. Referring to the exchange of track ball (page 3-24), take off the track ball.



2. Remove the track ball cover attached to the case, and clean it.
*Cleaning can be done with a rag soaked in fresh water and squeezed. Do not apply any detergent.



3. Take off O-ring from the track ball.



4. Clean the O-ring, the ball and the contact of ball.



5. After cleaning, reassemble the track ball referring to the exchange of track ball (page 3-24).

A.2 Interface

All input from external sensors such as GYRO and LOG are made with serial signal of IEC 61162-1 or 2. Therefore, it is necessary to put an interface unit between, when GYRO or LOG without output of IEC 61162-1 or 2 is connected.

1. Relation between functions and input signal

For radars, some signals are needed depending on their functions. The table below shows the relation.


The mark ○ in the table shows that the marked signal is necessary for performing the function.

Function		Necessary signal	HDG	STW	COG/SOG	POSITION (LAT/LON)	DTM (WGS84)
EBL TRUE			○	-	-	-	-
CURSOR LAT/LON			○	-	-	○	-
TRUE TRAIL			○	-	-	○	-
RELATIVE TRAIL			-	-	-	-	-
OS PAST TRK			○	-	-	○	-
GND STAB			○	-	○	-	-
SEA STAB			○	○	-	-	-
TT (ATA)			○	○	○ Note 1	-	-
AIS			○	○	○	○	○
MAP	COAST LINE NAV LINE ROUTE EVENT MARK AREA		○	-	-	○	-

Note 1: When TT (ATA) is used setting the stable mode at GND STAB under the condition that item of MAINTENANCE > I/O > COG/SOG has been set at EPFS, the vector of a tracking target may wobble. This is because COG of own ship may wobble due to the error in measuring position, when the speed of own ship is rather slow. Therefore, the vector of a tracking target may wobble as ATA calculates the course of the tracking target using this COG.

Consequently, it is strongly recommended that speed against water shall be applied in IMO resolution A.823 (19) on ARPA.

2. Kind of input/output ports



As the serial input/output ports of MDC-5000/5200/5500/7900(P)/7000(P) Series, total 4 ports for J3(NAV), J5(EPFS), J6(SDME) and J2(AIS) are provided as shown above.

MDC-7900/7000/7900P/7000P	MDC-5000/5200/5500
NAV IEC 61162-2	J3 38400bps
EPFS IEC 61162-1	J5 4800bps
SDME IEC 61162-1	J6 4800bps
AIS IEC 61162-2	J2 38400bps

For 3 ports for J3(NAV), J5(EPFS) and J6(SDME) the format is selectable from either one in IEC 61162-1 and IEC 61162-2.

Alternating method of format at radar side:

MDC-7900/7000/7900P/7000P

MENU > MAINTENANCE > I/O > FORMAT > NAV 61162-2 > 61162-1 or 61162-2 [ENT]

MENU > MAINTENANCE > I/O > FORMAT > EPFS 61162-1 > 61162-1 or 61162-2 [ENT]

MENU > MAINTENANCE > I/O > FORMAT > SDME 61162-1 > 61162-1 or 61162-2 [ENT]

MDC-5000/5200/5500

MENU > MAINTENANCE > I/O > BAUDRATE > J3 38400bps > 4800, 9600 or 19200 [ENT]

MENU > MAINTENANCE > I/O > BAUDRATE > J5 4800bps > 9600, 19200 or 38400 [ENT]

MENU > MAINTENANCE > I/O > BAUDRATE > J6 4800bps > 9600, 19200 or 38400 [ENT]

These 3 ports are designated as J3(NAV), J5(EPFS) and J6(SDME) for descriptive purposes, either port can accept input of HDG, STW, COG/SOG, POSITION (LAT/LON), TIME, DTM or ROUTE at the initial status of delivery from Plant.

Serial format IEC 61162-1 or IEC 61162-2 standard:

Baudrate	IEC 61162-1	4,800 bps
	IEC 61162-2	38,400 bps
Data length		8 bit
Parity		None
Stop bit		1 bit
Sentence length		Max. 82 characters
Checksum		Yes

3. Setup Interface

Setup of input shall be performed in the menu screen, MENU > MAINTENANCE > I/O, in the figure below.

MENU		
> MAINTENANCE		
> I/O		
HDG		>
GYRO	11.6°	←
OFFSET	0.0°	←
STW		>
GPS	14.1 kn	←
COG/SOG		>
GPS	9.2°	←
GPS	14.1kn	←
POSITION		>
DGPS	35°14.733 N	
	139°45.949 E	
OFFSET	MAN	
MAN	0.000N	
	0.000E	
DATUM	REF	NONE
	LOCAL	W84
SET/DRIFT		>
MAN	0.0°	
	0.0°kn	
TIME		>
CLOCK	24/05/18	←
	03:01	
TIME ZONE	00:00	
OUTPUT		>
INPUT		>
BAUDRATE		>
KGC SET		>
JB-35 SET		>
SERIAL MONITOR		>

When the sentence set in the set items is not input, the name of device is not displayed and XXX is displayed.

Those show the values of sentences set in the set items.

MDC-7900

3.1 Input and setup of HDG

To improve the accuracy of TT (ATA) function, signals with fast transmission cycle are necessary.

Input conditions:

Transmission cycle	25 ms ~ 100 ms
Baudrate (Format)	4800bps (IEC 61162-1), 9600bps, 19200bps or 38400bps (IEC 61162-2)
Talker device	GA, GP, GL, GN, IN, SN, HE, HN, HC
Sentence formatter	THS > HDT
Input port	J3 (NAV), J5 (EPFS), J6 (SDME)

When input is correct, they will be displayed regardless of the setup of radars.

Offset (compensation) of HDG:

When values of HDG to be input have deviations, they can be compensated with adding a fixed value to the input values.

Compensation method:

MENU > MAINTENANCE > I/O > HDG > OFFSET > 0.0 - 359.9

3.2 Input and setup of STW

When it is in sea stabilization, the speed used for TM, trail, TT (ATA) and AIS shall be set.

Input conditions:

Transmission cycle	1 s
Baudrate (Format)	4800bps (IEC 61162-1), 9600bps, 19200bps or 38400bps (IEC 61162-2)
Talker device	GA, GP, GL, GN, IN, SN, VD, VM, VW
Sentence formatter	VBW > VHW
Input port	J3, J5, J6 (SDME)

Setting method of STW:

In the case of MDC-7900P/7000P Series (IMO), when a sentence is input from LOG.

MENU > MAINTENANCE > I/O > STW > STW > SDME [ENT]

If the speed sensor breaks down, select manual speed [MAN] and input manual speed values.

MENU > MAINTENANCE > I/O > STW > STW > MAN [ENT]

MENU > MAINTENANCE > I/O > STW > MAN > 0.0 to 100.0 [ENT]

Note: Speed can be manually input with selecting MAN for emergency purpose. However, AIS cannot be used in this case.

3.3 Input and setup of COG/SOG

When it is in ground stabilization, the speed used for TM, trail, TT (ATA) and AIS shall be set.

Input conditions:

- Transmission cycle 1 s
- Baudrate (Format) 4800bps (IEC 61162-1), 9600bps, 19200bps or 3840bps (IEC 61162-2)
- Talker device GA, GP, GL, GN, IN, SN, VD, VM, VW
- Sentence formatter VBW > VTG
- Input port J3 (NAV), J5 (EPFS), J6 (SDME)

Setting method of COG/SOG:

When a sentence from navigation equipment (Talker devices: GA, GP, GL, GN, IN, SN) has been input, select EPFS.

MENU > MAINTENANCE > I/O > COG/SOG > COG/SOG > EPFS (or AUTO) [ENT]

If a sentence from LOG (Talker devices: VD, VM, VW) has been input, select SDME.

MENU > MAINTENANCE > I/O > COG/SOG > COG/SOG > SDME (or AUTO) [ENT]

When there is no input of VBW from SDME and there is VHW, and when SET/DRIFT signal (VDR) from a tide meter has been input, then select CURRENT.

MENU > MAINTENANCE > I/O > COG/SOG > COG/SOG > CURRENT [ENT]

Note: When CURRENT is selected, AIS cannot be used.

Example of sentence:

VTG	Course and ground
	<div style="display: flex; justify-content: space-between;"> <div style="width: 70%;"> <p style="margin: 0;">\$GPVTG, 30.0, T, 30.0, M, 2.3, N, 4.2, K, D *21</p> <div style="display: flex; justify-content: space-between; font-size: small;"> <div style="width: 20%;"> <p>Start of sentence</p> <p>Talker device</p> <p>Sentence formatter</p> </div> <div style="width: 40%; text-align: center;"> <p>These fields are not used</p> <p>Course over ground, true bearing</p> </div> <div style="width: 20%; text-align: center;"> <p>Speed over ground, knots</p> <p>Speed over ground, km/h</p> </div> <div style="width: 10%; text-align: center;"> <p>Mode indicator</p> <p>Check sum</p> </div> </div> </div> <div style="width: 25%; font-size: x-small;"> <p>Note:</p> <p>Mode indicator:</p> <p>A=Autonomous</p> <p>D=Differential</p> <p>E=Estimated</p> <p>M=Manual input</p> <p>S=Simulator</p> <p>N=Data not valid</p> </div> </div>

Note: When mode indicator shows E, M, S, N, COG/SOG will be displayed with XX.XXX in red and its associated functions will become unusable.

3.4 Input and setup of SET/DRIFT

When CURRENT is selected for COG/SOG used at ground stabilization, SET/DRIFT (VDR) to be added to STW is set to get COG/SOG.

Input conditions:

- Transmission cycle 1 s
- Baudrate (Format) 4800bps (IEC 61162-1), 9600bps, 19200bps or 3840bps (IEC 61162-2)
- Talker device GA, GP, GL, GN, IN, SN, VD, VM, VW
- Sentence formatter VDR
- Input port J3 (NAV), J5 (EPFS), J6 (SDME)

Setting method of SET/DRIFT:

When a VDR sentence has been input, select SDME.

MENU > MAINTENANCE > I/O > SET/DRIFT > SET/DRIFT > SDME (or VDR) [ENT]

3.5 Input and setup of POSITION (LAT/LON)

Input conditions:

Transmission cycle	1 s
Baudrate (Format)	4800bps (IEC 61162-1), 9600bps, 19200bps or 3840bps (IEC 61162-2)
Talker device	GA, GP, GL, GN, IN, SN
Sentence formatter	GLL > GGA > GNS > RMC
Input port	J3 (NAV), J5 (EPFS), J6 (SDME)

Setting method of POSITION:

When navigation equipment is connected, select EPFS.

**MENU > MAINTENANCE > I/O > POSITION > POSITION > EPFS [ENT] (MDC-7900P/7000P)
AUTO [ENT] (Others)**

Note: Latitude and longitude can be manually input with selecting MAN. However, AIS cannot be used in this case.

Example of sentence:

GGA	Global positioning system (GPS) fixed data					
	\$GPGGA, 132636.55, 3513.858, N, 13947.596, E, 2, 7, 2.0, 51, M, M, *7B					
	<table> <tr> <td style="border: none;"> Sentence formatter Talker device Start of sentence </td> <td style="border: none; text-align: center;"> UTC 35° 13.858 N </td> <td style="border: none; text-align: center;"> Latitude, N/S 35° 13.858 N </td> <td style="border: none; text-align: center;"> Longitude, E/W 139° 47.596 E </td> <td style="border: none; text-align: right;"> Check sum *7B These fields are not used </td> </tr> </table>	Sentence formatter Talker device Start of sentence	UTC 35° 13.858 N	Latitude, N/S 35° 13.858 N	Longitude, E/W 139° 47.596 E	Check sum *7B These fields are not used
Sentence formatter Talker device Start of sentence	UTC 35° 13.858 N	Latitude, N/S 35° 13.858 N	Longitude, E/W 139° 47.596 E	Check sum *7B These fields are not used		
	<p style="text-align: center;">Vales according to a local geographical coordinate system of DTM</p> <p>GPS quality indicator 0: Fix not available or invalid 1: GPS SPS mode 2: Differential mode 3: GPS PPS mode 4: Real Time Kinematic 5: Float RTK 6: Estimated mode 7: Manual input mode 8: Simulator mode</p>					

In the case of this sentence, when Talker device is outside of the input conditions and when GPS quality indicator is 0 or 4 to 8, the latitude and longitude will be displayed with XX°XX.XXX in red.

Position offset

When MAP function is used and the referred geographical coordinate system is different from that of latitude and longitude input from GPS, etc., this is a function to align the position in MAP function with offsetting.

The latitude and longitude of the own ship's position is always those of the local geographical system of DTM.

When GPS outputs DTM:

**MENU>MAINTENANCE>I/O>POSITION>OFFSET>OFFSET>EPFS [ENT](MDC-7900P/7000P)
> DTM [ENT] (Others)**

Note: Setup of EPFS will become effective when DATUM of MAP menu and local geographical system of DTM agree with each other.

When offset is manually done:

**MENU > MAINTENANCE > I/O > POSITION > OFFSET > OFFSET > MAN [ENT]
MENU > MAINTENANCE > I/O > POSITION > OFFSET > LAT MAN 0.000N > 1.000N - 1.000S [ENT]
MENU > MAINTENANCE > I/O > POSITION > OFFSET > LON MAN 0.000E > 1.000E - 1.000W [ENT]**
Alternatively, offset can be set in the MAP menu.

3.6 Input and setup of DTM

DTM signal is usually input from GPS. DTM will inform about the type of Local datum system and the offset value of the reference datum system (WGS84).

Caution: The reference of AIS is WGS84. When the Local datum system of DTM output from GPS is other than WGS84, the latitude and longitude of GGA, etc. output by the same GPS will be with same the Local datum system and then they are different from the latitude and longitude of AIS. In the result, the position of AIS target displayed on radar will differ, and the risk of collision increases. Therefore, AIS cannot be used unless the Local datum system of DTM is WGS84.

Input conditions:

- Transmission cycle 1 s
- Baudrate (Format) 4800bps (IEC 61162-1), 9600bps, 19200bps or 3840bps (IEC 61162-2)
- Talker device GP, GL, GN, IN, SN
- Sentence formatter DTM
- Input port J3 (NAV), J5 (EPFS), J6 (SDME)

Setting method of DTM:

MENU > MAINTENANCE > I/O > POSITION OFFSET > EPFS (or DTM) [ENT]

Example of sentence:

DTM	Datum reference
	<p>\$GPDTM, P90, 1, N 1, E, W84*43</p> <p>Datum: W84: WGS84 W72: WGS72 S85: SGS85 P90: PE90 999: user</p>

3.7 Input and setup of TIME

Input conditions:

- Transmission cycle 1 s
- Baudrate (Format) 4800bps (IEC 61162-1), 9600bps, 19200bps or 3840bps (IEC 61162-2)
- Talker device GA, GP, GL, GN, IN, SN
- Sentence formatter ZDA > RMC > GGA
- Input port J3 (NAV), J5 (EPFS), J6 (SDME)

Setting method of POSITION:

When ZDA is input from navigation equipment, select EPFS.

MENU > MAINTENANCE > I/O > TIME > TIME > EPFS (or ZDA) [ENT]

When an incorporated clock is used, select CLOCK.

MENU > MAINTENANCE > I/O > TIME > TIME > CLOCK [ENT]

MENU > MAINTENANCE > I/O > TIME > CLOCK SET > DATE > DD/MM/YY [ENT]

MENU > MAINTENANCE > I/O > TIME > CLOCK SET > TIME > hh:mm [ENT]

Note: DD = day, MM = month, YY = year, hh = hour, mm = minute

3.8 Input and display of ROUTE

Input conditions:

Transmission cycle	1 s
Baudrate (Format)	4800bps (IEC 61162-1), 9600bps, 19200bps or 3840bps (IEC 61162-2)
Tarker device	GP, GL, GN, IN, SN
Sentence formatter	RTE/WPL
Input port	J3 (NAV), J5 (EPFS), J6 (SDME)

Setting of radar display:

When sentences of RTE and WPL are correctly input, route can be displayed on the radar screen as shown in the example.

Setting method:

Display of MAP shall be ON.

MDC-7000(P)/7900(P):

DISP > ON at the lower left corner

MDC-5000/5200/5500:


MENU > MAP > DISP > ON [ENT]

MONITORED (External I/O) ROUTE shall be ON.

MENU > MAP > MONITORED ROUTE > ON [ENT]

When identifier (ID) is displayed on WP, WPT ID DISP shall be ON.

MENU>MAP>WPT ID DISP>ON [ENT]



Route Image sample

Examples of sentences:

\$GPRTE, 1, 1, W, 000, 001, 002, 003, 004 *1B

Display of the case W:

\$GPWPL, 3511.976, N, 13947.060, E, 000, *7B

\$GPWPL, 3513.926, N, 13947.848, E, 001 *7C

\$GPWPL, 3518.156, N, 13948.570, E, 002 *71

\$GPWPL, 3520.509, N, 13950.795, E, 003 *75

\$GPWPL, 3525.821, N, 14002.405, E, 004 *73

Note 1: The number of WPL is needed to be the same as that of WP identifier for RTE.


Note 2: The designations of WP identifiers for RTE and WPL shall agree with each other.

Note 3: The message mode of RTE will be those in "W".


5. Connection of gyro convertor S2N

Connection table of CW-376 cable

CW-376			S2N
Pin No.	Signal name	Wire color	Name of signal
1	Shield	Blue+shield	NC
2	OUT-A	White	NC
3	OUT-B	Red	NC
4	IN-A	Orange	NMEA OUT A
5	IN-B	Black	NMEA OUT C
6	J3,J5:12V J6:NC	Green	NC




CW-376 cable connector pin assignment
Pin 1 Indicated



Cables to be supplied from owner



On-board power supply
18 VDC to 36 VDC



Connection diagram of S2N (As for the detail, refer to S2N Technical Description/Installation manual)

Connection of synchronous method

Connection of stepper method



Setup of S2N

To adapt the output of S2N to MDC-5000/5200/5500/7900(P)/7000(P) series, setup S2N in accordance with the table below:

Item	Menu No.	Set value	Item	Menu No.	Set value
Baud rate	3.1	38400	Heading talker id	3.6	HE
Heading update rate	3.4	20	Transmit checksum	3.7	on
Heading sentence	3.5	HDT			

Setting method of S2N:

Meaning of marks [=>], [→], [D/+] in the example:

[=>]: Pushing of [Set] once,

[←]: Pushing of [Exit] once,

[D/+]: Pushing of [Dim/+] once,

[]: Contents displayed on LED of S2N. In the display, xx is optional numerical figures.

Setting example in the case when the gyro ES-2 (Tokyo Keiki make) is set:

Start: [A x.x] => => [Align] D/+ [Setup] => [P 1] D/+ [P 2] => [P 2.1] => [Step] D/+ [Synch] => [P 2.1] ← [P 2] D/+ [P 3] => [P 3.1] => [4800] D/+ D/+ D/+ [38400] => [P 3.1] D/+ D/+ D/+ [P 3.4] => [1] D/+ D/+ D/+ D/+ [20] => [P 3.4] D/+ [P 3.5] => [Hdt] => [P 3.5] D/+ [P 3.6] => [He] => [P 3.6] D/+ [P 3.7] => [Off] D/+ [On] => [P 3.7] ← [P 3] **D/+ [P 4] => [P 4.1] => [22] D/+ [90] => [P 4.1] D/+ [P 4.2] => [180] D/+ D/+ D/+ [36] => [P 4.2] D/+ [P 4.3] => [Dc] D/+ [Ac] => [P 4.3] ←← [Align] => [A x.x].** At the time of this display, input the values of ship's bearing read from compass with D/+ D/-, and push [Set] key to end.

Note: In the setting example, the parts *in italic* may depend on the type of gyro to be used.

Setting of radar menu:

When the above setup is correct, MDC-5000/5200/5500/7900(P)/7000(P) series will operate under the factory default setup conditions.

The factory default setup values are as follows:


MENU > MAINTENANCE > I/O > FORMAT > GYRO > 61162-2 (For IMO)

MENU > MAINTENANCE > I/O > BAUDRATE > OP1 > Setting value (For non-IMO)



6. Gyro/Log interface: Connection of ADPC-101 unit (non-IMO)

Connection table of CW-376 cable


CW-376			ADPC-101
Pin No.	Signal name	Wire color	Signal name
1	Shield	Blue+shield	NC
2	OUT-A	White	NC
3	OUT-B	Red	NC
4	IN-A	Orange	RS-422 TX+
5	IN-B	Black	RS-422 TX-
6	J3,J5:12V J6:NC	Green	NC




CW-376 cable connector pin assignment
Pin 1 Indicated




Connection diagram of ADPC-101 (for detail, refer to ADPC-101 Technical manual)



Connection when GYRO is synchronous method



Connection when GYRO is step method



Setup of ADPC-101

After connection, setup the following values in accordance with the manual for ADPC-101:

Menu item	Set value	Menu item	Set value
GYRO ratio	Gear ratio of gyro	COM baud rate	38400
GYRO sign	Positive. Select negative when rotation is inverse.	COM parity	NO
GYRO type	Select synchronous method or step method for gyro.	COM stop bits	1 bit
GYRO ref polarity	Positive. Select negative when to be shifted by 180°.	NMEA REFRESH	10
LOG impulse/mile	Number of pulse per mile	NMEA GYRO fmt	HEHDT
LOG bounce delay	50 ms. Increase the value when chattering is detected.	NMEA LOG fmt	VMVBW

Setting of radar menu:

When the above setup is correct, MDC-5000/5200/5500/7900(P)/7000(P) series will operate under the factory default setup conditions.

The factory default setup values are as follows:


MENU > MAINTENANCE > I/O > FORMAT > GYRO 61162-2 (For IMO)
MENU > MAINTENANCE > I/O > BAUDRATE > OP1 > Setting value (For non-IMO)

MENU > MAINTENANCE > I/O > STW > STW > SDME (For IMO)
MENU > MAINTENANCE > I/O > STW > STW > (For non-IMO)


7. Connection of LOG pulse NMEA converter L1N (200 pulse/nautical mile only)

Connection table of CW-376 cable


CW-376			L1N
Pin No.	Signal name	Wire color	Signal name
1	shield	Blue and shield	NC
2	OUT-A	White	NC
3	OUT-B	Red	NC
4	IN-A	Orange	NMEA OUT A
5	IN-B	Black	NMEA OUT B
6	Ground	Green	NC




CW-376 cable connector pin assignment
Pin 1 Indicated



Cables to be from owner supplied



Connection diagram of L1N (For detail, refer to the manual for L1N Log pulse-NMEA converter)



Setting of radar menu:

When the above setup is correct, MDC-5000/5200/5500/7900(P)/7000(P) series will operate under the factory default setup conditions.


The factory default setup values are as follows:

MENU > MAINTENANCE > I/O > FORMAT > SDME > 61162-1 (For IMO)

MENU > MAINTENANCE > I/O > STW > STW > SDME (For non-IMO)

8. Connection of AIS


CW-387 cable connector pin assignment
Pin 1 Indicated



Connection table of CW-387 cable

Terminal No.	Color of wire	Name of signal
1	Shield	Frame ground
2	Blue	Twist cable IN-A
3	White	
4	Yellow	Twist cable OUT-B
5	Brown	
6	Green*	GND
7	Red	Twist cable NC
8	Grey	

*Green/Black twisted cable (Black is not used.)



AIS cable connection


MENU		
>MAINTENANCE		
>I/O		
HDG		GYRO
GPS		44.7°
OFFSET		0.0°
STW		SDME
		XXX.X kn
COG/SOG		EPFS
GPS		44.7°
GPS		13.3kn
POSITION		EPFS
GPS		35°27.511N
		139°50.065E
OFFSET		EPFS
		GPS
		0.000N
		0.000E
DATUM	REF	W84
	LOCAL	W84
SET/DRIFT		SDME
		0.0°
		0.0°
TIME		EPFS
GPS		08/07/17
		02:10
TIME ZONE		09:00
CLOCK SET		>
DETAIL		>

To connect AIS, at least HDG, COG/SOG, POSITION and DTM (WGS84) must be input.


The presence or not of these signals can be confirmed in the MENU > MAINTENANCE > I/O menu as shown in the left table.

The values encircled with rectangles in the left table are the necessary parts to indicate AIS. Please confirm that they have been input.

When there is no input of STW, stabilization mode shall be set with STAB GND as shown at the upper left of the figure below. With STAB SEA, AIS can be displayed.



Operation and example of display of AIS



UTC 17/07/08 02:54
 HDG GPS 043.3°
 COG GPS 044.2°
 SOG GPS 13.2kn

GPS 35°27.506N
 139°50.028E

VECT T 3min
 LIMIT CPA 1.0NM
 TPCA 1.0min
 LOST ALARM ON
 ASSOCIATION AIS
 AIS ON 177/254
 TT OFF 0/ 60
 PAST POSN REL OFF

FILTER CPA/TCPA OFF
 RNG 10.0NM
 CLASS BOTH
 AUTO ACQ CPA/TCPA ON
 RNG 3.0NM

Setting columns of TT (ATA) and AIS:

- VECT** : Vector length and mode of symbol
- LIMIT CPA•TCPA** : Constant to judge dangerous targets
- LOST ALARM** : ON/OFF of Lost alarm display
- ASSOCIATION** : Integrate to AIS or TT (ATA) symbol that is setup
- AIS** : ON/OFF of AIS display
- TT** : ON/OFF of TT (ATA) display
- PAST POSN** : Time setting of display period of trails of tacking targets

Setting columns of AIS:

- FILTER CPA/TCPA** : Only activated AIS is displayed.
- FILTER RNG** : Symbols within the setup distance are displayed.
- FILTER CLASS** : The type of AIS to be displayed is designated.
- AUTO ACQ CPA/TCPA** : AIS targets agreed with the values of LIMIT CPA/TCPA are activated.
- AUTO ACQ RNG** : AIS targets within the designated distance are activated.

A.3 System Program

Version confirmation

Currently installed firmware version can be found by using following menu operation.

- 1 Press **[MENU]** key to display "Menu".
Select **[MAINTENANCE]** => **[VERSION]** =>

(MDC-5000 series)

MRM-110

KM-F71 xx.xx ↩ Firmware version of Display unit

MRO-110

KM-E49 yy.yy ↩ Firmware version of Operation unit

(MDC-5200 series)

MRD-111

KM-F54 xx.xx

PANEL

KM-F49 yy.yy

(MDC-5500 series)

MRD-109

KM-F54 xx.xx ↩ Firmware version of Display unit

MRO-108

KM-F45 yy.yy ↩ Firmware version of Operation unit

(MDC-7900/7000/7900P/7000P series)

MRD/MRM-108/108P

KM-F44 xx.xx ↩ Firmware version of Display/Processor unit

MRO-108/108P

KM-F45 yy.yy ↩ Firmware version of Operation unit

How to update the system program

- 1 Prepare SD memory card with latest program.

File name: KM-FXX_Verxxxx

File type: MOT

- 2 Turn off the power.

- 3 Insert SD memory card into the SD card slot.

- 4 Press **POWER ON/OFF** key to turn on, radar will start update procedure automatically.

Message of "LOADING IN PROGRESS", "PLEASE DO NOT POWER OFF" etc., and time bar will be displayed.

During updating, **EBL1** and **VRM1**, **EBL2** and **VRM2**, **BRILL** and **PANEL** key's lamps flash red. (MRO-110/108/108P)

Few minutes later, when program update is complete, "LOADING COMPLETE" and "PLEASE EJECT SD CARD" messages will appear on the display.

- 5 Remove SD memory card from the card reader, and new system program will run automatically.

The list of updated program file will be shown on the display.

In some cases, message of "SHUTDOWN" is displayed, and power will be turned off.

In this case, please press **POWER ON/OFF** key again, and message of "INITIALIZING" may be displayed.

CAUTION: Put the cover firmly after the SD card Insert /Remove. Water protection of the Display unit is not guaranteed when the card reader cover is removed.



Koden Electronics Co., Ltd.

Tamagawa Office:

2-13-24 Tamagawa, Ota-ku, Tokyo, 146-0095 Japan

Tel: +81-3-3756-6501 Fax: +81-3-3756-6509

Uenohara Office:

5278 Uenohara, Uenohara-shi, Yamanashi, 409-0112 Japan

Tel: +81-554-20-5860 Fax: +81-554-20-5875

www.koden-electronics.co.jp